

# THE BMW X5. **OWNER'S MANUAL.**

# BMW Efficient Dynamics Less emissions. More driving pleasure.

#### **Owner's Manual for Vehicle X5**

Thank you for choosing a BMW.

The more familiar you are with your vehicle, the better control you will have on the road. We therefore strongly suggest:

Read this Owner's Manual before starting off in your new BMW. Also use the Integrated Owner's Manual in your vehicle. It contains important information on vehicle operation that will help you make full use of the technical features available in your BMW. The manual also contains information designed to enhance operating reliability and road safety, and to contribute to maintaining the value of your BMW.

Any updates made after the editorial deadline for the printed or Integrated Owner's Manual are located in the appendix of the printed quick reference for the vehicle.

Supplementary information can be found in the additional brochures in the onboard literature.

We wish you a safe and enjoyable drive.

**BMW AG** 

© 2013 Bayerische Motoren Werke Aktiengesellschaft Munich, Germany Reprinting, including excerpts, only with the written consent of BMW AG, Munich. US English VII/13, 07 13 490 Printed on environmentally friendly paper, bleached without chlorine, suitable for recycling.

# **Contents**

The fastest way to find information on a particular topic or item is by using the index, refer to page 246.

6 Notes

### At a glance

- 12 Cockpit
- 16 iDrive
- 24 Voice activation system
- 27 Integrated Owner's Manual in the vehicle

#### **Controls**

- 32 Opening and closing
- 49 Adjusting
- 62 Transporting children safely
- 66 Driving
- 80 Displays
- 95 Lamps
- 100 Safety
- 127 Driving stability control systems
- 134 Driving comfort
- 161 Climate control
- 171 Interior equipment
- 179 Storage compartments

## **Driving tips**

- 188 Things to remember when driving
- 192 Loading
- 195 Saving fuel

### **Mobility**

- 202 Refueling
- 204 Fuel
- 205 Wheels and tires
- 215 Engine compartment
- 217 Engine oil
- 219 Coolant
- 220 Maintenance
- 222 Replacing components
- 230 Breakdown assistance
- 235 Care

#### Reference

- 242 Technical data
- 246 Everything from A to Z

# **Notes**

# **Using this Owner's Manual**

The fastest way to find information on a particular topic is by using the index.

An initial overview of the vehicle is provided in the first chapter.

# Updates made after the editorial deadline

Any updates made after the editorial deadline for the Owner's Manuals are located in the appendix of the printed quick reference for the vehicle.

# User's manual for Navigation, Entertainment, Communication

The topics of Navigation, Entertainment, Communication and the short commands of the voice activation system are described in a separate user's manual, which is also included with the onboard literature.

#### Additional sources of information

Should you have any questions, your service center will be glad to advise you at any time. Information on BMW, e.g., on technology, is available on the Internet: bmwusa.com.

# Symbols in the Owner's Manual

- A Indicates precautions that must be followed precisely in order to avoid the possibility of personal injury and serious damage to the vehicle.
- Marks the end of a specific item of information.
- "..." Identifies Control Display texts used to select individual functions.

- >.... Verbal instructions to use with the voice activation system.
- »...« Identifies the answers generated by the voice activation system.
- Refers to measures that can be taken to help protect the environment.

### Symbols on vehicle components

Il Indicates that you should consult the relevant section of this Owner's Manual for information on a particular part or assembly.

## Vehicle equipment

This Owner's Manual describes all models and all standard, country-specific and optional equipment that is offered in the model series. Therefore, in this Owner's Manual, equipment is also described and illustrated that is not available in your vehicle, e.g., because of the selected optional equipment or the country-specific variants.

This also applies for safety-related functions and systems.

For options and equipment not described in this Owner's Manual, please refer to the Supplementary Owner's Manuals.

On right-hand drive vehicles, some controls are arranged differently than shown in the illustrations.

# Status of the Owner's Manual

The manufacturer of your vehicle pursues a policy of constant development that is conceived to ensure that our vehicles continue to embody the highest quality and safety standards. In rare cases, therefore, the features de-

scribed in this Owner's Manual may differ from those in your vehicle.

# Updates made after the editorial deadline

Any updates made after the editorial deadline for the Owner's Manuals are located in the appendix of the printed quick reference for the vehicle.

## For your own safety

### Maintenance and repairs

Advanced technology, e.g., the use of modern materials and high-performance electronics, requires suitable maintenance and repair methods.

Therefore, have this work performed only by a BMW center or a workshop that works according to BMW repair procedures with appropriately trained personnel.

If this work is not carried out properly, there is the danger of subsequent damage and related safety hazards.

#### **Parts and Accessories**

For your own safety, use genuine parts and accessories approved by BMW. When you purchase accessories tested and approved by BMW and Genuine BMW Parts, you simultaneously acquire the assurance that they have been thoroughly tested by BMW to ensure optimum performance when installed on your vehicle. BMW warrants these parts to be free from defects in material and workmanship. BMW will not accept any liability for damage resulting from installation of parts and accessories not approved by BMW. BMW cannot test every product made by other manufacturers to verify if it can be used on a BMW safely and without risk to either the vehicle, its operation, or its occupants. Genuine BMW Parts, BMW Accessories and other products approved by BMW, together with professional

advice on using these items, are available from all BMW centers. Installation and operation of non-BMW approved accessories such as alarms, radios, amplifiers, radar detectors, wheels, suspension components, brake dust shields, telephones, including operation of any mobile phone from within the vehicle without using an externally mounted antenna, or transceiver equipment, for instance, CBs, walkietalkies, ham radios or similar accessories, may cause extensive damage to the vehicle, compromise its safety, interfere with the vehicle's electrical system or affect the validity of the BMW Limited Warranty. See your BMW center for additional information. Maintenance, replacement, or repair of the emission control devices and systems may be performed by any automotive repair establishment or individual using any certified automotive part.

### **California Proposition 65 Warning**

California laws require us to state the following warning:

Engine exhaust and a wide variety of automobile components and parts, including components found in the interior furnishings in a vehicle, contain or emit chemicals known to the State of California to cause cancer and birth defects and reproductive harm. In addition, certain fluids contained in vehicles and certain products of component wear contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Battery posts, terminals and related accessories contain lead and lead compounds. Wash your hands after handling. Used engine oil contains chemicals that have caused cancer in laboratory animals. Always protect your skin by washing thoroughly with soap and water.

## Service and warranty

We recommend that you read this publication thoroughly. Your vehicle is covered by the following warranties:

- New Vehicle Limited Warranty.
- Rust Perforation Limited Warranty.
- Federal Emissions System Defect Warranty.
- ▶ Federal Emissions Performance Warranty.
- California Emission Control System Limited Warranty.

Detailed information about these warranties is listed in the Service and Warranty Information Booklet for US models or in the Warranty and Service Guide Booklet for Canadian models.

Your vehicle has been specifically adapted and designed to meet the particular operating conditions and homologation requirements in your country and continental region in order to deliver the full driving pleasure while the vehicle is operated under those conditions. If you wish to operate your vehicle in another country or region, you may be required to adapt your vehicle to meet different prevailing operating conditions and homologation requirements. You should also be aware of any applicable warranty limitations or exclusions for such country or region. In such case, please contact Customer Relations for further information.

#### Maintenance

Maintain the vehicle regularly to sustain the road safety, operational reliability and the New Vehicle Limited Warranty.

Specifications for required maintenance measures:

- BMW Maintenance system
- Service and Warranty Information Booklet for US models
- Warranty and Service Guide Booklet for Canadian models

If the vehicle is not maintained according to these specifications, this could result in serious damage to the vehicle. Such damage is not covered by the BMW New Vehicle Limited Warranty.

## **Data memory**

Many electronic components on your vehicle are equipped with data memories that temporarily or permanently store technical information about the condition of the vehicle, events and faults. This technical information generally documents the state of a component, a module, a system or the environment:

- Operating states of system components, fill levels for instance.
- Status messages for the vehicle and from its individual components, e.g., wheel rotation speed/ vehicle speed, deceleration, transverse acceleration.
- ▶ Malfunctions and faults in important system components, e.g., lights and brakes.
- Responses by the vehicle to special situations, e.g., deployment of an airbag, engagement of stability control systems.
- Ambient conditions, such as temperature.

This data is purely technical in nature and is used to detect and correct faults and to optimize vehicle functions. Motion profiles over routes traveled cannot be created from this data. When service offerings are used, e.g., repair services, service processes, warranty claims, quality assurance, this technical information can be read out from the event and fault memories by the service personnel, including the manufacturer, using special diagnostic tools. You can obtain further information there if it is needed. After a fault is corrected, the information in the fault memory is deleted or overwritten on a continuous basis.

When the vehicle is in use, situations are conceivable in which it might be possible to associate this technical data with individuals if it is combined with other information, e.g., an accident report, damage to the vehicle, eye witness accounts — possibly with the assistance of an expert.

Additional functions that are contractually agreed with the customer, such as vehicle lo-

cating in an emergency, enable certain vehicle data to be transmitted from the vehicle.

### **Event Data Recorder EDR**

This vehicle is equipped with an event data recorder EDR. The main purpose of an EDR is to record, in certain crash or near crash-like situations, such as an air bag deployment or hitting a road obstacle, data that will assist in understanding how a vehicle's systems performed. The EDR is designed to record data related to vehicle dynamics and safety systems for a short period of time, typically 30 seconds or less.

The EDR in this vehicle is designed to record such data as:

- How various systems in your vehicle were operating.
- Whether or not the driver and passenger safety belts were fastened.
- How far, if at all, the driver was depressing the accelerator and/or brake pedal.
- How fast the vehicle was traveling.

These data can help provide a better understanding of the circumstances in which crashes and injuries occur.

EDR data are recorded by your vehicle only if a nontrivial crash situation occurs; no data are recorded by the EDR under normal driving conditions and no personal data, e.g., name, gender, age, and crash location, are recorded.

However, other parties, such as law enforcement, could combine the EDR data with the type of personally identifying data routinely acquired during a crash investigation.

To read data recorded by an EDR, special equipment is required, and access to the vehicle or the EDR is needed. In addition to the vehicle manufacturer, other parties, such as law enforcement, that have the special equipment, can read the information if they have access to the vehicle or the EDR.

## **Reporting safety defects**

#### For US customers

The following only applies to vehicles owned and operated in the US.

If you believe that your vehicle has a defect which could cause a crash or could cause injury or death, you should immediately inform the National Highway Traffic Safety Administration NHTSA, in addition to notifying BMW of North America, LLC, P.O. Box 1227, Westwood, New Jersey 07675-1227, Telephone 1-800-831-1117.

If NHTSA receives similar complaints, it may open an investigation, and if it finds that a safety defect exists in a group of vehicles, it may order a recall and remedy campaign.


However, NHTSA cannot become involved in individual problems between you, your dealer, or BMW of North America, LLC.

To contact NHTSA, you may call the Vehicle Safety Hotline toll-free at 1-888-327-4236 (TTY: 1-800-424-9153); go to http://www.safercar.gov; or write to: Administrator, NHTSA, 400 Seventh Street, SW., Washington, DC 20590. You can also obtain other information about motor vehicle safety from http://www.safercar.gov

#### For Canadian customers

Canadian customers who wish to report a safety-related defect to Transport Canada, Defect Investigations and Recalls, may telephone the toll-free hotline 1-800-333-0510. You can also obtain other information about motor vehicle safety from http://www.tc.gc.ca/roadsafety.






# **Cockpit**

# Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equip-

ment is also described that is not available in a vehicle, e.g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

# All around the steering wheel



- 1 Rear window safety switch 46
- 2 Power windows 45
- 3 Exterior mirror operation 58



Opening and closing top tailgate 38



Unlocking central locking system 38



Locking central locking system 38

6 Lamps



Front fog lamps 98



Parking lamps 95



Low beams 95



Automatic headlamp control 96

Daytime running lights 96 Adaptive Light Control 96

High-beam Assistant 97



Instrument lighting 98



Night Vision, switch on/switch off heat image 117

7 Steering column stalk, left



Turn signal 73



High beams, headlamp flasher 73



High-beam Assistant 97



Roadside parking lamps 96



Computer 91

8 Steering wheel buttons, left



Store speed 143, 134



Resume speed 145, 137



Cruise control on/off, interrupting 134



Cruise control on/off, interrupting 144



Congestion Assistant ON/OFF, Pause 140



Congestion Assistant: setting cruise control distance 134

Cruise control rocker switch 144, 136

9 Shift paddles 79

10 Instrument cluster 80

11 Steering wheel buttons, right

MODE

Entertainment source



Volume



Voice activation 24



Telephone, see user's manual for Navigation, Entertainment and Communication

Thumbwheel for selection lists 91

12 Steering column stalk, right



Windshield wipers 74



Rain sensor 74



Clean the windshields and headlamps 74



Rear window wiper in Canadian models 75



Rear window wiper 75



Cleaning rear window 75



Start/stop the engine and switch the ignition on/off 67





Auto Start/Stop function 68

15 Horn




Steering wheel heating 60



Adjust steering wheel 60

#### 18 Unlock hood 215

## All around the center console



- 1 All around the headliner 15
- 2 Control Display 16
- 3 Glove compartment 179
- 4 Ventilation 164



Hazard warning system 230



Intelligent Safety button 108

- 6 Automatic climate control 161
- 7 Radio/CD/Multimedia, see user's manual for Navigation, Entertainment and Communication
- 8 Controller with buttons 16



Parking brake 70

10

Auto Hold 71

11 P//<u>A</u>

PDC Park Distance Control 145

Rearview camera 148

Top View 151

Parking assistant 155
Panorama View 153





HDC Hill Descent Control 129

SPORT

COMFORT


Driving Dynamics Control 131



DSC Dynamic Stability Control 128

### **14** Transmission selector lever **76**

## All around the headliner



1 505

Intelligent Emergency Request 230

Readi

Reading lamps 99

2 \_\_\_

Panoramic glass sunroof 47

Interior lamps 99

3

PASS AIR BAG OFF Indicator lamp, front passenger airbag 102

6 Glasses compartment 182

# **iDrive**

# Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

## The concept

The iDrive combines the functions of a multitude of switches. Thus, these functions can be operated from a central location.

Using the iDrive during a trip

To avoid becoming distracted and posing an unnecessary hazard to your vehicle's occupants and to other road users, never attempt to use the controls or enter information unless traffic and road conditions allow this.

## Controls at a glance

#### **Controls**



- 1 Control Display
- 2 Controller with buttons and touchpad The buttons can be used to open the menus directly. The controller can be used to select menu items and create the settings.


### **Control Display**

#### Hints

- ▶ To clean the Control Display, follow the care instructions.
- Do not place objects close to the Control Display; otherwise, the Control Display can be damaged.

### **Switching off**

- OPTION
  - Press the button.
- 2. "Switch off control display"



### Switching on

Press the controller again to switch the screen back on.

## **Controller with navigation system**

Select menu items and create settings.


1. Turn.



#### 2. Press.



### 3. Move in four directions.



### **Buttons on controller**

Press the but- ton	Function
MENU	Open the main menu.
RADIO	Opens the Radio menu.
MEDIA	Opens the CD/Multimedia menu.
NAV	Opens the Navigation menu.
TEL	Opens the Telephone menu.
BACK	Displays the previous panel.
OPTION	Opens the Options menu.

## **Controller without navigation system**

Select menu items and create settings.


### 1. Turn.



### 2. Press.



### 3. Move in two directions.



## **Buttons on controller**

Press the button	Function
MENU	Open the main menu.
Audio	Open audio menu last listened to, switch between audio menus.
TEL	Opens the Telephone menu.


Press the but- ton	Function
BACK	Open previous panel.
OPTION	Opens the Options menu.

## **Operating concept**

## Opening the main menu

MENU

Press the button.




The main menu is displayed.

All iDrive functions can be called up via the main menu.

## Selecting menu items

Menu items shown in white can be selected.

 Turn the controller until the desired menu item is highlighted.



Press the controller.

### Menu items in the Owner's Manual

In the Owner's Manual, menu items that can be selected are set in quotation marks, e.g., "Settings".

### **Changing between panels**

After a menu item is selected, e.g., "Radio", a new panel is displayed. Panels can overlap.

- Move the controller to the left.
  - The current panel is closed and the previous panel is displayed.
  - The previous panel is opened again by pressing the BACK button. In this case, the current panel is not closed.
- Move the controller to the right.
   A new panel is opened on top of the previous display.



White arrows pointing to the left or right indicate that additional panels can be opened.

## View of an opened menu

When a menu is opened, it generally opens with the panel that was last selected in that menu. To display the first panel of a menu:


- Move the controller to the left repeatedly until the first panel is displayed.
- Press the menu button on the controller twice.

## **Opening the Options menu**



Press the button.

The "Options" menu is displayed.



Additional options: move the controller to the right repeatedly until the "Options" menu is displayed.


### **Options menu**

The "Options" menu consists of various areas:

- Screen settings, e.g., "Split screen".This area remains unchanged.
- ▶ Control options for the selected main menu, e.g., for "Radio".
- ▶ If applicable, further operating options for the selected menu, e.g., "Store station".

### **Changing settings**

- 1. Select a field.
- Turn the controller until the desired setting is displayed.



Press the controller.

## **Activating/deactivating the functions**

Several menu items are preceded by a checkbox. It indicates whether the function is activated or deactivated. Selecting the menu item activates or deactivates the function.

The function is activated.

The function is deactivated.

# **Touchpad**

Some iDrive functions can be operated using the touchpad on the controller:

### **Selecting functions**

- 1. "Settings"
- "Touchpad"
- Select the desired function.
  - "Speller": letters and numbers, entering.
  - "Map": operating the interactive map.
  - ▶ "Browser": enter Internet addresses.
  - "Audio feedback": the entered letters and numbers are announced.

### **Entering letters and numbers**

The entry of the letters requires some practice at the beginning. In the entry, pay attention to the following:

- For the entry of large/small letters and numbers, first convert via iDrive to the corresponding Input mode, refer to page 22.
- ▶ Enter characters as they are displayed on the Control Display.
- Always enter accompanying signs, such as accents or periods so that the letter can be clearly recognized.
- ➤ To delete a character, slide to the left on the touchpad.

## Operating the interactive map

The interactive map in the navigation system can be moved via the touchpad.

Function	Controls
Interactive map.	Slide in the corresponding direction.
Enlarge/shrink interactive map.	Drag the display inwards or outwards with the fingers.
Display menu.	Tap once.


## **Changing settings**

Settings on the control display, such as the volume, can be made via the touchpad. To do this slide to the left or right accordingly.

# **Example: setting the clock**

### Setting the clock

- Press the button. The main menu is displayed.
- 2. Turn the controller until "Settings" is highlighted, and then press the controller.




3. If necessary, move the controller to the left to display "Time/Date".

Turn the controller until "Time/Date" is highlighted, and then press the controller.



Turn the controller until "Time:" is highlighted, and then press the controller.



- Turn the controller to set the hours and press the controller.
- Turn the controller to set the minutes and press the controller.

## Status information

#### Status field

The following information is displayed in the status field at the top right:

- Time.
- Current entertainment source.
- Sound output, on/off.
- Wireless network reception strength.
- Telephone status.
- Traffic bulletin reception.

## Status field symbols

The symbols are grouped as follows.

### Radio symbols

Symbol	Meaning
1.	Satellite radio is switched on.

## **Telephone symbols**

Symbol	Meaning
<u></u>	Incoming or outgoing call.
Š	Missed call.
atl	Wireless network reception strength Symbol flashes: searching for network.
atl	Wireless network is not available.
3	Bluetooth is switched on.
$\blacktriangle$	Roaming is active.
$\bowtie$	Text message was received.
<b></b> ©	Check the SIM card.
<b>■</b> Î	SIM card is blocked.
<b>/</b>	SIM card is missing.
	Enter the PIN.

## **Entertainment symbols**

Symbol	Meaning
<b>(3)</b>	CD/DVD player.
	Music collection.
gracenote	Gracenote® database.
P	AUX-IN port.
<b>₽</b> AUX-L	Rear AUX-IN port on the left.
<b> ∕</b> AUX-R	Rear AUX-IN port on the right.

### **Additional symbols**

Symbol	Meaning
炣	Spoken instructions are switched off.

## **Split screen**

#### General information

Additional information can be displayed on the right side of the split screen, e.g., information from the computer.


In the divided screen view, the so-called split screen, this information remains visible even when you change to another menu.

## Switching the split screen on and off

- 1. Press the button.
- 2. "Split screen"

## **Selecting the display**

- 1. Press the button.
- 2. "Split screen"
- Move the controller until the split screen is selected.
- Press the controller or select "Split screen content".
- 5. Select the desired menu item.



# Programmable memory buttons

### **General information**

The iDrive functions can be stored on the programmable memory buttons and called up directly, e.g., radio stations, navigation destinations, phone numbers and entry points into the menu.

The settings are stored for the remote control currently in use.

### Saving a function

- 1. Highlight the function via the iDrive.
- 2. 1...8 Press the desired button for more than 2 seconds.


### **Running a function**

Press the button.
The function will run immediately. This means, for example, that the number is dialed when a phone number is selected.

## Displaying the button assignment

Use a finger to touch the buttons. Do not wear gloves or use objects.

The key assignment is displayed at the top edge of the screen.



- To display short information: touch the button.
- To display detailed information: touch the button for an extended period.

### **Deleting the button assignments**

- Press buttons 1 and 8 simultaneously for approx. five seconds.
- 2. "OK"

# **Entering letters and numbers**

### **General information**

- Turn the controller: select letters or numbers.
- Select additional letters or numbers if needed.
- 3. "OK": confirm the entry.

Depending on the menu, you can switch between entering upper and lower case, letters and numbers:

Symbol	Function
l←	Press the controller: delete the letter or number.
l←	Press the controller for an extended period: delete all letters or numbers.

# Switching between cases, letters and numbers

Depending on the menu, you can switch between entering upper and lower case, letters and numbers:

Symbol	Function
A <sup>B</sup> C	Enter the letters.
1@+	Enter the numbers.
abc or ABC	Move the controller up.

## Without navigation system

### **Entry comparison**

Entry of names and addresses: the selection is narrowed down every time a letter is entered and letters may be added automatically.

The entries are continuously compared to the data stored in the vehicle.

- Only those letters are offered during the entry for which data is available.
- Destination search: town/city names can be entered using the spelling of language available on the Control Display.

# Voice activation system

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

# The concept

- Most functions that are displayed on the Control Display can be operated by spoken commands via the voice activation system. The system prompts you to make your entries.
- Functions that can only be used when the vehicle is stationary cannot be operated using the voice activation system.
- The system uses a special microphone on the driver's side.
- > .... Verbal instructions in the Owner's Manual to use with the voice activation system.


## Requirements

Via the Control Display, set a language that is also supported by the voice activation system so that the spoken commands can be identified.

Set the language, refer to page 94.

## **Using voice activation**

### Activating the voice activation system



- 2. Wait for the signal.
- Say the command.The command is displayed in the instrument cluster.

If no other commands are available, operate the function in this case via iDrive.

# Terminating the voice activation system



Briefly press the button on the steering wheel or Cancek.

## Possible commands

Most menu items on the Control Display can be voiced as commands.

The available commands depend on which menu is currently displayed on the Control Display.

Short commands exist for many functions.

Some list entries, e.g., Phone book entries, can also be selected via the voice activation system. Speak these list entries exactly as they are displayed in the respective list.

## Having possible commands read aloud

You can have the available commands read out loud for you: >Voice commands

For example, if the "Settings" menu is displayed, the commands for the settings are read out loud.

# **Executing functions using short commands**

Functions on the main menu can be performed directly by means of short commands, nearly irrespective of which menu item is currently selected, e.g., Vehicle status.

List of short commands of the voice activation system, see Navigation, Entertainment, Communication Owner's Manual.

# Help dialog for the voice activation system

Calling up help dialog: >Help«

Additional commands for the help dialog:

- Help with examples: information about the current operating options and the most important commands for them are announced.
- Help with voice activation: information about the principle of operation for the voice activation system is announced.

## **Example: playing back a CD**

#### Via the main menu

The commands of the menu items are spoken just as they are selected via the controller.

- Switch on the Entertainment sound output if necessary.
- 2. Press the button on the steering wheel.
- Multimedia
   The medium last played is played back.
- 4. →C Do
- 5. ⇒C D drived
- 6. →Track ..., e.g., CD track 4.

#### Via short command

Playback of the CD can also be started via a short command.

- 1. Switch on the Entertainment sound output if necessary.
- 2. Press the button on the steering wheel.
- 3. →C D drive track ...<, e.g., CD track 4.


# **Setting the voice dialog**

You can set whether the system should use the standard dialog or a shorter version.

In the shorter variant of the voice dialog, the announcements from the system are issued in an abbreviated form.

On the Control Display:

- 1. "Settings"
- 2. "Language/Units"
- 3. "Speech mode:"
- Select the setting.



# Adjusting the volume

Turn the volume button while giving an instruction until the desired volume is set.

- The volume remains constant even if the volume of other audio sources is changed.
- The volume is stored for the remote control currently in use.

# Notes on Emergency Requests

Do not use the voice activation system to initiate an Emergency Request. In stressful situations, the voice and vocal pitch can change. This can unnecessarily delay the establishment of a telephone connection.

Instead, use the SOS button, refer to page 230, in the vicinity of the interior mirror.

### **Environmental conditions**

- Say the commands, numbers, and letters smoothly and with normal volume, emphasis, and speed.
- Always say commands in the language of the voice activation system.
- Keep the doors, windows, and glass sunroof closed to prevent noise interference.
- Avoid making other noise in the vehicle while speaking.

# **Integrated Owner's Manual in the vehicle**

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

# Integrated Owner's Manual in the vehicle

The Integrated Owner's Manual can be displayed on the Control Display. The equipment and functions that are in the vehicle are described therein.

### Components of the integrated Owner's Manual

The integrated Owner's Manual consists of three parts, which offer various levels of information or access possibilities.

#### **Quick Reference Guide**

Located in the Quick Reference is important information for the operation of the vehicle, the operation of basic vehicle functions or for what to do in the event of a flat tire. This information can also be displayed during driving.

## **Search by pictures**


Information and descriptions based on illustrations can be searched via search by pictures. This is helpful, for example, if the description of an outfitting package that cannot be named is needed.

#### Owner's Manual

Information and descriptions can be searched by direct entry of a search term via the index.

### **Select components**

- Press the button.
- 2. Turn the controller: open "Vehicle Info".
- 3. Press the controller.
- 4. Selecting desired range:
  - "Quick reference"
  - "Search by pictures"
  - "Owner's Manual"



## **Leafing through the Owner's Manual**

## Page by page with link access

Turn the controller until the next or previous page is displayed.

## Page by page without link access

Leaf through the pages directly while skipping the links.

Highlight the symbol once. Now simply press the controller to leaf from page to page.



Leaf back.



Leaf forward.

# Context help - Owner's Manual to the temporarily selected function

The relevant information can be opened directly.

### Opening via the iDrive

To move directly from the application on the Control Display to the options menu:

- 1. Press the button or move the controller to the right repeatedly until the "Options" menu is displayed.
- 2. "Display Owner's Manual"

# Opening when a Check Control message is displayed

Directly from the Check Control message on the Control Display:

"Display Owner's Manual"

### Changing between a function and the Owner's Manual

To change from a function, e.g., radio, to the Owner's Manual on the Control Display and to switch between the two displays:

- 1. Press the button or move the controller to the right repeatedly until the "Options" menu is displayed.
- 2. "Display Owner's Manual"
- Select the desired page in the Owner's Manual.
- Press the button again to return to the function displayed last.
- 5. Press the button to return to the page of the Owner's Manual displayed last.

To switch back and forth repeatedly between the function displayed last and the page of the Owner's Manual displayed last, repeat steps 4 and 5. This opens a new panel every time.

### **Programmable memory buttons**

### **General information**

The Owner's Manual can be stored on the programmable memory buttons and called up directly.


### **Storing**

- 1. "Owner's Manual" Select via the iDrive.
- 2. Press the desired button for more than 2 seconds.

### **Executing**

Press the button.
The Owner's Manual is displayed immediately.





# **Opening and closing**

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

## Remote control/key

### **Buttons on the remote control**



- 1 Unlocking
- 2 Locking
- 3 Opening the tailgate
- 4 Panic mode

#### General information

The vehicle is supplied with two remote controls with keys.

Every remote control contains a replaceable battery.

The settings called up and implemented when the car is unlocked depend on which remote control is used to unlock the car. Personal Profile, refer to page 33.

Information on the required maintenance is stored in the remote control as well. Service data in the remote control, refer to page 220

### **Integrated key**




Press the button on the back of the remote control, arrow 1, and pull out the key, arrow 2.

The integrated key fits the following locks:

- Driver's door.
- Glove compartment on the front passenger side.

### Replacing the battery



- Take the integrated key out of the remote control.
- 2. Push in the catch with the key, arrow 1.
- Remove the cover of the battery compartment; see arrow 2.
- 4. Insert a battery of the same type with the positive side facing upwards.
- Press the cover closed.



Take the used battery to a recycling center or to your service center.

#### **New remote controls**

You can obtain new remote controls from your service center.

#### Loss of the remote controls

Lost remote controls can be blocked by your service center.


# **Emergency detection of remote** control

It is possible to switch on the ignition or start the engine in situations such as the following:

- Interference of radio transmission to remote control by external sources.
- Discharged battery in the remote control.
- Interference of radio transmission by mobile devices in close proximity to the remote control.
- Interference of radio transmission by charger while charging items such as mobile devices in the vehicle.

A Check Control message is displayed if an attempt is made to switch on the ignition or start the engine.

# Starting the engine with emergency detection of the remote control



If a corresponding Check Control message appears, hold the remote control vertically against the marked area on the steering column and press the Start/Stop button within 10 seconds while pressing the brake.

### **Personal Profile**

### The concept

You can set several of your vehicle's functions to suit your personal needs and preferences.

- The settings are automatically saved in the profile currently activated.
- The remote control used is detected when the vehicle is unlocked and the stored profile is called up.
- Your personal settings will be recognized and called up again even if the vehicle has been used in the meantime by someone else with another remote control.

The individual settings are stored for three Personal Profiles and one guest profile.

### **Transmitting the settings**

Your personal settings can be taken with you to another vehicle equipped with the Personal Profile function. For more information, contact your service center.

Transmission takes place via:

- The USB interface in the center armrest onto a USB device.
- BMW Online.

## **Profile management**

## **Opening the profiles**

A different profile can be called up than the one associated with the remote control currently in use.

- 1. "Settings"
- 2. "Profiles"
- 3. Select a profile.

Called up profile is assigned to the remote control being used at the time.

### **Renaming profiles**

- "Settings"
- 2. "Profiles"

The current profile is selected.

- 3. Open "Options".
- 4. "Rename current profile"

### **Resetting profiles**

The settings of the active profile are reset to their default values.

- 1. "Settings"
- 2. "Profiles"

The current profile is selected.

- 3. Open "Options".
- 4. "Reset current profile"

### **Importing profiles**

Existing settings and contacts are overwritten with the imported profile.

- "Settings"
- "Profiles"
- 3. "Import profile"
- BMW Online: "BMW Online"
   USB interface, refer to page 175: "USB device"

## **Exporting profiles**

Most settings of the active profile and the saved contacts can be exported.

This can be helpful for securing and retrieving personal settings, before delivering the vehicle to a workshop for example.

- "Settings"
- 2. "Profiles"
- "Export profile"
- BMW Online: "BMW Online"
   USB interface, refer to page 175: "USB device"

### Using the guest profile

The guest profile can be used to make individual settings without affecting the three Personal Profiles.

This can be useful for drivers who are using the vehicle temporarily and do not have their own profile.

- 1. "Settings"
- "Profiles"
  The current profile is selected.
- 3. Open "Guest".
- 4. Create the settings.

Note: the guest profile cannot be renamed.

## Display profile list during start

The profile list can be displayed during each start for selecting the desired profile.

- "Settings"
- 2. "Profiles"
- Open "Options".
- 4. "Display user list at startup"

## Personal Profile settings

The following functions and settings can be stored in a profile.

- Collision warning: warning time.
- Exterior mirror position.
- CD/Multimedia: audio source listened to last.
- Unlocking/locking of the vehicle: settings.
- Driving Dynamics Control: sport program.
- Driver's seat position: automatic retrieval after unlocking.
- Programmable memory buttons: assignment.
- ► Head-up Display: selection, brightness, position and rotation of the display.
- Headlamp courtesy delay feature: time setting.

- Tone: tone settings.
- Automatic climate control: settings.
- Steering wheel position.
- Navigation: map views, route criteria, voice output on/off.
- Night Vision with pedestrian detection.
- Intelligent Safety: individual settings.
- Park Distance Control PDC: adjusting the signal tone volume.
- Radio: stored stations, station listened to last, special settings.
- Rearview camera: selection of functions and type of display.
- Side View: selection of the display type.
- Language on the Control Display.
- Lane departure warning: last setting, on/ off.
- Active Blind Spot Detection: last setting, on/off.
- Daytime running lights: current setting.
- Triple turn signal activation.
- Locking the vehicle: after a brief period or after starting to drive.

# **Central locking system**

### The concept

The central locking system becomes active when the driver's door is closed.

The system simultaneously engages and releases the locks on the following:

- Doors.
- Tailgate.
- Fuel filler flap.

## **Operating from the outside**

- Via the remote control.
- Via the door handles.
- Via the button on the tailgate.

The following takes place simultaneously when locking/unlocking the vehicle via the remote control:

- Depending on how the vehicle is equipped, the theft protection is activated/deactivated. Theft protection prevents the doors from being unlocked using the lock buttons or the door opener.
- The welcome lamps, interior lamps and courtesy lamps are switched on and off.
- ▶ The alarm system, refer to page 44, is armed or disarmed.

## Operating from the inside



Press the button.

Vehicle is locked.

Press the button.

The vehicle is unlocked.

If the vehicle has been locked from inside, the fuel filler flap remains unlocked.

If an accident of a certain severity occurs, the central locking system unlocks automatically.

The hazard warning system and interior lamps come on.

# Opening and closing: from the outside

### Using the remote control

#### **General information**

Take the remote control with you People or animals left unattended in a parked vehicle can lock the doors from the inside. Always take the remote control with you when leaving the vehicle so that the vehicle can then be opened from the outside.

### **Unlocking**



Press the button on the remote con-

The vehicle is unlocked.

Welcome lamps, interior lamp and courtesy lamps are switched on.

You can set how the vehicle is to be unlocked. Create the settings, refer to page 43.

### **Convenient opening**

The remote control can be used to simultaneously open the windows and the glass sunroof.



Press and hold the button on the remote control.

The windows and the glass sunroof open. Releasing the button stops the motion.

### Locking



Press the button on the remote control.

Locking from the outside

Do not lock the vehicle from the outside if there are people in it, as the vehicle cannot be unlocked from inside without special knowledge.

# Switching on interior lamps and courtesy lamps



Press the button on the remote control with the vehicle locked.

#### Panic mode

You can trigger the alarm system if you find yourself in a dangerous situation.



Press the button on the remote control for at least 3 seconds.

To switch off the alarm: press any button.

### Opening the tailgate



Press the button on the remote control for approx. 1 second and release.

The tailgate opens automatically, regardless of whether it was previously locked or unlocked.

The tailgate pivots back and up when it opens. Ensure that adequate clearance is available before opening.

This button can also be used to unlock the doors. The button assignment on the remote control can be set variously depending on how the vehicle is equipped and according to the country-specific variant.

In some vehicle equipment variants, the tailgate can only be opened using the remote control if the vehicle has been unlocked.



Do not place the remote control in the cargo area

Take the remote control with you and do not leave it in the cargo area; otherwise, the remote control is locked inside the vehicle when the tailgate is closed.◀

The tailgate is locked again as soon as it is pushed closed.

Provide edge protection

Sharp or angular objects can hit the rear window while driving and damage the heating wires of the rear window. Provide edge protection.

#### Malfunction

If the vehicle can no longer be locked or unlocked with the remote control, the battery may be discharged or there may be interference from external sources such as mobile phones, metal objects, overhead power lines, transmission towers, etc.

If this occurs, lock or unlock the driver's door at the door lock using the integrated key.

#### For US owners only

The transmitter and receiver units comply with part 15 of the FCC/Federal Communication Commission regulations. Operation is governed by the following:

#### FCC ID:

- LX8766S.
- LX8766E.
- LX8CAS.
- LX8CAS2.
- MYTCAS4.

Compliance statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modifications or changes to these devices could void the user's authority to operate this equipment.

## Using the door lock

#### **General information**

Locking from the outside

Do not lock the vehicle from the outside if there are people in it, as the vehicle cannot be unlocked from inside without special knowledge.

The alarm system is triggered when the door is opened, if the vehicle is unlocked via the door lock.

In order to terminate this alarm, unlock vehicle with the remote control or switch on the ignition, if necessary, by emergency detection of the remote control.

Only the driver's door is unlocked or locked via the door lock.

## Locking the doors and tailgate at once

To lock all doors and the tailgate at once:


- With the doors closed, lock the vehicle using the button for the central locking system in the interior.
- Unlock and open the driver's or front passenger door.
- Lock the vehicle.
  - ▶ Lock the driver's door using the integrated key in the door lock, or
  - Press down the lock button of the front passenger door and close the door from the outside.

The fuel filler flap can only be locked using the remote control.

## **Manual operation**

If an electrical malfunction occurs, lock or unlock the vehicle using the integrated key via the door lock on the driver's door.

 Integrated key in opening, arrow, press and remove cover.



Unlock or lock the driver's door using the integrated key in the door lock, or

# Opening and closing: from the inside

## Locking and unlocking



Press the button.

Vehicle is locked.

Press the button.

The vehicle is unlocked.

Pressing the buttons locks and unlocks the doors and the tailgate when the front doors are closed, but they are not secured against theft.

The fuel filler flap remains unlocked.

### **Doors**

### **Automatic Soft Closing**

To close the doors, push lightly. It is closed automatically.

Danger of pinching
Make sure that the closing path of the
doors is clear; otherwise, injuries may result.

✓

## Top tailgate

### **Opening**


The tailgate pivots back and up when it opens. Ensure that adequate clearance is available before opening.

Provide edge protection
Sharp or angular objects can hit the rear window while driving and damage the heating wires of the rear window. Provide edge protection.

## **Opening from the outside**



Press the button next to the tailgate.



The tailgate opens fully.

This button can also be used to unlock the doors. The button assignment on the remote control can be set variously depending on how the vehicle is equipped and according to the country-specific variant.

## Opening from the inside





Press the button.

The tailgate is opened if the vehicle is stationary, provided that the tailgate has not been locked.

## Closing from the inside

Keep the closing path clear
Make sure that the closing path is clear;
otherwise, injuries may result. ◄

Pull and hold the button.
An acoustic signal sounds and the tailqate closes.

Releasing the button stops the motion.

Monitor the closing process

Monitor the closing process to ensure
that no one becomes trapped.

✓

#### **Manual opening**



When there is an electrical defect.

- Fold the rear seat backrest forward.
- In the lower tailgate, loosen and remove the cover using the onboard tool kit or a suitable object.
- Pull the plastic hose in the direction of the interior.

The tailgate is unlocked.

- 4. Open the top tailgate, and press the plastic hose back in.
- Insert and close the cover.

The tailgate is locked again as soon as it is closed.

## Closing



The recessed grip on the inside trim of the tailgate makes pulling down the tailgate easy.

Keep the closing path clear
Make sure that the closing path of the tailgate is clear; otherwise, injuries may result.

✓



Do not place the remote control in the cargo area

Take the remote control with you and do not leave it in the cargo area; otherwise, the remote control is locked inside the vehicle when the tailgate is closed.◀

### Locking the vehicle



Press the button on the inside of the tailgate. When the driver's door is closed, the vehicle is completely locked.

## **Automatic tailgate operation**

## Adjusting the opening height

You can set how far the tailgate should open.

Adjusting the opening height
When adjusting the opening height, ensure that there is a clearance of at least
4 in/10 cm above the tailgate. Otherwise, the ceiling may not be high enough for the open tailgate if the load situation changes.

- 1. "Settings"
- 2. "Tailgate"
- Turn the controller until the desired opening height is selected.

## **Opening**

The tailgate opens fully.

Note the opening height of the tailgate
The tailgate pivots back and up when it
opens. Ensure that there is sufficient clearance
when the tailgate opens; otherwise, damage
may result.

Adjust the opening height of the tailgate according to the given situation. ◀



- Press the button on the exterior of the tailgate.
- Press the button on the remote control for approx. 1 second.

This button can also be used to unlock the doors. The button assignment on the remote control can be set variously depending on how the vehicle is equipped and according to the country-specific variant.

Press the button in the driver's door.

The tailgate is opened if the vehicle is stationary, provided that the tailgate has not been locked.

Pressing the button again stops the motion.

The opening process is interrupted as well:

- When starting the engine.
- When the vehicle starts moving.
- By pressing the button in the driver's door.
- By pressing the button on the inside of the tailgate.

Provide edge protection

Sharp or angular objects can hit the rear window while driving and damage the heating wires of the rear window. Provide edge protection.

#### Closing

The floor panel in the cargo area must be folded down; otherwise, the tailgate cannot be closed.

Without Comfort Access:



Press the button on the inside of the tailgate.

The tailgate closes automatically. Pressing again stops the motion.

#### With Comfort Access:



Press the button, arrow 1, on the inside of the tailgate.

The tailgate closes automatically. Pressing again stops the motion.

▶ Press the button, arrow 2.

Tailgate closes automatically and the vehicle is locked.



Press the button on the exterior of the tailgate.

Pressing again stops the motion.

The closing operation is interrupted:

- When starting the engine.
- ▶ The vehicle starts off with jerks.

Make sure that the closing path of the tailgate is clear; otherwise, injuries may result.

✓



Do not place the remote control in the cargo area

Take the remote control with you and do not leave it in the cargo area; otherwise, the remote control is locked inside the vehicle when the tailgate is closed.◀

## **Manual operation**

In the event of an electrical malfunction, operate the unlocked tailgate manually with a slow and smooth motion.




Do not operate the tailgate manually if it is blocked

If the tailgate is blocked, do not operate it manually as the tailgate may otherwise become damaged and injury may result.

Contact your service center. ◀

## Lower tailgate

### **Opening**



Pull the lever and swing down the tailgate. The open tailgate can be loaded with up to 550 lbs/250 kg.

## Closing

Swing up the tailgate, and press it closed.

## **Comfort Access**

## The concept

The vehicle can be accessed without activating the remote control.

All you need to do is to have the remote control with you, e.g., in your jacket pocket.

The vehicle automatically detects the remote control when it is nearby or in the passenger compartment.

Comfort Access supports the following functions:

- Unlocking/locking of the vehicle.
- Convenient closing.
- Unlocking of the tailgate separately.
- Start the engine.

## **Functional requirements**


- There are no external sources of interference nearby.
- To lock the vehicle, the remote control must be located outside of the vehicle.

- ▶ The next unlocking and locking cycle is not possible until after approx. 2 seconds.
- The engine can only be started if the remote control is inside the vehicle.

## Comparison with ordinary remote control

The functions can be controlled by pressing the buttons of the remote control or Comfort Access.


## **Unlocking**



Fully grasp a door handle, arrow 1.

This corresponds to pressing the  $\mathbf{n}$  button on the remote control.

## Locking



Press the area on the door handle, arrow 2, with your finger for approx. 1 second.

This corresponds to pressing the **3** button on the remote control.

To save battery power, ensure that the ignition and all electronic systems and/or power con-

sumers are switched off before locking the vehicle.

### **Convenient closing**

Press the area on the door handle, arrow 2, with the finger and hold it down.

In addition to locking, the windows and the glass sunroof are closed.

Monitor the closing process

Monitor the closing process to ensure
that no one becomes trapped.

✓

## Unlocking the tailgate separately

Press the button on the exterior of the tailgate.

This corresponds to pressing the button on the remote control.



Do not place the remote control in the cargo area

Take the remote control with you and do not leave it in the cargo area; otherwise, the remote control is locked inside the vehicle when the tailgate is closed.◀

#### Malfunction

Comfort Access may not function properly if it experiences interference from external sources such as mobile phones, metal objects, overhead power lines, transmission towers, etc.

In this case, open or close the vehicle using the buttons on the remote control or use the integrated key in the door lock.

## **Adjusting**

## **Unlocking**

The setting is stored for the remote control currently in use.

- 1. "Settings"
- 2. "Doors/key"

- 3. f Select symbol or "Unlock button:"
- Select the desired function:
  - "Driver's door only"
     Only the driver's door and the fuel filler flap are unlocked. Pressing again unlocks the entire vehicle.
  - "All doors"
     The entire vehicle is unlocked.

Depending on how the vehicle is equipped or the country-specific variant, you can set whether the doors are also unlocked with the button on the remote control.

## Confirmation signals from the vehicle

- 1. "Settings"
- 2. "Doors/key"
- Deactivate or activate the desired confirmation signals.
  - "Acoustic sig. lock/unlock"
  - "Flash when lock/unlock"

## **Automatic locking**

The setting is stored for the remote control currently in use.

- 1. "Settings"
- 2. "Doors/kev"
- Select the desired function:
  - "Lock if no door opened"
    The vehicle locks automatically after a short period of time if a door is not opened.
  - "Lock after start driving"
     The vehicle locks automatically after you drive away.

# Retrieving the seat, mirror, and steering wheel settings

The driver's seat, exterior mirror, and steering wheel positions selected last are stored for the currently used remote control.

When the vehicle is unlocked, these positions are automatically retrieved if this function was activated.

Pinch hazard when moving back the seat If this function is used, first make sure that the footwell behind the driver's seat is empty. Otherwise, people can be injured or objects damaged when the seat is moved back.

The adjustment procedure is interrupted:

- ▶ When a seat position switch is pressed.
- When a button of the seat, mirror, and steering wheel memory is pressed briefly.

#### **Activating the setting**

- 1. "Settings"
- 2. "Doors/key"
- 3. "Last seat position autom."

## **Alarm system**

## The concept

The vehicle alarm system responds to:

- Dening of a door, the hood or the tailgate.
- Movements in the vehicle.
- Changes in the vehicle tilt, e.g., during attempts to steal a wheel or when towing the car.
- Interruptions in battery voltage.

The alarm system briefly indicates tampering:

- By sounding an acoustic alarm.
- By switching on the hazard warning system.
- By flashing the high beams.

# Arming and disarming the alarm system

#### General information

When you lock or unlock the vehicle, either with the remote control or via the Comfort Ac-

cess at the door lock, the alarm system is armed or disarmed at the same time.

### Door lock and armed alarm system

The alarm system is triggered when the door is opened, if the vehicle is unlocked via the door lock.

In order to terminate this alarm, unlock vehicle with the remote control or switch on the ignition, if necessary, by emergency detection of the remote control.

## Tailgate and armed alarm system

The tailgate can be opened even when the alarm system is armed.



Press the button on the remote control for approx. 1 second.

After the tailgate is closed, it is locked and monitored again if the doors are locked. The hazard warning system flashes once.

In some vehicle equipment variants, the tailgate can only be opened using the remote control if the vehicle was unlocked first.

#### Panic mode

You can trigger the alarm system if you find yourself in a dangerous situation.




Press the button on the remote control for at least 3 seconds.

To switch off the alarm: press any button.

## Switching off the alarm

- Unlock the vehicle using the remote control.
- With Comfort Access: If you are carrying the remote control with you, pull on the driver side or front passenger side door handle.

### Indicator lamp on the interior rearview mirror



The indicator lamp flashes briefly every 2 seconds:

The system is armed.

The indicator lamp flashes after locking: The doors, hood or tailgate is not closed properly, but the rest of the vehicle is secured.

After 10 seconds, the indicator lamp flashes continuously. Interior motion sensor and tilt alarm sensor are not active.

▶ The indicator lamp goes out after unlocking:

The vehicle has not been tampered with.

The indicator lamp flashes after unlocking until the engine ignition is switched on, but no longer than approx. 5 minutes:

An alarm has been triggered.

#### Tilt alarm sensor

The tilt of the vehicle is monitored.

The alarm system responds in situations such as attempts to steal a wheel or when the car is towed.

#### Interior motion sensor

The windows and glass sunroof must be closed for the system to function properly.

#### **Avoiding unintentional alarms**

The tilt alarm sensor and interior motion sensor can be switched off together, such as in the following situations:

- In automatic car washes.
- In duplex garages.
- During transport on car-carrying trains, at sea or on a trailer.
- When animals are to remain in the vehicle.

#### Switching off the tilt alarm sensor and interior motion sensor



Press the remote control button again within 10 seconds as soon as the vehicle is locked.

The indicator lamp lights up for approx. 2 seconds and then continues to flash.

The tilt alarm sensor and interior motion sensor are switched off until the vehicle is locked again.

## **Power windows**

#### General information

Take the remote control with you Take the remote control with you when leaving the vehicle so that children, for example, cannot operate the power windows and injure themselves. ◀



### **Opening**

Press the switch to the resistance point.

The window opens while the switch is held.

Press the switch beyond the resistance point.

The window opens automatically.

Pressing the switch again stops the motion. Convenient opening, refer to page 36, via the remote control.

### Closing

Keep the closing path clear

Monitor the closing process and make sure that the closing path of the window is clear; otherwise, injuries may result.

✓

Pull the switch to the resistance point.

The window closes while the switch is held.

Pull the switch beyond the resistance point.

The window closes automatically.

Pressing the switch stops the motion.

Convenient closing, refer to page 43, with Comfort Access.

## Pinch protection system

If the closing force exceeds a specific value as a window closes, the closing action is interrupted.

The window reopens slightly.



Danger of pinching even with pinch protection

Even with the pinch protection system, check that the window's closing path is clear; other-

wise, the closing action may not stop in certain situations, e.g., if thin objects are present. ◄

No window accessories

Do not install any accessories in the range of movement of the windows; otherwise, the pinch protection system will be impaired.

# Closing without the pinch protection system

Keep the closing path clear
Monitor the closing process and make
sure that the closing path of the window is
clear; otherwise, injuries may result.

✓

For example, if there is an external danger or if ice on the windows prevents a window from closing normally, proceed as follows:

- Pull the switch past the resistance point and hold it there.
  - The pinch protection is limited and the window reopens slightly if the closing force exceeds a certain value.
- Pull the switch past the resistance point again within approx. 4 seconds and hold it there.

The window closes without pinch protection.

## Safety switch

The safety switch in the driver's door can be used to prevent children, for example, from opening and closing the rear windows using the switches in the rear.

## Switching on and off



Press the button.

The LED lights up if the safety function is switched on.

Safety switch for rear operation
Press the safety switch when transporting children in the rear; otherwise, injury may result if the windows are closed without supervision.

## **Roller sunblinds**

## Roller sunblinds for the rear side windows

Pull out the roller sunblind at the loop and hook it onto the bracket.



Do not open the window while the roller supplied is raised.

Do not open the window while the roller sunblind is raised; otherwise, there is a risk of damage at high speeds that may result in personal injury.◀

## **Panoramic-glass sunroof**

#### **General information**

The glass sunroof and the sliding visor can be operated together or separately, using the same switch.

The glass sunroof is operational when the ignition is switched on.

Monitor the closing path clear
Monitor the closing process and make
sure that the closing path of the glass sunroof
is clear; otherwise, injuries may result.

✓

Take the remote control with you Take the remote control with you when leaving the vehicle so that children, for example, cannot operate the roof and injure themselves.◀



## Tilting the glass sunroof



Push switch upward briefly.

- The closed roof is tilted and the sliding visor opens slightly.
- The opened roof closes until it is in its tilted position. The sliding visor stays completely open.

### **Opening/closing the sliding visor**



- Press the switch in the desired direction to the resistance point and hold it there.
  - The sliding visor moves while the switch is being held.
- Press the switch in the desired direction past the resistance point.

The sliding visor moves automatically. Pressing the switch again stops the motion.

## Opening/closing the glass sunroof

When the sliding visor is open, proceed as described under Sliding visor.

# Opening/closing the glass sunroof and sliding visor together



Briefly press the switch twice in succession in the desired direction past the resistance point.

The glass sunroof and sliding visor move together. Pressing the

switch again stops the motion.

Convenient operation, refer to page 36, via the remote control.

Convenient closing, refer to page 43, with Comfort Access.

### **Comfort position**

Stops the roof in the comfort position if the roof is not fully open. This reduces wind noise in the passenger compartment.

If desired, continue the movement by pressing the switch.

### **Pinch protection system**

If the closing force when closing the glass sunroof exceeds a certain value, the closing movement is stopped, beginning at approximately the middle of the opening in the roof, or from the tilted position during closing.

The glass sunroof opens again slightly.



Danger of pinching even with pinch protection

Despite the pinch protection system, check that the roof's closing path is clear; otherwise, the closing action may not be interrupted in certain extreme situations, such as when thin objects are present.◀

# Closing from the open position without pinch protection

For example, if there is an external danger, proceed as follows:

Press the switch forward beyond the resistance point and hold.

- Pinch protection is limited and the roof reopens slightly if the closing force exceeds a certain value.
- Press the switch forward again beyond the resistance point and hold until the roof closes without pinch protection.

# Closing from the raised position without pinch protection

If there is an external danger, push the switch forward past the resistance point and hold it.

The roof closes without pinch protection.

## Initializing after a power failure

After a power failure during the opening or closing process, the roof can only be operated to a limited extent.

### Initializing the system

The system can be initialized when the vehicle is stationary and the engine is running.

During the initialization, the roof closes without pinch protection.

Keep the closing path clear

Monitor the closing process and make sure that the closing path of the glass sunroof is clear; otherwise, injuries may result.

✓



Press the switch up and hold it until the initialization is complete:

- Initialization begins within 15 seconds and is completed when the sunroof and sliding visor are completely closed.
- ▶ The roof closes without pinch protection.

## **Adjusting**

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

## Sitting safely

The ideal seating position can make a vital contribution to relaxed, fatigue-free driving.

The seating position plays an important role in an accident in combination with:

- Safety belts, refer to page 54.
- Head restraints, refer to page 56.
- Airbags, refer to page 100.

## **Front seats**

#### **General information**

Do not adjust the seat while driving
Do not adjust the driver's seat while driving, or the seat could respond with unexpected
movement and the ensuing loss of vehicle
control could lead to an accident.

✓



Do not incline the backrest too far to the rear

Also on the front passenger side, do not incline the backrest on the front passenger side too far to the rear during driving, or there is a risk of slipping under the safety belt in the event of an accident. This would eliminate the protection normally provided by the belt.

### Semi-electrically adjustable seats

#### At a glance



- 1 Forward/backward
- 2 Height, tilt
- 3 Backrest
- 4 Lumbar support

#### Tilt



Move the control in the desired direction until the desired tilt is set. After releasing the control, apply your weight to the seat or lift it off to make sure the seat engages properly.

#### Forward/backward



Pull the lever and slide the seat in the desired direction

After releasing the control, move the seat forward or back slightly to make sure it engages properly.

## Height



Move the button in the required direction.


#### **Backrest**



Move the button in the required direction.

### **Electrically adjustable seats**

## At a glance



- 1 Seat, mirror, and steering wheel memory
- 2 Shoulder support
- 3 Backrest width
- 4 Lumbar support
- 5 Backrest
- 6 Forward/back, height, tilt
- 7 Thigh support

#### Note


The seat setting for the driver's seat is stored for the remote control currently in use. When the vehicle is unlocked via the remote control, the position is automatically retrieved if the Function, refer to page 43, for this is activated.

## Adjustments in detail

1. Forward/backward



#### 2. Height



#### 3. Seat tilt




#### 4. Backrest tilt




## **Thigh support**

#### **Multifunctional seat**



Adjust the position using the lever.

#### **Sport seat**



Pull the lever at the front of the seat and adjust the thigh support.

## **Lumbar support**

The curvature of the seat backrest can be adjusted in such a way that it supports the lumbar region of the spine. The lower back and the spine are supported for upright posture.



- Press the front/rear section of the switch.
  - The curvature is increased/ decreased.
- Press the upper/lower section of the switch.

The curvature is shifted up/down.

#### **Backrest width**



Change the width of the backrest using the side wings to adjust the lateral support.

### **Shoulder support**



Also supports the back in the shoulder area:

- Results in a relaxed seating position.
- Reduces strain on the shoulder muscles.

## Front seat heating



## Switching on



Press the button once for each temperature level.

The maximum temperature is reached when three LEDs are lit.

If the drive is continued within approx. 15 minutes, the seat heating is activated automatically with the temperature selected last.

### **Switching off**



Press the button longer.

The LEDs go out.

## **Temperature distribution**

The heating action in the seat cushion and backrest can be distributed in different ways.

- 1. "Climate"
- 2. "Front seat heating"
- 3. Select the required seat.
- Turn the controller to set the temperature distribution.

## Active seat ventilation, front

The seat cushion and backrest surfaces are cooled by means of integrated fans.

The ventilation cools the seat, e. g., if the vehicle interior is overheated or for continuous cooling at high temperatures.



## **Switching on**



Press the button once for each ventilation level.

The highest level is active when three LEDs are lit.

After a short time, the system automatically moves down one level in order to prevent excessive cooling.

## **Switching off**



Press the button longer.

The LEDs go out.

### Rear seats

#### Second row of seats

#### **Hints**

Center armrest

When folding down the center armrest, ensure that the area below the center head restraint is clear. Otherwise, injury may result. ◄

Do not adjust the seat while driving
Do not adjust the seat while the vehicle is
moving, otherwise, the restraining effect of the
seat can be limited in an accident.

✓

#### Forward/backward



- Pull the lever, arrow 1, and slide the seat in the desired direction.
- Release lever and move seat slightly forward or back to get it to latch in place.

#### **Backrest tilt**

The backrest tilt can be adjusted to six settings.



Pull the lever, and apply your weight to the backrest or lift it off, as necessary.

#### Access to the third row of seats



Keep the floor area under the second row of seats clear

When you fold back the second row of seats, make sure that the floor area under the second row of seats is clear. Otherwise, persons who are located in the third row of seats could be injured or objects could be damaged.◀

 Make sure that the middle section is folded up.

When the middle section is folded down, comfortable entry is not possible.



Pull the lever and fold the seat forward.The recessed grip on the inside trim of the door pillar makes getting into the vehicle eas-

If the second row of seats is not locked, a warning symbol is displayed in the instrument cluster.

ier.

### **Rear seat heating**



#### **Switching on**



Press the button once for each temperature level.

The maximum temperature is reached when three LEDs are lit.

If the drive is continued within approx. 15 minutes, the seat heating is activated automatically with the temperature selected last.

### Switching off



Press the button longer.

The LEDs go out.

#### Third row of seats

#### **General information**

The third row of seats is divided and offers space for two people.

## Folding up the backrest



Ensure that the lock is securely engaged

Make sure that the lock engages correctly. If it is not properly engaged, transported cargo could enter the passenger compartment even during braking or evasive maneuvers and endanger the vehicle occupants.

Before folding up the backrest, remove the cargo cover, refer to page 176. If necessary, slide the second row of seats forward a little.

 Pull the lever, arrow, to unlock the backrest.



- Fold up and latch the backrest.
- 3. Slide headrests into the highest position.

### Folding the backrest down

- 1. Moving the headrest down.
- Pull the lever, arrows, to unlock the backrest



Fold the backrest down.

## Safety belts

## Seats with safety belt

The vehicle has five seats, each of which is equipped with a safety belt.

The vehicle has five or seven seating positions, each of which is equipped with a safety belt.

#### **Hints**

Always make sure that safety belts are being worn by all occupants before driving away.

Although airbags enhance safety by providing added protection, they are not a substitute for safety belts.

- The shoulder strap's anchorage point will be correct for adult seat occupants of every build if the seat is correctly adjusted.
- The two outer safety belt buckles, integrated into the 2nd row of seats, are for passengers sitting on the left and right.
- The center belt buckle of the 2nd row of seats is solely intended for the center passenger.
- The safety belt buckles, integrated into the 3rd row of seats, are for passengers sitting on the left and right.

One person per safety belt


Never allow more than one person to
wear a single safety belt. Never allow infants or
small children to ride on a passenger's lap.

Putting on the belt
Lay the belt, without twisting, snugly
across the lap and shoulders, as close to the
body as possible. Make sure that the belt lies
low around the hips in the lap area and does
not press on the abdomen. Otherwise, the belt
can slip over the hips in the lap area in a frontal
impact and injure the abdomen.

The safety belt must not lie across the neck, rub on sharp edges, be routed over solid or breakable objects, or be pinched.◀

Avoid wearing clothing that prevents the belt from fitting properly, and pull the shoulder belt periodically to readjust the tension across your lap; otherwise, the retention effect of the safety belt may be reduced.

### **Buckling the belt**



Make sure you hear the latch plate engage in the belt buckle.

## **Unbuckling the belt**

- 1. Hold the belt firmly.
- 2. Press the red button in the belt buckle.
- Guide the belt back into its reel.

# Safety belt reminder for driver's and passenger's seat



The indicator lamp flashes or lights up and a signal sounds. Make sure that the safety belts are positioned cor-

rectly. The safety belt reminder is active at speeds above approx. 5 mph/8 km/h. It can also be activated if objects are placed on the front passenger seat.

## Damage to safety belts

In the case of strain caused by accidents or damage:

Have the safety belts, including the safety belt tensioners, replaced and have the belt anchors checked.

Checking and replacing safety belts
Have the work performed only by your
service center; otherwise, it cannot be ensured
that this safety feature will function properly.

## Front head restraints

### **Correctly adjusted head restraint**

A correctly adjusted head restraint reduces the risk of injury to cervical vertebrae in the event of an accident.

Adjusting the head restraint

Correctly adjust the head restraints of all occupied seats; otherwise, there is an increased risk of injury in an accident.

### Height

Adjust the head restraint so that its center is approximately at ear level.

#### **Distance**

Adjust the distance so that the head restraint is as close as possible to the back of the head.

#### **Active head restraint**

In the event of a rear-end collision with a certain severity, the active head restraint automatically reduces the distance from the head.



Reduced protective function


- Do not use seat or head restraint covers.
- Do not hang objects, e.g., clothes hangers, on the head restraints.
- Only attach accessories approved by BMW to the seat or head restraint.

Otherwise, the protective function of the active head restraint will be impaired and the personal safety of the occupants will be endangered.◀

In the case of strain caused by accidents or damage:


Have the active headrest checked and if necessary replaced.

## Adjusting the height: manual head restraints



- ▶ To raise: pull.
- ▶ To lower: press the button, arrow 1, and push the head restraint down.

# Adjusting the height: electrical head restraints



Adjusting electrically.

# Distance to back of head: manual head restraints



- Forward: by pulling
- Back: press the button and push the head restraint toward the rear.

## Distance to back of head: electrical head restraints

The head restraint is automatically repositioned when the shoulder support is adjusted.

### Adjusting the side extensions



Fold forward for increased lateral support in the resting position.

### Removing

The head restraints cannot be removed.

## Rear head restraints

## **Correctly adjusted head restraint**

A correctly adjusted head restraint reduces the risk of injury to cervical vertebrae in the event of an accident.

Adjusting the head restraint


Correctly adjust the head restraints of all occupied seats; otherwise, there is an increased risk of injury in an accident.

✓

## Height

Adjust the head restraint so that its center is approximately at ear level.

### Adjusting the height




- To raise: pull.
- ➤ To lower: press the button, arrow 1, and push the head restraint down.

The center head restraint cannot be adjusted in elevation.

## Removing

Only remove the head restraint if no one will be sitting in the seat in question.



- Pull the head restraint upward as far as possible.
- 2. Press the button, arrow 1, and pull the head restraint out completely.

Before transporting passengers
Reinstall the head restraint before transporting anyone in the seat; otherwise, the protective function of the head restraint is unavailable.

# Seat, mirror, and steering wheel memory

#### **General information**



Two different driver's seat, exterior mirror, and steering wheel positions can be stored and retrieved for each remote control. The adjustment of the lumbar support is not stored.

### **Storing**

- 1. Switch on the ignition.
- 2. Set the desired position.
- 3. Press the button. The LED in the button lights up.
- 4. Press the desired button 1 or 2. The LED goes out.

If the M button is pressed accidentally:

М

Press the button again.

The LED goes out.

## **Calling up settings**

Do not retrieve the memory while driving Do not retrieve the memory setting while driving, as an unexpected movement of the seat or steering wheel could result in an accident.

#### **Comfort function**

- 1. Open the driver's door.
- 2. Switch off the ignition.
- 3. Briefly press the desired button 1 or 2.

The corresponding seat position is performed automatically.

The procedure stops when a switch for adjusting the seat or one of the buttons is pressed.

### Safety mode

- Close the driver's door or switch on the ignition.
- Press and hold the desired button 1 or 2 until the adjustment procedure is completed.

## Calling up of a seat position deactivated

After a brief period, the calling up of stored seat positions is deactivated to save battery power.

To reactivate calling up of a seat position:

- Open or close the door or tailgate.
- Press a button on the remote control.
- Press the Start/Stop button.

## **Mirrors**

#### **Exterior mirrors**

## At a glance



- 1 Adjusting
- 2 Left/right, Automatic Curb Monitor
- 3 Fold in and out

#### **General information**

The mirror on the passenger side is more curved than the driver's side mirror.

Estimating distances correctly
Objects reflected in the mirror are closer
than they appear. Do not estimate the distance
to the traffic behind you based on what you
see in the mirror, as this will increase your risk
of an accident.◄

Depending on how the vehicle is equipped, the mirror setting is stored for the remote control in use. When the vehicle is unlocked via the remote control, the position is automatically retrieved if the setting for this function is active.

### Selecting a mirror



To change over to the other mirror: Slide the mirror changeover switch.

## Adjusting electrically



The setting corresponds to the direction in which the button is pressed.

## Saving positions

Seat, mirror, and steering wheel memory, refer to page 58.

## **Adjusting manually**

If an electrical malfunction occurs, for example, press the edges of the mirror glass.

#### **Automatic Curb Monitor**

When the reverse gear is engaged, the mirror glass tilts downward slightly on the front passenger side. This improves your view of the curb and other low-lying obstacles when parking, for example.

#### **Activating**

1. Slide the mirror changeover switch to the driver's side mirror position.

2. Engage transmission position R.

#### Deactivating

Slide the mirror changeover switch to the passenger's side mirror position.

#### Fold in and out



Press the button.

Possible up to approx. 15 mph/20 km/h.

For example, this is advantageous

- In car washes.
- In narrow streets.
- For folding back mirrors that were folded away manually.

Mirrors that were folded in are folded out automatically at a speed of approx. 25 mph/40 km/h.

Fold in the mirror in a car wash
Before washing the car in an automatic
car wash, fold in the exterior mirrors by hand or
with the button; otherwise, the mirrors could
be damaged, depending on the width of the
vehicle.

## **Automatic heating**


Both exterior mirrors are automatically heated whenever the engine is running.

## **Automatic dimming feature**

Both exterior mirrors are automatically dimmed. Photocells are used for control in the Interior rear view mirror, refer to page 60.

# Interior rearview mirror, automatic dimming feature

### The concept



Photocells are used for control:

- In the mirror glass.
- On the back of the mirror.

### **Functional requirement**

For proper operation:

- Keep the photocells clean.
- Do not cover the area between the inside rearview mirror and the windshield.


## Steering wheel

#### **General information**

Do not adjust while driving
Do not adjust the steering wheel while
driving; otherwise, an unexpected movement
could result in an accident.


✓

## Manual steering wheel adjustment



- 1. Fold the lever down.
- Move the steering wheel to the preferred height and angle to suit your seating position.
- 3. Fold the lever back.

## Power steering wheel adjustment



The steering wheel can be adjusted in four directions.

## Storing the position

Seat, mirror and steering wheel memory, refer to page 58.

## Steering wheel heating



## Switching on/off



Press the button.

- On: the LED lights up.
- Off: the LED goes out.

## **Transporting children safely**

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

## The right place for children

#### **Note**

Children in the vehicle
Do not leave children unattended in the vehicle; otherwise, they could endanger themselves and other persons, e.g., by opening the doors.

## Children should always be in the rear

Accident research shows that the safest place for children is in the back seat.

Transporting children in the rear
Only transport children younger than
13 years of age or shorter than 5 ft/150 cm in
the rear in child restraint fixing systems provided in accordance with the age, weight and
size of the child; otherwise, there is an increased risk of injury in an accident.

Children 13 years of age or older must wear a safety belt as soon as a suitable child restraint fixing system can no longer be used, due to their age, weight and size.◀

## Children on the front passenger seat

Should it ever be necessary to use a child restraint fixing system in the front passenger seat, make sure that the front, knee and side airbags on the front passenger side are deactivated. Automatic deactivation of front passenger side airbags, refer to page 102.

#### Note

Deactivated front passenger airbags
If a child restraint fixing system is used in
the front passenger seat, the front passenger
airbags must be deactivated; otherwise, there
is an increased risk of injury to the child when
the airbags are triggered, even with a child restraint fixing system.

# Installing child restraint fixing systems

### **Before mounting**

Before mounting child restraint fixing systems, ensure that the rear seat backrests are locked.

#### Third row of seats

Before installing a child restraint system on the third row of seats, note the following:

- Roll up the cargo cover, partition net and remove the case
- Bring seats and backrests of the second row of seats into the forwardmost position
- Raise the headrests of the third row of seats into the highest position.

Do not change the settings that have been made after this.

#### **Hints**



Manufacturer's information for child restraint fixing systems

To select, mount and use child restraint fixing systems, observe the information provided by the system manufacturer; otherwise, the protective effect can be impaired. ◄

Lock the rear seat backrests in position
Before installing a child restraint system,
make sure that the rear seat backrests are
locked; otherwise, the protective effect is not
guaranteed and there is an increased risk of injury for the child in the event of an accident.

Lock seats of the second row of seats When equipped with a third row of seats: when a child restraint system is installed on the second row of seats, make sure that this seat is correctly locked; otherwise, there is an increased risk of injury for the child in the event of an accident.



Only approved child restraint systems on the third row of seats

On the third row of seats install only approved child restraint systems; otherwise the protective effect is not guaranteed and there is an increased risk of injury for the child in the event of an accident.

## On the front passenger seat

## **Deactivating airbags**

After installing a child restraint fixing system in the front passenger seat, make sure that the front, knee and side airbags on the front passenger side are deactivated.

Deactivate the front passenger airbags automatically, refer to page 102.

Deactivating the front passenger airbags If a child restraint fixing system is used in the front passenger seat, the front passenger airbags must be deactivated; otherwise, there is an increased risk of injury to the child when the airbags are triggered, even with a child restraint fixing system.

## Seat position and height

Before installing a child restraint fixing system, move the front passenger seat as far back as possible and adjust its height to the highest position to obtain the best possible position for the belt and to offer optimal protection in the event of an accident.

Do not change the seat position and height after this.

#### **Backrest width**

Adjustable backrest width: before installing a child restraint fixing system in the front passenger seat, open the backrest width completely. Do not change the backrest width again and do not call up a memory position.

Backrest width for the child seat
Before installing a child restraint fixing
system in the front passenger seat, the backrest width must be opened completely. Do not
change the adjustment after this; otherwise,
the stability of the child seat will be reduced.

## **Child seat security**



The rear safety belts and the front passenger safety belt can be locked against pulling out for mounting the child restraint fixing systems.

## Locking the safety belt

- 1. Pull out the belt webbing completely.
- 2. Secure the child restraint fixing system with the belt.
- Allow the belt webbing to be pulled in and pull it taut against the child restraint fixing system. The safety belt is locked.

## Unlocking the safety belt

- 1. Unbuckle the belt buckle.
- 2. Remove the child restraint fixing system.
- Allow the belt webbing to be pulled in completely.

# LATCH child restraint fixing system

LATCH: Lower Anchors and Tether for CHildren.

#### Note



Manufacturer's information for LATCH child restraint fixing systems

To mount and use the LATCH child restraint fixing systems, observe the operating and safety information from the system manufacturer; otherwise, the level of protection may be reduced. ◄

### Mounts for the lower LATCH anchors

The lower anchors may be used to attach the CRS to the vehicle seat up to a combined child and CRS weight of 65 lb/30 kg when the child is restr- ained by the internal harnesses.



Correctly engage the lower LATCH anchors

Make sure that the lower LATCH anchors have properly engaged and that the child restraint fixing system is resting snugly against the backrest; otherwise, the degree of protection offered may be reduced. ◀

Before mounting the LATCH child restraint fixing system, pull the belt away from the child restraint fixing system.

#### **Position**




Mounts for the lower LATCH anchors are located in the gap between the seat and backrest.

# Mounting ISOFIX child restraint fixing systems

- Mount the child restraint fixing system; refer to the user's manual of the system.
- Ensure that both LATCH anchors are properly connected.

# Child restraint fixing system with a tether strap

## **Mounting points**



There are three mounting points for the upper retaining strap of LATCH child restraint fixing systems.

#### Note


Mounting eyes

Only use the mounting eyes for the upper retaining strap to secure child restraint fixing systems; otherwise, the mounting eyes could be damaged.

### Retaining strap guide

Retaining strap

Make sure that the upper retaining strap is not routed over the head restraints or sharp edges and is free of twisting on its way to the upper mounting point; otherwise, the belt cannot properly secure the child restraint fixing system in an accident.◄



- 1 Direction of travel
- 2 Head restraint.
- 3 Hook for upper retaining strap
- 4 Mounting point/eye
- 5 Seat backrest
- 6 Upper retaining strap

# Attaching the upper retaining strap to the mounting point

- 1. Raise the head restraint if necessary.
- 2. Guide the upper retaining strap between the supports of the head restraint.
- 3. If there is a retaining strap, run it between the backrest and the cargo cover.
- 4. Attach the hooks of the retaining strap to the mounting eyes.

- 5. Tighten the retaining strap by pulling it down.
- 6. Lower and lock head restraints as needed.

# Locking the doors and windows

#### Rear doors



Push the locking lever on the rear doors down. The door can now be opened from the outside only.

## Safety switch for the rear



Press the button on the driver's door if children are being transported in the

rear.

This locks various functions so that they cannot be operated from the rear: safety switch, refer to page 46.

## **Driving**

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

## **Start/Stop button**

### The concept



Pressing the Start/Stop button switches the ignition on or off and starts the engine.

The engine starts if the brake pedal is pressed when you press

the Start/Stop button.

## **Ignition** on

Press the Start/Stop button and do not press on the brake pedal at the same time.

All vehicle systems are ready for operation.

Most of the indicator and warning lamps in the instrument cluster light up for varying lengths of time.

To save battery power when the engine is off, switch off the ignition and any unnecessary electronic systems/power consumers.

The ignition switches off automatically:

- When locking the vehicle, even if the low beams are switched on.
- Shortly before the battery is discharged completely, so that the engine can still be started.

#### Note

If the engine is switched off and the ignition is switched on, the system automatically switches to the radio ready state when the door is opened if the lights are switched off or the daytime running lights are switched on.

### **Ignition off**

Press the Start/Stop button again and do not press on the brake pedal at the same time.

All indicator lamps in the instrument cluster go out.

To save battery power when the engine is off, switch off the ignition and any unnecessary electronic systems/power consumers.



Transmission position P with the ignition off

When the ignition is switched off, position P is engaged automatically. When in an automatic car wash, for example, ensure that the ignition is not switched off accidentally.◀

The ignition automatically cuts off while the vehicle is stationary and the engine is stopped:

- When locking the vehicle, and when the low beams are activated.
- Shortly before the battery is discharged completely, so that the engine can still be started. This function is only available when the low beams are switched off.
- When opening or closing the driver door, if the driver's seat belt is unbuckled and the low beams are switched off.
- While the driver's seat belt is unbuckled, if the driver's door is open and the low beams are switched off.

When the ignition is switched off, by opening or closing the driver's door or unbuckling the driver's seat belt, the radio ready state remains active.

#### Radio ready state

Activate radio ready state:

When the engine is running: press the Start/Stop button.

Some electronic systems/power consumers remain ready for operation.

The radio ready state switches off automatically:

- After approx. 8 minutes.
- When the vehicle is locked using the central locking system.
- Shortly before the battery is discharged completely, so that the engine can still be started.

## Starting the engine

#### **Hints**

Enclosed areas

Do not let the engine run in enclosed areas; otherwise, breathing of exhaust fumes may lead to loss of consciousness and death. The exhaust gases contain carbon monoxide, an odorless and colorless but highly toxic gas.◀

Unattended vehicle

Do not leave the vehicle unattended with the engine running; doing so poses a risk of danger.

Before leaving the vehicle with the engine running, set the parking brake and place the transmission in position P or neutral to prevent the vehicle from moving.

Repeated starting in quick succession
Avoid repeated unsuccessful attempts to
start the vehicle or starting the vehicle several
times in quick succession. Otherwise, the fuel
is not burned or is inadequately burned, posing
a risk of overheating and damage to the catalytic converter.

Do not wait for the engine to warm-up while the vehicle remains stationary. Start driving at moderate engine speeds.

#### Automatic transmission

#### Starting the engine

- Depress the brake pedal.
- 2. Press the Start/Stop button.

The ignition is activated automatically for a certain time and is stopped as soon as the engine starts.

## **Engine stop**

#### Hints

Take the remote control with you when leaving the vehicle so that children, for example, cannot start the engine. ◄



Set the parking brake and further secure the vehicle as required

Set the parking brake firmly when parking; otherwise, the vehicle could roll. On steep upward and downward inclines, further secure the vehicle, for example, by turning the steering wheel in the direction of the curb.

## Before driving into a car wash

In order for the vehicle to be able to roll into a car wash, heed the information regarding Washing in automatic car washes, refer to page 235.

#### **Automatic transmission**

## Switching off the engine

- Engage transmission position P with the vehicle stopped.
- Press the Start/Stop button. The engine is switched off.

The radio ready state is switched on.

3. Set the parking brake.

# **Automatic Engine Start/Stop Function**

#### The concept

The Auto Start/Stop function helps save fuel. The system switches off the engine during a stop, e.g., in a traffic congestion or at traffic lights. The ignition remains switched on. The engine starts again automatically for driving off.

Certain vehicle components may experience additional wear as a result of this system.

#### **Automatic mode**

The Auto Start/Stop function is operational after each engine start.

This function is activated at speeds faster than about 3 mph, approx. 5 km/h.

## **Engine stop**

The engine is switched off automatically during a stop under the following conditions:

Automatic transmission:

- The selector lever is in transmission position D.
- The brake pedal remains pressed while the vehicle is stationary or the vehicle is held by Automatic Hold.
- The driver's seat belt is buckled or the driver's door is closed.

The air volume of the air conditioner is reduced when the engine is switched off.

## Displays in the instrument cluster



The display indicates that the automatic engine start-stop function is ready for an automatic engine start.



The display indicates that the conditions for an automatic engine stop have not been satisfied.

#### Note

The engine is not switched off automatically in the following situations:

- External temperature too low.
- ➤ The external temperature is high and automatic climate control is running.
- The passenger compartment has not yet been heated or cooled to the required level.
- The engine is not yet at operating temperature.
- ➤ The wheels are at a sharp angle or the steering wheel is being turned.
- After driving in reverse.
- Fogging of the windows when the automatic climate control is switched on.
- Vehicle battery is heavily discharged.
- ▶ The engine compartment lid is unlocked.
- HDC Hill Descent Control is activated.
- ▶ The parking assistant is activated.
- Stop-and-go traffic.
- ▶ The transmission selector lever is in position N or M/S.
- Use of fuel with high ethanol content.

## Starting the engine

The engine starts automatically under the following conditions:

Automatic transmission:
 By releasing the brake pedal.
 When Automatic Hold is activated: press the accelerator.

After the engine starts, accelerate as usual.

#### Safety mode

After the engine switches off automatically, it will not start again automatically if any one of the following conditions are met.

- ➤ The driver's safety belt is unbuckled and the driver's door is open.
- The hood was unlocked.

Some indicator lamps light up for varying lengths of time.

The engine can only be started via the Start/Stop button.

#### Note

Even if driving away was not intended, the deactivated engine starts up automatically in the following situations:

- Excessive warming of the passenger compartment when the cooling function is switched on.
- The steering wheel is turned.
- Automatic transmission: the transmission position is changed from D to N, R, or M/S.
- Automatic transmission: the transmission position is changed from P to N, D, R or M/S.
- Fogging of the windows when the automatic climate control is switched on.
- Vehicle battery is heavily discharged.
- Excessive cooling of the passenger compartment when the heating is switched on.

## Preventing an automatic engine stop with automatic transmission

## The concept

To make it possible to drive away very quickly, such as at an intersection, the automatic engine stop can be actively prevented.

# Preventing an engine stop using the brake pedal

The engine stop can be actively prevented within one second after the vehicle comes to a standstill.

- Immediately after the vehicle comes to a standstill, briefly press the brake pedal forcefully.
- ▶ Then press the brake pedal with normal braking force.

# Activating/deactivating the system manually

### **Using the button**





Press the button.

- LED comes on: Auto Start Stop function is deactivated.
  - The engine is started during an automatic engine stop.
  - The engine can only be stopped or started via the Start/Stop button.
- LED goes out: Auto Start Stop function is activated.

# Switching off the vehicle during an automatic engine stop

During an automatic engine stop, the vehicle can be switched off permanently, e.g., when leaving it.

 Press the Start/Stop button. The ignition is switched off. The Auto Start/Stop function is deactivated. Transmission position P is engaged automatically.

2. Set the parking brake.

Engine start as usual via Start/Stop button.

#### **Automatic deactivation**

In certain situations, the Auto Start/Stop function is deactivated automatically for safety reasons, such as when the driver is detected to be absent.

#### Malfunction

The Auto Start/Stop function no longer switches of the engine automatically. A Check Control message is displayed. It is possible to continue driving. Have the system checked.

## **Parking brake**

### The concept

The parking brake is used to prevent the vehicle from rolling when it is parked.



## **Setting**



Pull the switch.

The LED lights up.



The indicator lamp lights up red. The parking brake is set.



Lower lamp: indicator lamp in Canadian models



Set the parking brake and further secure the vehicle as required

Set the parking brake firmly when parking; otherwise, the vehicle could roll. On steep upward and downward inclines, further secure the vehicle, for example, by turning the steering wheel in the direction of the curb. ◀

### While driving

Use while driving serves as an emergency braking function:

Pull the switch and hold it. The vehicle brakes hard while the switch is being pulled.



The indicator lamp lights up red, a signal sounds and the brake lamps light up.




Lower lamp: indicator lamp in Canadian models.

If the vehicle is braked to a speed of approx. 2 mph/3 km/h, the parking brake remains set.

## Releasing

With the ignition switched on:



transmission position P is engaged. The LED and indicator lamp go out.

The EED and maleater lamp go o

The parking brake is released.

## Automatic Release in cars with automatic transmission

For automatic release, operate the accelerator pedal.

The LED and indicator lamp go out.

Subject to the following requirements, the parking brake is automatically released by operation of the accelerator pedal:

- ▶ Engine on.
- Drive position engaged.
- Driver buckled in and doors closed.



Inadvertent operation of the accelerator pedal

Make sure that the accelerator pedal is not operated unintentionally; otherwise, the vehicle is set in motion and there is a risk of an accident. ◀

#### **Automatic Hold**

### The concept

This system assists the driver by automatically setting and releasing the brake, such as when moving in stop-and-go traffic.

The vehicle is automatically held in place when it is stationary.

On inclines, the system prevents the vehicle from rolling backward when driving away.



## For your safety

Under the following conditions, Automatic Hold is automatically deactivated and the parking brake is set:

- The engine is switched off.
- A door is opened and driver's safety belt is unbuckled while the vehicle is stationary.
- The moving vehicle is brought to a standstill using the parking brake.



The indicator lamp switches from green to red and the letters AUTO H go out.



Lower lamp: indicator lamp in Canadian models.



Leaving the vehicle with the engine running

Before leaving the vehicle with the engine running, engage position P of the automatic transmission and ensure that the parking brake is set. Otherwise, the vehicle may begin to roll. ◄

### **Activating**

This function can be activated when the driver's door is closed and the safety belt is fastened, and while driving.



up.

Press the button.

The LED and the letters AUTO H light



The indicator lamp lights up.

Automatic Hold is activated.

## **Deactivating**



Press the button again.

The LED and the letters AUTO H go

out.

Automatic Hold is deactivated.

If the vehicle is being held by Automatic Hold, press on the brake pedal to deactivate it.

When the parking brake is set manually, Automatic Hold is deactivated automatically.

## **Driving**

Automatic Hold is activated: the vehicle is automatically secured against rolling after braking to a standstill.



The indicator lamp lights up green.

Step on the accelerator pedal to drive off.



The brake is released automatically.

The indicator lamp goes out.

Lower lamp: indicator lamp in Canadian models

Before driving into a car wash
Before driving into the car wash, deactivate Automatic Hold; otherwise, the parking brake will be set when the vehicle is stationary and the vehicle will no longer be able to roll.

#### **Parking**

The parking brake is automatically set if the engine is switched off while the vehicle is being held by Automatic Hold.



The indicator lamp changes from green to red.



The parking brake is not set if the engine is switched off while the vehicle is coasting to a halt. Automatic Hold is

deactivated.

Lower lamp: indicator lamp in Canadian models

Automatic Hold remains activated during the engine stop brought about by the Auto Start/ Stop function.

Take the remote control with you

Take the remote control with you when
leaving the vehicle so that children, for example, cannot release the parking brake.

✓

#### Malfunction

In the event of a failure or malfunction of the parking brake, secure the vehicle against rolling using a wheel chock, for example, when leaving it.

#### Manual release

The parking brake can be released manually in the event of a power failure or electrical fault.




Before releasing, secure the vehicle against rolling

Before releasing the parking brake manually, and whenever you park the vehicle with the parking brake released, ensure that position P of the automatic transmission is engaged.

Secure the vehicle in a manner appropriate to the inclination of the road, e.g., with a wheel chock; otherwise, there is the danger of the vehicle rolling.◀

#### Unlocking

- 1. Open the left side trim in the cargo area.
- Remove the first aid kit and warning triangle. Close the bracket of the warning triangle.
- Insert the screwdriver, in the onboard vehicle tool kit under the cargo floor panel, into the strap of the release point, see arrow.
- Forcefully pull the screwdriver up against the mechanical resistance until you notice a marked increase in the resistance and the parking brake releases audibly.



Stow the screwdriver, warning triangle and first aid kit, and close the left side trim in the cargo area.

Have the malfunction corrected

If the parking brake has been released manually in response to a malfunction, only technicians can return it to operation.

Have the malfunction corrected by your service center. ◀

## After a power failure



Only put the parking brake into operation after a power failure

The parking brake should only be put into operation again if it was manually released due to an interruption in the supply of electrical

power. Otherwise, it cannot be ensured that the parking brake will function properly. ◀

# Putting the parking brake into operation

- 1. Switch on the ignition.
- Press the switch while the brake is depressed or transmission position P is engaged.

It may take several seconds for the brake to be put into operation. Any sounds associated with this are normal.



The indicator lamp in the instrument cluster goes out as soon as the parking brake is ready for operation.




Lower lamp: indicator lamp in Canadian models.

# Turn signal, high beams, headlamp flasher

## **Turn signal**

Do not fold in the exterior mirrors
Do not fold in the exterior mirror while
driving and when the turn signals/warning
flashers are working, or else the additional
flasher lights in the exterior mirror will no longer be in the prescribed position and will be
difficult to see.

### **Using turn signals**



Press the lever beyond the resistance point.

To switch off manually, press the lever to the resistance point.

Unusually rapid flashing of the indicator lamp indicates that a turn signal bulb has failed.

### **Triple turn signal activation**

Press the lever to the resistance point.

The turn signal flashes three times.


The function can be activated or deactivated:

- 1. "Settings"
- 2. "Lighting"
- "Triple turn signal"

### Signaling briefly

Press the lever to the resistance point and hold it there for as long as you want the turn signal to flash.

### High beams, headlamp flasher



- > High beams, arrow 1.
- Headlamp flasher, arrow 2.

# Washer/wiper system

# Switching the wipers on/off and brief wipe

Do not switch on the wipers if frozen
Do not switch on the wipers if they are
frozen onto the windshield; otherwise, the
wiper blades and the windshield wiper motor
may be damaged.

No wiper operation on dry windshield Do not use the windshield wipers if the windshield is dry, as this may damage the wiper blades or cause them to become worn more quickly.

### **Switching on**



Press the wiper levers up.

The lever automatically returns to its initial position when released.

- Normal wiping speed: press up once.
   The wipers switch to intermittent operation when the vehicle is stationary.
- Fast wiping speed: press up twice or press once beyond the resistance point.
  - The wipers switch to normal speed when the vehicle is stationary.

### Switching off and brief wipe



Press the wiper levers down.

The lever automatically returns to its initial position when released.

- Brief wipe: press down once.
- To switch off normal wipe: press down once.
- To switch off fast wipe: press down twice.

### Rain sensor

### The concept

The rain sensor automatically controls the time between wipes depending on the intensity of the rainfall. The sensor is located on the windshield, directly behind the interior rearview mirror.

### **Activating/deactivating**



Press the button on the wiper lever.

The LED in the wiper lever lights up and a wiping operation is started. At temperatures below 32 °F/0 °C, a wiping operation is not started.

Deactivate the rain sensor in car washes
Deactivate the rain sensor when passing
through an automatic car wash; otherwise,
damage could be caused by undesired wiper
activation.

### Rain sensor, sensitivity



Turn the thumbwheel.

### Clean the windshield, headlamps



Pull the wiper lever.

The system sprays washer fluid on the windshield and activates the wipers briefly.

In addition, the headlamps are cleaned at regular intervals when the vehicle lights are switched on.



Do not use the washer system at freezing temperatures

Do not use the washers if there is any danger that the fluid will freeze on the windshield; otherwise, your vision could be obscured. For this reason, use antifreeze. Avoid using the washer when the reservoir is empty; otherwise, you could damage the pump.◀

### Windshield washer nozzles

The windshield washer nozzles are automatically heated while the ignition is switched on.

### **Rear window wiper**

### Switching on the rear window wiper



Turn switch from idle position 0 upward, arrow 1: interval mode. When reverse gear is engaged, the system switches to continuous operation.

### **Cleaning rear window**

In interval mode: turn the switch further upward, arrow 2. The switch automatically returns to its interval position when released.

In idle position: turn switch downward, arrow 3. The switch automatically returns to its idle position when released.

### Fold-out position of the wipers

Required when changing the wiper blades or under frosty conditions, for example.

- 1. Switch the ignition on and off again.
- Under frosty conditions, ensure that the wiper blades are not frozen onto the windshield.
- Press the wiper lever up beyond the point of resistance and hold it for approx. 3 sec-

onds, until the wiper remains in a nearly vertical position.

After the wipers are folded back down, the wiper system must be reactivated.

Fold the wipers back down
Before switching the ignition on, fold the wipers back down to the windshield; otherwise, the wipers may become damaged when they are switched on.

- 1. Switch on the ignition.
- Press the wiper levers down. The wipers move to their resting position and are ready for operation.

### Washer fluid

#### **General information**

Antifreeze for washer fluid
Antifreeze is flammable and can cause injury if it is used incorrectly.

Therefore, keep it away from sources of ignition.

Only keep it in the closed original container and inaccessible to children.

Follow the notes and instructions on the container.

United States: The washer fluid mixture ratio is regulated by the U.S. EPA and many individual states; do not exceed the allowable washer fluid dilution ratios limits that apply. Follow the usage instructions on the washer fluid container. Use BMW's Windshield Washer Concentrate or the equivalent.◀

#### Washer fluid reservoir

Adding washer fluid
Only add washer flui

Only add washer fluid when the engine is cool, and then close the cover completely to avoid contact between the washer fluid and hot engine parts.

Otherwise, there is the danger of fire and a risk to personal safety if the fluid is spilled.◀



All washer nozzles are supplied from one reservoir.

Fill with a mixture of windshield washer concentrate and tap water and – if required – with a washer antifreeze, according to the manufacturer's recommendations.

Mix the washer fluid before adding to maintain the correct mixing ratio.

Do not add windshield washer concentrate and antifreeze undiluted and do not fill with pure water; this could damage the wiper system.

Do not mix window washer concentrates of different manufacturers, because otherwise it can result in clogging of the windshield washer nozzles.

For the capacity, refer to technical data.

# Automatic transmission with Steptronic

### **Transmission positions**

## D Drive, automatic position

Position for normal vehicle operation. All forward gears are available.

#### R is Reverse

Select only when the vehicle is stationary.

#### N is Neutral

Use in automatic car washes, for example. The vehicle can roll.

When the ignition is switched off, refer to page 66, position P is engaged automatically.

#### P Park

Select only when the vehicle is stationary. The drive wheels are blocked.

P is engaged automatically:

- After the engine is switched off when the vehicle is in radio ready state, refer to page 67, or when the ignition is switched off, refer to page 66, and when position R or D is engaged.
- With the ignition is off, if position N is engaged.
- If the safety belt is unbuckled, the driver's door is opened, and the brake pedal is not pressed while the vehicle is stationary and transmission position R or D is engaged.

Before exiting the vehicle, make sure that position P of the automatic transmission is engaged. Otherwise, the vehicle may begin to roll.

#### **Kickdown**

Kickdown is used to achieve maximum driving performance. Press on the gas pedal beyond the resistance point at the full throttle position.

### **Engaging the transmission position**

- Transmission position P can only be disengaged if the engine is running and the brake pedal is pressed.
- ▶ With the vehicle stationary, press on the brake pedal before shifting out of P or N; otherwise, the shift command will not be executed: shift lock.



Depress the brake until you start driving

To prevent the vehicle from creeping after you select a driving position, maintain pressure on the brake pedal until you are ready to start.◀

### **Engaging D, R and N**



Briefly push the selector lever in the desired direction, beyond a resistance point if necessary.

After releasing the selector lever, it returns to its center position.



Press unlock button, in order to:

- Engage R.
- Shift out of P.

### **Engaging P**



Press button P.

### Sport program and manual mode

### **Activating the sport program**



Push the selector lever to the left out of transmission position D.

The engaged gear is displayed in the instrument cluster, e.g., S1.

The sport program of the transmission is activated.

### Activating the M/S manual mode

- 1. Push the selector lever to the left out of transmission position D.
- Push the selector lever forward or pull it backward.

Manual mode becomes active and the gear is changed.

The engaged gear is displayed in the instrument cluster, e.g., M1.

Once maximum engine speed is attained, M/S manual mode is automatically upshifted as needed.

### Switching to manual mode

- To shift down: press the selector lever forward.
- To shift up: pull the selector lever rearwards.

Gears will only be shifted at appropriate engine and road speeds, e.g., downshifting is not possible if the engine speed is too high.

The selected gear is briefly displayed in the instrument cluster, followed by the current gear.

# Not X5 M50d: Sport automatic transmission: prevent automatic upshifting in M/S manual mode

For vehicles with Sport automatic transmissions, automatic shift operations are not performed, at maximum engine speed for example, if one of the following conditions is met:

- DSC deactivated.
- TRACTION activated.
- SPORT+ activated.

In addition, the kickdown is deactivated.

# **Ending the sport program/manual mode**

Push the selector lever to the right.

D is displayed in the instrument cluster.

### Shift paddles



The shift paddles on the steering wheel allow you to shift gears quickly while keeping both hands on the steering wheel.

If the shift paddles on the steering wheel are used to shift gears in automatic mode, the transmission temporarily switches to manual mode.

If the shift paddles are not used and the vehicle is not accelerated for a certain time, the system switches back into automatic mode if the selector lever is in transmission position D.

- Shift up: pull right shift paddle.
- Shift down: pull left shift paddle.

Gears will only be shifted at appropriate engine and road speeds, e.g., downshifting is not possible if the engine speed is too high.

The selected gear is briefly displayed in the instrument cluster, followed by the current gear.

### Displays in the instrument cluster



The transmission position is displayed, e.g.: P.

# **Sport automatic transmission: launch Control**

### The concept

Launch Control enables optimum acceleration on surfaces with good traction.

#### Hints

A Co

Component wear

Do not use Launch Control too often; otherwise, this may result in premature wear of components due to the high stress placed on the vehicle.

Did not use Launch Control during the breakin, refer to page 188, period.

To increase vehicle stability, activate DSC again as soon as possible.

### Requirements

Launch Control is available when the engine is warmed up, that is, after uninterrupted driving of at least 6 miles/10 km.

To start with Launch Control do not steer the steering wheel.

### Start with launch control

While the engine is running:

- Press button or select with the Driving Dynamics Control Sport+.
  - TRACTION is displayed in the instrument cluster and the indicator lamp for DSC OFF lights up.
- Engaging the transmission position S
- 3. With the left foot, forcefully press down on the brake.
- 4. Press on the accelerator beyond the resistance point at the full throttle position.
  - A flag symbol appears in the instrument cluster.
- 5. The starting engine speed adjusts. Within 3 seconds, release the brake.

Before using Launch Control, allow the transmission to cool down for approx. 5 minutes.

Launch Control adjusts to the surrounding conditions, e.g., wet pavement, when used again.

# **Displays**


# Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equip-

ment is also described that is not available in a vehicle, e.g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

### Instrument cluster


### Overview, instrument cluster



- 1 Fuel gauge 86
- 2 Speedometer
- 3 Indicator/warning lamps 84
- 4 Tachometer 86

- 5 Engine oil temperature 86
- 6 Electronic displays 82
- 7 Display/reset miles 87

## Overview, instrument cluster with enhanced features




- 1 Fuel gauge 86
- 2 Speedometer
- 3 Indicator/warning lamps 84
- 4 Tachometer 86

- 5 Engine oil temperature 86
- 6 Electronic displays 82
- 7 Display/reset miles 87

### **Electronic displays**

### **Overview, instrument cluster**



- 1 Clock 87 External temperature 87
- 2 Messages, e.g., Check Control 84
- 3 Transmission displays 79
- 4 Selection list, e.g., Driving Dynamics Control 131
- 5 Computer 91Service requirements 88
- **6** Kilometer display 87 Selection list, e.g., radio 91

### Overview, instrument cluster with navigation system or TV




- Kilometer display 87
   External temperature 87
   Time 87
   Selection list, e.g., radio 91
  - Navigation display, see user's manual for Navigation, Entertainment and Communication.

Computer 91

- Symbol for service need
- Transmission display 79Current fuel consumption 88Energy recovery 88
- 3 Service requirements 88 Messages, e.g., Check Control 84 Navigation display, see user's manual for Navigation, Entertainment and Communication.

### Overview, instrument cluster with enhanced features



- 1 Messages, e.g. Check Control 84 Time 87
- 2 Range 87
- 3 Computer 91
- 4 Navigation display, see user's manual for Navigation, Entertainment and Communication.

Service requirements 88

- Kilometer display 87
- 5 Selection list, e.g., radio 91Current fuel consumption 88

Energy recovery 88

External temperature 87

Transmission display 79

## **Check Control**

### The concept

The Check Control system monitors functions in the vehicle and notifies you of malfunctions in the monitored systems.

A Check Control message is displayed as a combination of indicator or warning lamps and text messages in the instrument cluster and in the Head-up Display.

In addition, an acoustic signal may be output and a text message may appear on the Control Display.

## Indicator/warning lamps

The indicator and warning lamps in the instrument cluster can light up in a variety of combinations and colors.

Several of the lamps are checked for proper functioning and light up temporarily when the engine is started or the ignition is switched on.

### **Overview: indicator/warning lamps**

### Symbol Function or system



Turn signal.



Parking brake.



Parking brake in Canadian models.



Automatic hold.



Front fog lamps.



High beams.



High-beam Assistant.



Parking lamps, headlamp control.



Vehicle detection, Active Cruise Control: collision warning.



Cruise control.



Lane departure warning.



DSC Dynamic Stability Control.



DSC Dynamic Stability Control or DTC Dynamic Traction Control



Tire Pressure Monitor.

Flat Tire Monitor.

### Symbol Function or system



Safety belts.



Airbag system.



Steering system.



Engine functions.



Engine functions in Canadian mod-



Brake system.



Brake system in Canadian models.



ABS Antilock Brake System.



ABS Antilock Brake System in Canadian models.



At least one Check Control message is displayed or is stored.

## Text messages

Text messages in combination with a symbol in the instrument cluster explain a Check Control message and the meaning of the indicator and warning lamps.

### Supplementary text messages

Additional information, such as on the cause of a fault or the required action, can be called up via Check Control.

The supplementary text of urgent messages is automatically displayed on the Control Display.

### **Symbols**

Depending on the Check Control message, the following functions can be selected.

- ▶ (ii) "Owner's Manual"
  - Display additional information about the Check Control message in the Integrated Owner's Manual.
- "Service request"Contact the service partner.
- Roadside Assistance"
   Contact Roadside Assistance.

### **Hiding Check Control messages**



Press the computer button on the turn signal lever.

- Some Check Control messages are displayed continuously and are not cleared until the malfunction is eliminated. If several malfunctions occur at once, the messages are displayed consecutively.
  - These messages can be hidden for approx. 8 seconds. After this time, they are displayed again automatically.
- Other Check Control messages are hidden automatically after approx. 20 seconds.
   They are stored and can be displayed again later.

# **Displaying stored Check Control messages**

- "Vehicle Info"
- "Vehicle status"

- 3. 

  ∧ "Check Control"
- Select the text message.

### Messages after trip completion

Special messages that are displayed during driving are displayed again after the ignition is switched off.

# Fuel gauge



The vehicle inclination may cause the display to vary.

US models: the arrow beside the fuel pump symbol shows which side of the vehicle the fuel filler

flap is on.

Hints on refueling, refer to page 202.

### **Tachometer**

Always avoid engine speeds in the red warning field. In this range, the fuel supply is interrupted to protect the engine.

# **Engine oil temperature**



- Cold engine: the pointer is at the low temperature end.
   Drive at moderate engine and vehicle speeds.
- Normal operating temperature: the pointer is in the middle or in the left half of the temperature display.
- Hot engine: the pointer is at the high temperature end. A Check Control message is also displayed.

## **Coolant temperature**

If the coolant along with the engine becomes too hot, a Check Control message is displayed. Check the coolant level, refer to page 219.

# **Odometer and trip odometer**



- Odometer, arrow 1.
- Trip odometer, arrow 2.

### Display/reset miles



Press the knob.

- When the ignition is switched off, the time, the external temperature and the odometer are displayed.
- When the ignition is switched on, the trip odometer is reset.

## **External temperature**

### **External temperature warning**



If the indicator drops to  $+37 \,^{\circ}\text{F/} + 3 \,^{\circ}\text{C}$  or lower, a signal sounds.

A Check Control message is displayed.

There is the increased danger of ice.

Ice on roads

Even at temperatures above +37 °F/+3 °C, there can be a risk of ice on roads.

Therefore, drive carefully on bridges and shaded roads, for example, to avoid the increased risk of an accident.

✓

## **Time**



The time is displayed at the bottom of the instrument cluster.

Setting the time and time format, refer to page 93.

### **Date**



The date is displayed in the computer.

Setting the date and date format, refer to page 94.

# Range



After the reserve range is reached:

- A Check Control message is displayed briefly.
- The remaining range is shown on the onboard computer.
- When a dynamic driving style is used, such as when cornering quickly, operation of the engine is not always ensured.

The Check Control message appears continuously below a range of approx. 30 miles/50 km.

Refuel promptly

Refuel no later than at a range of 30 miles/50 km, or operation of the engine is not ensured and damage may occur.

### Displaying the cruising range

- 1. "Settings"
- 2. "Info display"
- "Additional indicators"

The range is displayed in the instrument cluster.

# **Current fuel consumption**



Displays the current fuel consumption. You can check whether you are currently driving in an efficient and environmentally-friendly manner.

# Displaying the current fuel consumption

- 1. "Settings"
- 2. "Info display"
- 3. "Additional indicators"

The bar display for the current fuel consumption is displayed in the instrument cluster.

## **Energy recovery**



The kinetic energy of the vehicle is converted to electrical energy while coasting. The vehicle battery is partially charged and fuel consumption can be lowered.

# Service requirements

### **Display**



The driving distance or the time to the next scheduled maintenance is displayed briefly after the ignition is switched on.

The current service require-

ments can be read out from the remote control by the service specialist.

With TeleService, data regarding the service status or legally mandated inspections of your vehicle are automatically transmitted to your service center before the service due date.

# Detailed information on service requirements

More information on the scope of service required can be displayed on the Control Display.

- 1. "Vehicle Info"
- 2. "Vehicle status"
- "Service required"
   Required maintenance procedures and le-
- 4. Select an entry to call up detailed information.

gally mandated inspections are displayed.

### **Symbols**

Symbols	Description
OK	No service is currently required.
Δ	The deadline for service or a legally mandated inspection is approaching.
	The service deadline has al-

### **Entering appointment dates**

Enter the dates for the required inspections. Ensure that the vehicle date and time are set correctly.

- 1. "Vehicle Info"
- "Vehicle status"
- Service required"
- 4. "§ Vehicle inspection"
- 5. "Date:"
- Adjust the settings.
- 7. Confirm.

The entered date is stored.

### **Automatic Service Request**

Data regarding the service status or legally mandated inspections of the vehicle are automatically transmitted to your service center before a service due date.

You can check when your service center was notified.

- 1. "Vehicle Info"
- 2. "Vehicle status"
- 3. Open "Options".
- 4. "Last Service Request"

### **Service history**

Perform maintenance work at the service center and have them recorded in the vehicle data. The entries are like a service booklet of the documentation of regular maintenance.

The entered maintenance work can be displayed on the Control Display. Function is available as soon as a maintenance operation has been entered in the vehicle data.

- 1. "Vehicle Info"
- 2. "Vehicle status"
- 3. Service required"
- 4. Service history"

Performed maintenance operations are displayed.

Select an entry to call up detailed information.

## **Symbols**

Symbols	Description
OK	Green: maintenance was performed on schedule.
OK	Yellow: maintenance was performed late.
	Maintenance was not performed.

### **Gear shift indicator**

### The concept

The system recommends the most fuel efficient gear in the current driving situation.

Depending on how the vehicle is equipped and the country-specific version of the vehicle, the gear shift indicator is active in the manual mode of the automatic transmission.

Indicators to shift up or down are displayed in the instrument cluster.

On vehicles without a gear shift indicator, the engaged gear is displayed.

### **Displays**

Example	Description
3	Fuel efficient gear is engaged.
3▶4	Shift into fuel efficient gear.

# **Speed limit detection with No Passing Information**

### The concept

## Speed limit detection

Speed limit detection uses a symbol in the shape of a traffic sign to display the currently detected speed limit. The camera at the base of the interior rearview mirror detects traffic signs at the edge of the road as well as variable overhead sign posts. Traffic signs with extra symbols for wet road conditions, etc. are also detected and compared with vehicle interior data, such as for the rain sensor, and are displayed depending on the situation. The system takes into account the information stored in the navigation system and also displays speed limits present on routes without signs.

### **No Passing Information**

No Passing Information in the instrument cluster displays the beginnings and ends of no passing zones detected by the camera. The system accounts for only the beginnings and ends of No Passing zones marked by signs.

No display is shown:

- In countries where No Passing zones are primarily identified with road markings.
- On routes without signage.
- Where there are railroad crossings, highway markings or other situations where no signage is present, but passing would not be permitted.

#### **Hints**

Personal judgment

The system cannot serve as a substitute for the driver's personal judgment of the traffic situation.

The system assists the driver and does not replace the human eye. ◀

## At a glance

#### **Camera**



The camera is located near the base of the mirror.

Keep the windshield in the area behind the interior rear view mirror clean and clear.

## Switching on/off

1. "Settings"

- 2. "Info display"
- "Speed limit information"

If speed limit detection is switched on, it can be displayed on the info display in the instrument cluster via the onboard computer. No Passing Information is displayed together with the activated speed limit information.

### **Display**

The following is displayed in the instrument cluster.

### **Speed limit detection**



Current speed limit.



Speed limit detection is not available.

Speed limit detection can also be displayed in the Head-up Display.

## **No Passing Information**



- Start of No Passing zone.
- ▶ End of No Passing zone.
  - No Passing Information not available.

No Passing Information can also be displayed in the Head-up Display.

## **System limits**

The system may not be fully functional and may provide incorrect information in the following situations:

- ▶ In heavy fog, rain or snowfall.
- ▶ When signs are concealed by objects.

- When driving very close to the vehicle in front of you.
- When driving toward bright lights.
- When the windshield behind the interior rearview mirror is fogged over, dirty or covered by a sticker, etc.
- In the event of incorrect detection by the camera.
- ▶ If the speed limits stored in the navigation system are incorrect.
- In areas not covered by the navigation system.
- When roads differ from the navigation, such as due to changes in the road network.
- When passing buses or trucks with a speed sticker.
- If the traffic signs are non-conforming.
- During calibration of the camera immediately after vehicle shipment.

# Selection lists in the instrument cluster


### The concept



The following can be operated using the buttons and the thumbwheel on the steering wheel:

- Current audio source.
- Redial on telephone.
- Activation of the voice activation system.

# Activating a list and creating the setting



On the right side of the steering wheel, turn the thumbwheel to activate the corresponding list.

Using the thumbwheel, select the desired setting and confirm it by pressing the thumbwheel.

# Computer

## Indication in the info display



The information from the onboard computer is shown in the info display in the instrument cluster.

# Calling up information on the info display



Press the onboard computer button on the turn signal lever.

Information is displayed on the info display of the instrument cluster.

### Information at a glance

Repeatedly pressing the button on the turn signal lever calls up the following information on the info display:

- Range.
- Average fuel consumption.
- Average speed.
- Date.
- Speed limit detection.
- Time of arrival.

When destination guidance is activated in the navigation system.

- Distance to destination.
  - When destination guidance is activated in the navigation system.
- Arrow view of navigation system.
  - When destination guidance is activated in the navigation system.
  - When the arrow view in the Head-up Display is inactive.
- Compass display in the navigation system.

### Adjusting the info display

You can select what information from the onboard computer is to be displayed on the info display of the instrument cluster.

- 1. "Settings"
- 2. "Info display"
- Select the desired displays.

#### Information in detail

### Range

Displays the estimated cruising range available with the remaining fuel.

It is calculated based on your driving style over the last 20 miles/30 km.

### **Average fuel consumption**

The average fuel consumption is calculated for the period during which the engine is running.

The average fuel consumption is calculated for the distance traveled since the last reset by the onboard computer.

### Average speed

Periods in which the vehicle is parked with the engine manually stopped do not enter into the calculation of the average speed.

### **Resetting average values**

Press and hold the computer button on the turn signal lever.

#### Distance to destination

The distance remaining to the destination is displayed if a destination is entered in the navigation system before the trip is started.

The distance to the destination is adopted automatically.

### Time of arrival



The estimated time of arrival is displayed if a destination is entered in the navigation system before the trip is started.

The time must be correctly set.

### **Speed limit detection**

Description of the speed limit detection, refer to page 89, function.

### Compass

With Professional navigation system: compass display for the driving direction.

## **Speed limit**

Display of a speed limit which, when reached, should cause a warning to be issued.

The warning is repeated if the vehicle speed drops below the set speed limit once by at least 3 mph/5 km/h.

# Displaying, setting or changing the limit

- 1. "Settings"
- 2. "Speed"
- 3. "Warning at:"
- Turn the controller until the desired limit is displayed.
- 5. Press the controller.

The speed limit is stored.

### **Activating/deactivating the limit**

- 1. "Settings"
- 2. "Speed"
- 3. "Warning"
- 4. Press the controller.

### Setting your current speed as the limit

- 1. "Settings"
- 2. "Speed"
- "Select current speed"
- 4. Press the controller.

The current vehicle speed is stored as the limit.

### **Trip computer**

The vehicle features two types of computer.

- "Onboard info": the values can be reset as often as necessary.
- "Trip computer": the values provide an overview of the current trip.

### Resetting the trip computer

- 1. "Vehicle Info"
- 2. "Trip computer"
- 3. "Reset": all values are reset.

"Automatically reset": all values are reset approx. 4 hours after the vehicle comes to a standstill.

### **Display on the Control Display**

Display the onboard computer or trip computer on the Control Display.

- 1. "Vehicle Info"
- "Onboard info" or "Trip computer"

# Resetting the fuel consumption or speed

- 1. "Vehicle Info"
- 2. "Onboard info"
- "Consumpt." or "Speed"
- 4. "Yes"

# **Settings on the Control Display**

### **Time**

### Setting the time zone

- 1. "Settings"
- 2. "Time/Date"
- 3. "Time zone"
- 4. Select the desired time zone.

The time zone is stored.

## Setting the time

- 1. "Settings"
- 2. "Time/Date"
- 3. "Time:"
- Turn the controller until the desired hours are displayed.
- Press the controller.
- Turn the controller until the desired minutes are displayed.
- 7. Press the controller.

The time is stored.

### Setting the time format

- 1. "Settings"
- 2. "Time/Date"
- "Format:"
- Select the desired format.

The time format is stored.

#### Date

### Setting the date

- 1. "Settings"
- 2. "Time/Date"
- "Date:"
- 4. Turn the controller until the desired day is displayed.
- Press the controller.
- 6. Make the necessary settings for the month and vear.

The date is stored.

### Setting the date format

- 1. "Settings"
- 2. "Time/Date"
- 3. "Format:"
- Select the desired format.

The date format is stored.

### Language

### Setting the language

To set the language on the Control Display:

- 1. "Settings"
- "Language/Units"
- 3. "Language:"
- 4. Select the desired language.

The setting is stored for the remote control currently in use.

### Setting the voice dialog

Voice dialog for the voice activation system. refer to page 25.

### Units of measure

### Setting the units of measure

To set the units for fuel consumption, route/ distance and temperature:

- "Settings"
- "Language/Units"
- Select the desired menu item.
- Select the desired unit.

The setting is stored for the remote control currently in use.

### **Brightness**

### Setting the brightness

To set the brightness of the Control Display:

- 1. "Settings"
- 2. "Control display"
- "Brightness"
- 4. Turn the controller until the desired brightness is set.
- Press the controller.

The setting is stored for the remote control currently in use.


Depending on the light conditions, the brightness control may not be clearly visible.

# **Lamps**

# Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

# At a glance



- 1 Rear fog lamps
- 2 Front fog lamps
- 3 Automatic headlamp control, Adaptive Light Control, High-beam Assistant, Welcome lamps, Daytime running lights
- 4 Lamps off, daytime running lights
- 5 Parking lamps, daytime running lights
- 6 Low beams, welcome lamps, High-beam Assistant
- 7 Headlamp range control
- 8 Instrument lighting

# Parking lamps/low beams, headlamp control

### **General information**

Switch position: 0, **ID** , **ID** 

If the driver door is opened with the ignition switched off, the exterior lighting is automatically switched off at these switch settings.

### **Parking lamps**

Switch position **ED QE**: the vehicle lamps light up on all sides, e.g., for parking.

Do not use the parking lamps for extended periods; otherwise, the battery may become discharged and it would then be impossible to start the engine.

When parking, it is preferable to switch on the one-sided roadside parking lamps, refer to page 96.

#### Low beams

Switch position **D** with the ignition switched on: the low beams light up.

### Welcome lamps

When parking the vehicle, leave the switch in position  $\PD$  or  $\PD$ : the parking and interior lamps light up briefly when the vehicle is unlocked.

### **Activating/deactivating**

- 1. "Settings"
- 2. "Lighting"
- 3. "Welcome lights"

The setting is stored for the remote control currently in use.

## Headlamp courtesy delay feature

The low beams stay lit for a short while if the headlamp flasher is switched on after the ignition is switched off.

### **Setting the duration**

- 1. "Settings"
- 2. "Lighting"

- 3. "Pathway lighting:"
- 4. Set the duration.

The setting is stored for the remote control currently in use.

### **Automatic headlamp control**

Switch position **\*** the low beams are switched on and off automatically, e.g., in tunnels, in twilight or if there is precipitation. The indicator lamp in the instrument cluster lights up.

A blue sky with the sun low on the horizon can cause the lights to be switched on.

The low beams always stay on when the fog lamps are switched on.

Personal responsibility
The automatic headlamp control cannot serve as a substitute for your personal judg-

serve as a substitute for your personal judgment in determining when the lamps should be switched on in response to ambient lighting conditions.

For example, the sensors are unable to detect fog or hazy weather. To avoid safety risks, you should always switch on the lamps manually under these conditions.

### **Daytime running lights**

With the ignition switched on, the daytime running lights light up in position 0,  $\Rightarrow$ **D Q** $\Rightarrow$  or  $\Rightarrow$ **Q** $\Rightarrow$  . After the ignition is switched off, the parking lamps light up in position  $\Rightarrow$ **D Q** $\Rightarrow$  .


### **Activating/deactivating**

In some countries, daytime running lights are compulsory, so it may not be possible to deactivate the daytime running lights.

- 1. "Settings"
- 2. "Lighting"
- 3. "Daytime running lamps"

The setting is stored for the remote control currently in use.

### Roadside parking lamps



The vehicle can be illuminated on one side.

### Switching on

With the ignition switched off, press the lever either up or down past the resistance point for approx. 2 seconds.

### **Switching off**

Briefly press the lever to the resistance point in the opposite direction.

# **Adaptive Light Control**

## The concept

Adaptive Light Control is a variable headlamp control system that enables dynamic illumination of the road surface.

Depending on the steering angle and other parameters, the light from the headlamp follows the course of the road.

In tight curves, e.g., on mountainous roads or when turning, one of the two front fog lamps is switched on as a turning lamp. As a result the inside of the curve is better lighted.

## **Activating**

Switch position \* with the ignition switched on

The turning lamps are automatically switched on depending on the steering angle or the use of turn signals.

To avoid blinding oncoming traffic, the Adaptive Light Control does not swivel to the driver's side when the vehicle is at a standstill.

When driving in reverse, only the turning lamp is active.

### **Self-leveling headlamps**

The self-leveling headlamps compensate for acceleration and braking operations in order not to blind the oncoming traffic and to achieve optimum illumination of the roadway.

#### Malfunction

A Check Control message is displayed.

Adaptive light control is malfunctioning or has failed. Have the system checked as soon as possible.

# **High-beam Assistant**

### The concept

When the low beams are switched on, this system automatically switches the high beams on and off. The procedure is controlled by a sensor on the front of the interior rearview mirror. The assistant ensures that the high beams are switched on whenever the traffic situation allows. The driver can intervene at any time and switch the high beams on and off as usual.

### **Activating**



The High-beam Assistant can be activated when the low beams are switched on.

- Press the button on the turn signal lever, arrow.



The indicator lamp in the instrument cluster lights up.

When the low beams are on, the lights are automatically brightened or dimmed.


The system responds to light from oncoming traffic and traffic driving ahead of you, and to adequate illumination, e.g., in towns and cities.



The blue indicator lamp in the instrument cluster lights up when the system switches on the high beams. Depend-

ing on the version of the system in the vehicle, the high beams may not switch off for oncoming vehicles, but may only be dimmed in the areas that blind oncoming traffic. In this case, the blue indicator light will stay on.

# Switching the high beams on and off manually



- ▶ High beams on, arrow 1.
- ▶ High beams off/headlamp flasher, arrow 2.

The High-beam Assistant can be switched off when manually adjusting the light. To reactivate the High-beam Assistant, press the button on the turn signal lever.

### **System limits**


Personal responsibility

The high-beam assistant cannot serve as a substitute for the driver's personal judgment of when to use the high beams. Therefore, manually switch off the high beams in situations where this is required to avoid a safety risk.

The system is not fully functional in situations such as the following, and driver intervention may be necessary:

- In very unfavorable weather conditions, such as fog or heavy precipitation.
- In detecting poorly-lit road users, such as pedestrians, cyclists, horseback riders and wagons; when driving close to train or ship traffic; and at animal crossings.
- In tight curves, on hilltops or in depressions, in cross traffic or half-obscured oncoming traffic on freeways.
- In poorly-lit towns and cities and in the presence of highly reflective signs.
- At low speeds.
- When the windshield in front of the interior rearview mirror is fogged over, dirty or covered with stickers, etc.

#### Camera



The camera is located near the base of the mirror.

Keep the windshield in the area behind the interior rear view mirror clean and clear.

# Fog lamps

### Front fog lamps

The parking lamps or low beams must be switched on.



Press the button. The green indicator lamp lights up.

If the automatic headlamp control, refer to page 96, is activated, the low beams will come on automatically when you switch on the front fog lamps.

# **Instrument lighting**

### **Adjusting**



The parking lamps or low beams must be switched on to adjust the brightness.

Adjust the brightness using the thumbwheel.

# **Interior lamps**

### **General information**

The interior lamps, footwell lamps, entry lamps and courtesy lamps are controlled automatically.

The brightness of some of these lamps is influenced by the thumbwheel for the instrument lighting.



- Interior lamps
- 2 Reading lamp

# Switching the interior lamps on and off



Press the button.

To switch off permanently: press the button for approx. 3 seconds.

Switch back on: press button.

### **Reading lamps**



Press the button.

Reading lamps are located at the front and rear next to the interior lamps.

When the interior lamps are switched off permanently, the reading lamps cannot be switched on.

### **Ambient light**

Depending on the equipment, the lighting can be adjusted in the interior for some lights.

### **Selecting color scheme**

- 1. "Settings"
- 2. "Lighting"
- 3. "Lighting design"
- 4. Select the desired setting.

If the color scheme of the ensemble is selected and the welcome lamps are activated, the welcome lamps are displayed in the color of the ensemble when the vehicle is unlocked. To deactivate the ambient light: "Off".

### **Setting the brightness**

The brightness of the ambient light can be adjusted via the thumbwheel for the instrument lighting but also independently of it.

- 1. "Settings"
- 2. "Lighting"
- 3. "Brightness:"
- 4. Adjust the brightness.


# **Safety**

# Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equip-

ment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

# **Airbags**



- 1 Front airbag, driver
- 2 Front airbag, front passenger
  - 3 Head airbag

## Front airbags

Front airbags help protect the driver and front passenger by responding to frontal impacts in which safety belts alone cannot provide adequate restraint.

## Side airbags

In a lateral impact, the side airbag supports the side of the body in the chest and lap area.

- 4 Side airbag
- 5 Knee airbags

### **Head airbags**

In a lateral impact, the head airbag supports the head.

### **Knee airbag**

The knee airbag supports the legs in a frontal impact.

#### **Protective action**

Airbags are not triggered in every impact situation, e.g., in less severe accidents or rear-end collisions.



Information on how to ensure the optimal protective effect of the airbags

- Keep at a distance from the airbags.
- Always grasp the steering wheel on the steering wheel rim, holding your hands at the 3 o'clock and 9 o'clock positions, to keep the danger of injury to your hands or arms as low as possible if the airbag is triggered.
- There should be no people, animals, or objects between an airbag and a person.
- Do not use the cover of the front airbag on the front passenger side as a storage area.
- Keep the dashboard and window on the front passenger side clear, i.e., do not cover with adhesive labels or coverings, and do not attach holders such as for navigation instruments and mobile phones.
- Make sure that the front passenger is sitting correctly, i.e., keeps his or her feet and legs in the footwell; otherwise, leg injuries can occur if the front airbag is triggered.
- Do not place slip covers, seat cushions or other objects on the front passenger seat that are not approved specifically for seats with integrated side airbags.
- Do not hang pieces of clothing, such as jackets, over the backrests.
- Make sure that occupants keep their heads away from the side airbag and do not rest against the head airbag; otherwise, injuries can occur if the airbags are triggered.
- Do not remove the airbag restraint system.
- Do not remove the steering wheel.
- Do not apply adhesive materials to the airbag cover panels, cover them or modify them in any way.

Never modify either the individual components or the wiring in the airbag system. This also applies to steering wheel covers, the dashboard, the seats, the roof pillars and the sides of the headliner. ◄

Even when all instructions are followed closely, injury from contact with the airbags cannot be ruled out in certain situations.

The ignition and inflation noise may lead to short-term and, in most cases, temporary hearing impairment in sensitive individuals.



In the case of a malfunction, deactivation and after triggering of the airbags

Do not touch the individual components immediately after the system has been triggered; otherwise, there is the danger of burns.

Only have the airbags checked, repaired or dismantled and the airbag generator scrapped by your service center or a workshop that has the necessary authorization for handling explosives.

Non-professional attempts to service the system could lead to failure in an emergency or undesired triggering of the airbag, either of which could result in injury. ◀

Warnings and information on the airbags are also found on the sun visors.

# Functional readiness of the airbag system

When the ignition is switch on, the warning lamp in the instrument cluster lights up briefly and thereby indicates

the operational readiness of the entire airbag system and the belt tensioner.

## Airbag system malfunctioning

- Warning lamp does not come on when the ignition is turned on.
- ▶ The warning lamp lights up continuously.



When there is a malfunction, have the airbag system checked immediately

When there is a malfunction, have the airbag system checked immediately; otherwise, there is a risk that the system does not function as expected in the event of an accident despite corresponding severity of the accident. ◄

# Automatic deactivation of the front passenger airbags

The system determines whether the front passenger seat is occupied by measuring the resistance of the human body.

The front, knee, and side airbag on the front passenger side are activated or deactivated accordingly.

Leave feet in the footwell

Make sure that the front passenger keeps his or her feet in the footwell; otherwise, the front passenger airbags may not function properly. ◀



Child restraint fixing system in the front passenger seat

Before transporting a child on the front passenger seat, refer to the safety notes and instructions under Children on the front passenger seat. ◀

# Malfunction of the automatic deactivation system

When transporting older children and adults, the front passenger airbags may be deactivated in certain sitting positions. In this case, the indicator lamp for the front passenger airbags lights up.

In this case, change the sitting position so that the front passenger airbags are activated and the indicator lamp goes out.

If it is not possible to activate the airbags, have the person sit in the rear.

To make sure that the occupied seat cushion can be evaluated correctly

- Do not attach covers, cushions, ball mats or other items to the front passenger seat unless they are specifically recommended by the manufacturer of your vehicle.
- Do not place any electronic devices on the passenger seat if a child restraint system is to be installed on it.
- Do not place objects under the seat that could press against the seat from below.

# Indicator lamp for the front passenger airbags



The indicator lamp for the front passenger airbags indicates the operating state of the front passenger airbags.

The lamp indicates whether the airbags are activated or deactivated.



- ➤ The indicator lamp lights up when a child who is properly seated in a child restraint fixing system intended for that purpose is detected on the seat or the seat is empty. The airbags on the front passenger side are not activated.
- The indicator lamp does not light up when, for example, a correctly seated person of sufficient size is detected on the seat. The airbags on the front passenger side are activated.

#### **Detected child seats**

The system generally detects children seated in a child seat, especially in the child seats that were required by NHTSA when the vehicle was manufactured. After installing a child seat, make sure that the indicator lamp for the front passenger airbags lights up. This indicates that the child seat has been detected and the front passenger airbags are not activated.

# Strength of the driver's and front passenger airbag

The strength with which the driver's and front passenger airbags are triggered depends on the position of the driver's and front passenger seats.

To maintain the accuracy of this function over the long-term, calibrate the front seats when a corresponding message appears on the Control Display.

### **Calibrating the front seats**

A corresponding message appears on the Control Display.

- Move the respective seat forward all the way.
- 2. Move the respective seat forward again. It moves forward briefly.
- 3. Readjust the seat to the desired position.

The calibration procedure is completed when the message on the Control Display disappears.

If the message continues to be displayed, repeat the calibration.

If the message does not disappear after a repeat calibration, have the system checked as soon as possible.

Unobstructed area of movement
Ensure that the area of movement of the
seats is unobstructed to avoid personal injury
or damage to objects.

✓

### **Tire Pressure Monitor TPM**

### The concept

The system monitors tire pressure in the four mounted tires. The system warns you if there is a significant loss of pressure in one or more tires. For this purpose, sensors in the tire valves measure the tire pressure and tire temperature.

#### **Hints**

Tire damage due to external factors
Sudden tire damage caused by external influences cannot be indicated in advance.

✓

Pay attention to the other information and indications under Tire inflation pressure, refer to page 205, as well when using the system.

### **Functional requirements**

The system must have been reset with the correct tire inflation pressure; otherwise, reliable signaling of tire pressure loss is not ensured.

Reset the system again after each correction of the tire inflation pressure and after every tire or wheel change.

Always use wheels with TPM electronics to ensure that the system will operate properly.

## Status display

The current status of the Tire Pressure Monitor TPM can be displayed on the Control Display, e.g., whether or not the TPM is active.

- "Vehicle Info"
- 2. "Vehicle status"
- 3. (!) "Tire Pressure Monitor"

The status is displayed.

### Status display

The tire and system status is indicated by the color of the wheels and a text message on the Control Display.

### All wheels green

System is active and will issue a warning relative to the tire inflation pressures stored during the last reset.

### One wheel is yellow

A flat tire or major drop in inflation pressure in the indicated tire.

### All wheels are yellow

A flat tire or major drop in inflation pressure in several tires.

### Wheels, gray

The system cannot detect a flat tire. Reasons for this may be:

- The system is being reset.
- Malfunction.

#### Additional information

The status display additionally shows the current tire inflation pressures. The values shown are current measurement values and may vary depending on driving style or weather conditions. If the tire inflation pressure and tire temperatures are not displayed despite the system being active, an incorrect tire sensor might be installed.

### **Carry out reset**

Reset the system after each correction of the tire inflation pressure and after every tire or wheel change.

- 1. "Vehicle Info"
- 2. "Vehicle status"
- 3. (!), "Perform reset"
- 4. Start the engine do not drive away.
- 5. Carry out the reset with "Perform reset".
- 6. Drive away.

The tires are shown in gray and the status is displayed.

After driving faster than 19 mph/30 km/h for a short period, the tire inflation pressures set are accepted as reference values. The reset is completed automatically during driving.

In Canadian models

The progress of the reset is displayed.

After a successfully completed Reset, the wheels on the Control Display are shown in green and "Tire Pressure Monitor (TPM) active" is displayed.

The trip can be interrupted at any time. If you drive away again, the reset resumes automatically.

### Low tire pressure message



The yellow warning lamp lights up. A Check Control message is displayed.

- ► There is a flat tire or a major loss in tire inflation pressure.
- No reset was performed for the system. The system therefore issues a warning based on the tire pressures before the last reset.
- Reduce your speed and stop cautiously. Avoid sudden braking and steering maneuvers
- 2. Check whether the vehicle is fitted with regular tires or run-flat tires.

Run-flat tires, refer to page 214, are labeled with a circular symbol containing the letters RSC marked on the tire sidewall.



Do not continue driving without run-flat tires

Do not continue driving if the vehicle is not equipped with run-flat tires; continued driving may result in serious accidents.◀

When a low inflation pressure is indicated, DSC Dynamic Stability Control is switched on if necessary.

### Actions in the event of a flat tire

### **Normal tires**

1. Identify the damaged tire.

Do this by checking the air pressure in all four tires.

If the tire inflation pressure in all four tires is correct, it is possible that a reset was not carried out for the Tire Pressure Monitor. In that case, carry out a reset.

If an identification is not possible, please contact the service center.

2. Rectify the flat tire.

Use of tire sealant, e.g., the Mobility System, may damage the TPM wheel electronics. In this case, have the electronics checked at the next opportunity and have them replaced if necessary.

### **Run-flat tires**

### **Maximum speed**

You can continue driving with a damaged tire at speeds up to 50 mph/80 km/h.

### Continued driving with a flat tire

If continuing to drive with a damaged tire:

- Avoid sudden braking and steering maneuvers.
- 2. Do not exceed a speed of 50 mph/80 km/h.
- 3. Check the air pressure in all four tires at the next opportunity.

If the tire inflation pressure in all four tires is correct, it is possible that a reset was not carried out for the Tire Pressure Monitor. In that case, carry out a reset.

Possible driving distance with complete loss of tire inflation pressure:

The possible driving distance after a loss of tire inflation pressure depends on the cargo load and the driving style and conditions.

For a vehicle containing an average load, the possible driving distance is approx. 50 miles/80 km.

When the vehicle is driven with a damaged tire, its handling characteristics change, e.g., reduced lane stability during braking, a longer braking distance, and altered self-steering properties. Adjust your driving style accordingly. Avoid abrupt steering maneuvers or driving over obstacles, e.g., curbs, potholes, etc.

Because the possible driving distance depends on how the vehicle is used during the trip, the actual distance may be smaller or greater depending on the driving speed, road conditions, external temperature, cargo load, etc.

Continued driving with a flat tire
Drive moderately and do not exceed a speed of 50 mph/80 km/h.

A loss of tire inflation pressure results in a change in the handling characteristics, e.g., reduced lane stability during braking, a longer braking distance and altered self-steering properties.

Final tire failure

Vibrations or loud noises while driving can indicate the final failure of the tire. Reduce speed and stop; otherwise, pieces of the tire could come loose and cause an accident. Do not continue driving, and contact your service center.

# Required inflation pressure check message

A Check Control message is displayed.

Check the tire inflation pressure and carry out a reset of the system.

In some cases, a wheel was changed without having carried out a reset.

### **System limits**

The system does not function properly if a reset has not been carried out, e.g., a flat tire is reported even though the tire inflation pressures are correct.

The tire pressure depends on the temperature of the tire. If the tire temperature rises, e.g., due to driving or because of the heat of the Sun, the tire inflation pressure increases also. The tire pressure is reduced when the tire temperature falls again. This behavior may cause a warning to be issued if temperatures fall very sharply.

### Malfunction



The yellow warning lamp flashes and then lights up continuously. A Check Control message is displayed. No flat

tire or loss of tire pressure can be detected.

Display in the following situations:

- A wheel without TPM electronics is fitted: have the service center check it if necessary.
- Malfunction: have the system checked by your service center.
- TPM was unable to complete the reset. Reset the system again.
- Disturbance by systems or devices with the same radio frequency: after leaving the area of the disturbance, the system automatically becomes active again.

### Declaration according to NHTSA/ FMVSS 138 Tire Pressure Monitoring System

Each tire, including the spare (if provided) should be checked monthly when cold and inflated to the inflation pressure recommended by the vehicle manufacturer on the vehicle placard or tire inflation pressure label. (If your vehicle has tires of a different size than the size indicated on the vehicle placard or tire inflation pressure label, you should determine the

proper tire inflation pressure for those tires.) As an added safety feature, your vehicle has been equipped with a tire pressure monitoring system (TPMS) that illuminates a low tire pressure telltale when one or more of your tires is significantly under-inflated. Accordingly, when the low tire pressure telltale illuminates, you should stop and check your tires as soon as possible, and inflate them to the proper pressure. Driving on a significantly under-inflated tire causes the tire to overheat and can lead to tire failure. Under-inflation also reduces fuel efficiency and tire tread life, and may affect the vehicle's handling and stopping ability. Please note that the TPMS is not a substitute for proper tire maintenance, and it is the driver's responsibility to maintain correct tire pressure, even if under-inflation has not reached the level to trigger illumination of the TPMS low tire pressure telltale. Your vehicle has also been equipped with a TPMS malfunction indicator to indicate when the system is not operating properly. The TPMS malfunction indicator is combined with the low tire pressure telltale. When the system detects a malfunction, the telltale will flash for approximately one minute and then remain continuously illuminated. This sequence will continue upon subsequent vehicle start-ups as long as the malfunction exists. When the malfunction indicator is illuminated, the system may not be able to detect or signal low tire pressure as intended. TPMS malfunctions may occur for a variety of reasons, including the installation of replacement or alternate tires or wheels on the vehicle that prevent the TPMS from functioning properly. Always check the TPMS malfunction telltale after replacing one or more tires or wheels on your vehicle to ensure that the replacement or alternate tires and wheels allow the TPMS to continue to function properly.

## **FTM Flat Tire Monitor**

### The concept

The system does not measure the actual inflation pressure in the tires.

It detects a pressure loss in a tire by comparing the rotational speeds of the individual wheels while moving.

In the event of a pressure loss, the diameter and therefore the rotational speed of the corresponding wheel change. This is detected and reported as a flat tire.

### **Functional requirements**

The system must have been initialized when the tire inflation pressure was correct; otherwise, reliable signaling of a flat tire is not ensured. Initialize the system after each correction of the tire inflation pressure and after every tire or wheel change.

### **Status display**

The current status of the Flat Tire Monitor can be displayed on the Control Display, e.g., whether or not the FTM is active.

- "Vehicle Info"
- 2. "Vehicle status"
- 3. (!) "Flat Tire Monitor (FTM)"

The status is displayed.

#### Initialization

The initialization process adopts the set inflation tire pressures as reference values for the detection of a flat tire. Initialization is started by confirming the inflation pressures.

Do not initialize the system when driving with snow chains.

- 1. "Vehicle Info"
- 2. "Vehicle status"
- 3. (!) "Perform reset"
- 4. Start the engine do not drive away.

- 5. Start the initialization with "Perform reset".
- Drive away.

The initialization is completed while driving, which can be interrupted at any time.

The initialization automatically continues when driving resumes.

### Indication of a flat tire



The yellow warning lamp lights up. A Check Control message is displayed.

There is a flat tire or a major loss in tire inflation pressure.

- Reduce your speed and stop cautiously. Avoid sudden braking and steering maneuvers.
- 2. Check whether the vehicle is fitted with regular tires or run-flat tires.

Run-flat tires, refer to page 214, are labeled with a circular symbol containing the letters RSC marked on the tire sidewall.



Do not continue driving without run-flat tires

Do not continue driving if the vehicle is not equipped with run-flat tires; continued driving may result in serious accidents.◀

When a flat tire is indicated, DSC Dynamic Stability Control is switched on if necessary.

### **System limits**

Sudden tire damage

Sudden serious tire damage caused by external influences cannot be indicated in advance.

A natural, even pressure loss in all four tires cannot be detected. Therefore, check the tire inflation pressure regularly.

The system could be delayed or malfunction in the following situations:

When the system has not been initialized.

- When driving on a snowy or slippery road surface.
- Sporty driving style: slip in the drive wheels, high lateral acceleration.
- When driving with snow chains.

### Actions in the event of a flat tire

#### **Normal tires**

1. Identify the damaged tire.

Do this by checking the air pressure in all four tires.

If the tire inflation pressure in all four tires is correct, the Flat Tire Monitor may not have been initialized. In this case, initialize the system.

If an identification is not possible, please contact the service center.

2. Rectify the flat tire.

### **Run-flat tires**

#### Maximum speed

You can continue driving with a damaged tire at speeds up to 50 mph/80 km/h.

#### Continued driving with a flat tire

If continuing to drive with a damaged tire:

- Avoid sudden braking and steering maneuvers.
- 2. Do not exceed a speed of 50 mph/80 km/h.
- 3. Check the air pressure in all four tires at the next opportunity.

If the tire inflation pressure in all four tires is correct, the Flat Tire Monitor may not have been initialized. In this case, initialize the system.

Possible driving distance with complete loss of tire inflation pressure:

The possible driving distance after a loss of tire inflation pressure depends on the cargo load and the driving style and conditions.

For a vehicle containing an average load, the possible driving distance is approx. 50 miles/80 km.

When the vehicle is driven with a damaged tire, its handling characteristics change, e.g., reduced lane stability during braking, a longer braking distance, and altered self-steering properties. Adjust your driving style accordingly. Avoid abrupt steering maneuvers or driving over obstacles, e.g., curbs, potholes, etc.

Because the possible driving distance depends on how the vehicle is used during the trip, the actual distance may be smaller or greater depending on the driving speed, road conditions, external temperature, cargo load, etc.

Continued driving with a flat tire
Drive moderately and do not exceed a speed of 50 mph/80 km/h.

A loss of tire inflation pressure results in a change in the handling characteristics, e.g., reduced lane stability during braking, a longer braking distance and altered self-steering properties.

Final tire failure

Vibrations or loud noises while driving can indicate the final failure of the tire. Reduce speed and stop; otherwise, pieces of the tire could come loose and cause an accident. Do not continue driving, and contact your service center.

# Intelligent Safety

## The concept

Depending on how the vehicle is equipped, Intelligent Safety consists of one or more of the following systems, which can help to avoid an imminent collision.

- Collision warning, refer to page 109.
- Pedestrian warning, refer to page 115.

- ▶ Lane departure warning, refer to page 120.
- Active Blind Spot Detection, refer to page 122

#### Note

Personal responsibility

The system does not serve as a substitute for the driver's personal judgment of the traffic situation.

Be aware of the traffic situation and the vehicle's surroundings at all times, otherwise an accident is still possible despite all warnings.

#### At a glance

#### **Button in the vehicle**





Intelligent Safety button

## Switching on/off

Some Intelligent Safety systems are automatically active after each engine start via the start/stop button.

Press the button:

A panel appears on the Control Display. Adjustments can be made. The individual settings are stored for the remote control currently in use.



Press the button briefly:

- Intelligent Safety systems are individually switched off according to individual setting.
- ▶ LED lights up orange or goes out depending on the individual setting.

Press the button again:

- All Intelligent Safety systems are switched on.
- The LED lights up green.



Hold the button down:

- All Intelligent Safety systems are switched off.
- > The LED goes out.

## **Collision warning**

Depending on how the equipment is equipped, the collision warning system consists of one of the following functions:

- Collision warning with City Braking function, refer to page 109.
- Collision warning with braking function, refer to page 112

# **Collision warning with City Braking function**

## The concept

The system can help to prevent accidents. If an accident cannot be prevented, the system helps to reduce the collision speed.

The system issues a warning if there is imminent danger of a collision and if so brakes independently.

The automatic braking intervention is done with limited force and duration.

The system is controlled via a camera in the base of the mirror.

The collision warning is available even if cruise control has been deactivated.


When the vehicle is intentionally brought close to a vehicle, the collision warning is delayed to avoid false warnings.

#### **General information**

The system issues a two-phase warning of a danger of collision with vehicles at speeds above approx. 3 mph/5 km/h. The time of these warnings may vary depending on the current driving situation.

Up to approx. 35 mph/60 km/h a braking intervention occurs when appropriate.

### **Detection range**



Vehicles are observed when they are traveling in the same direction of movement if they are located within the detection range of the system.

## At a glance

#### **Button in the vehicle**





Intelligent Safety button

#### Switching on/off

Some Intelligent Safety systems are automatically active after each engine start via the start/stop button.

**(** 

Press the button:

A panel appears on the Control Dis-

play. Adjustments can be made. The individual settings are stored for the remote control currently in use.



Press the button briefly:

- Intelligent Safety systems are individually switched off according to individual setting.
- ▶ LED lights up orange or goes out depending on the individual setting.

Press the button again:

- All Intelligent Safety systems are switched on.
- ▶ The LED lights up green.



Hold the button down:

- All Intelligent Safety systems are switched off.
- ▶ The LED goes out.

## **Setting the warning time**

The warning time can be set via iDrive.

These settings have no effect on the time of the warning when the system prompts the driver to intervene or brake.

- 1. "Settings"
- 2. "Frontal Coll. Warning"
- Activate the desired warning time on the Control Display.

If the vehicle is equipped with Night Vision with Dynamic Light Spot:

- 1. "Settings"
- "Intelligent Safety"
- 3. "Frontal Coll. Warning"
- Activate the desired warning time on the Control Display.

The selected channel is stored for the remote control currently in use.

### Warning with braking function

Adapting your speed and driving style
The warning does not relieve the driver
of the responsibility to adapt his or her driving
speed and style to the traffic conditions.

### **Display**

If a collision with a vehicle detected in this way is imminent, a warning symbol appears on the instrument cluster and in the Head-up Display.

#### Symbol Measure



The vehicle lights up red: prewarning.

Increase braking and distance.



The vehicle flashes red and an acoustic signal sounds: acute warning.

You are requested to intervene by braking or making an evasive maneuver.

## **Braking intervention**

The warning prompts the driver himself to intervene. During the warning, the maximum braking force is used, even with light pressure on the brake pedal. In addition, if there is a risk of collision, the system can assist with a slight braking intervention. The intervention can bring a vehicle traveling at slow speed to a complete stop.

The braking intervention is executed only if DSC Dynamic Stability Control is switched on and Dynamic Traction Control DTC is activated.

The braking intervention can be interrupted by pressing on the accelerator or by actively moving the steering wheel.

When towing or tow-starting the vehicle, switch off the collision warning with braking function to prevent undesired interventions.

### **System limits**

Be alert

Due to system limitations, warnings may be not be issued at all, or may be issued late or improperly. Therefore, always be alert and ready to intervene; otherwise, there is the danger of an accident occurring. ◄

#### **Detection range**

The system's detection capabilities are limited.

This may result in the warning not being issued or being issued late.

For example, the following situations may not be detected:

- Slow moving vehicles when you approach them at high speed.
- Vehicles that suddenly swerve in front of you or sharply decelerating vehicles.
- ▶ Vehicles with an unusual rear appearance.
- Two-wheeled vehicles ahead of you.
- Pedestrians.

#### **Functional limitations**

The system may not be fully functional in the following situations:

- In heavy fog, rain, sprayed water or snowfall.
- In tight curves.

- If the driving stability control systems are limited or deactivated, for example, DSC OFF.
- ▶ If the camera in the mirror or the radar sensor is dirty or obscured.
- During calibration of the camera immediately after vehicle shipment.
- If there is constant dimming because of oncoming light, for example, from the sun low in the sky.

#### **Prewarning sensitivity**

Depending on the set prewarning time, this may result in increased false warnings.

# Collision warning with braking function

#### The concept

The system issues a warning if there is imminent danger of a collision and also includes a braking function.

If the vehicle is equipped with Active Cruise Control with Stop & Go, the collision warning is controlled via the cruise control radar sensor in conjunction with a camera.


The collision warning is available even if cruise control has been deactivated.

When the vehicle is intentionally brought close to a vehicle, the collision warning is delayed to avoid false warnings.

#### **General information**

The system issues a two-phase warning of a possible danger of collision with vehicles at speeds above approx. 3 mph/5 km/h. The time of these warnings may vary depending on the current driving situation.

#### **Detection range**



It responds to stationary or moving objects that are within the detection range of the radar system.

### At a glance


#### **Button in the vehicle**





Intelligent Safety button


#### Radar sensor



The radar sensor is located in the lower area of the front bumper.

Always keep radar sensor clean and unobstructed.

#### Camera



The camera is located near the base of the mirror.

Keep the windshield in the area behind the interior rear view mirror clean and clear.

### Switching on/off

Some Intelligent Safety systems are automatically active after each engine start via the start/stop button.

Press the button:

A panel appears on the Control Display. Adjustments can be made. The individual settings are stored for the remote control currently in use.



Press the button briefly:

- Intelligent Safety systems are individually switched off according to individual setting.
- LED lights up orange or goes out depending on the individual setting.

Press the button again:

- All Intelligent Safety systems are switched on.
- ▶ The LED lights up green.



Hold the button down:

- All Intelligent Safety systems are switched off.
- The LED goes out.

#### Setting the warning time

The warning time can be set via iDrive.

These settings have no effect on the time of the warning when the system prompts the driver to intervene or brake.

- 1. "Settings"
- 2. "Frontal Coll. Warning"
- Activate the desired warning time on the Control Display.

If the vehicle is equipped with Night Vision with Dynamic Light Spot:

- 1. "Settings"
- 2. "Intelligent Safety"
- 3. "Frontal Coll. Warning"
- 4. Activate the desired warning time on the Control Display.

The selected channel is stored for the remote control currently in use.

#### **Display**

#### **Warning stages**

### **Prewarning**

This warning is issued, for example, when there is the impending danger of a collision or the distance to the vehicle ahead is too small.

#### Acute warning with braking function

Warning of the imminent danger of a collision when the vehicle approaches another object at a relatively high differential speed.

The acute warning prompts the driver to intervene and, if there is the danger of a collision, is accompanied by a braking intervention.

The braking intervention may be executed with maximum braking force and for a brief period only as necessary.

The intervention can bring the vehicle to a complete stop.

The braking intervention is executed only if DSC Dynamic Stability Control is switched on and Dynamic Traction Control DTC is activated.

Above approx. 130 mph/210 km/h, the braking intervention occurs as a brief braking pressure. No automatic delay occurs.

Adapting your speed and driving style
The warning does not relieve the driver
of the responsibility to adapt his or her driving
speed and style to the traffic conditions.

The braking intervention can be interrupted by pressing on the accelerator or by actively moving the steering wheel.

When towing or tow-starting the vehicle, switch off the collision warning with braking function to prevent undesired interventions.

## Display in the instrument cluster

The collision warning can be issued in the instrument cluster, in the Head-up Display, and acoustically.

### Warning stages

## Symbol Measure



The vehicle lights up red: prewarning.

Increase distance.



The vehicle flashes red and an acoustic signal sounds: acute warning.

You are requested to intervene by braking or making an evasive maneuver.

Adapting your speed and driving style
The display does not relieve the driver of
the responsibility to adapt his or her driving
speed and style to the traffic conditions.

#### **System limits**

lack

Be alert

Due to system limitations, warnings may be not be issued at all, or may be issued late or improperly. Therefore, always be alert and ready to intervene; otherwise, there is the danger of an accident occurring. ◄

#### **Detection range**

The system's detection capabilities are limited.

This may result in the warning not being issued or being issued late.

For example, the following situations may not be detected:

- Slow moving vehicles when you approach them at high speed.
- Vehicles that suddenly swerve in front of you or sharply decelerating vehicles.
- Vehicles with an unusual rear appearance.
- ▶ Two-wheeled vehicles ahead of you.
- Pedestrians.

#### **Functional limitations**

The system may not be fully functional in the following situations:

- In heavy fog, rain, sprayed water or snowfall.
- In tight curves.
- If the driving stability control systems are limited or deactivated, for example, DSC OFF.
- ▶ If the camera in the mirror or the radar sensor is dirty or obscured.
- During calibration of the camera immediately after vehicle shipment.
- If there is constant dimming because of oncoming light, for example, from the sun low in the sky.

### **Prewarning sensitivity**

Depending on the set prewarning time, this may result in increased false warnings.

# **Pedestrian warning**

Depending on how the vehicle is equipped, the function warns of an imminent collision with pedestrians during daytime or nighttime.

The function is subdivided into the following systems:

- During daytime: Pedestrian warning with city braking function, refer to page 115
- At night: Night Vision with pedestrian detection, refer to page 117

# Pedestrian warning with city braking function

#### The concept

The system can help to prevent accidents with pedestrians.

The system issues a warning in the city driving speed area if there is imminent danger of a collision with pedestrians and includes a braking function.


The system is controlled via the camera in the base of the interior mirror.

#### **General information**

The system issues a warning with brightness staring at approx. 6 mph/10 km/h to approx. 35 mph/60 km/h regarding a possible risk of collision with pedestrians and assists with a brake intervention shortly before a collision.

It responds to persons that are within the detection range of the system.

#### **Detection range**



The warning area in front of the vehicle is divided into two areas.

- Central area, arrow 1, directly in front of the vehicle.
- Expanded area, arrow 2, to the right and left.

A collision is imminent if pedestrians are located within the central area. A warning is issued about pedestrians who are located within the extended area only if they are moving in the direction of the central area.

## At a glance

#### Button in the vehicle





Intelligent Safety button

#### Camera



The camera is located near the base of the mirror.

Keep the windshield in the area behind the interior rear view mirror clean and clear.

### Switching on/off

### Switching on automatically

The system is automatically active every time the engine is started using the Start/Stop button.

## Switching off



Each time a button is pressed a panel is displayed on the Control Display.

Adjustments can be made. The individual settings are stored for the remote control currently in use.

Press the button briefly:

- Intelligent Safety systems are individually switched off according to individual setting.
- The LED lights up orange.

Press the button again:

- All Intelligent Safety systems are switched on.
- The LED lights up green.

Hold the button down:

- All Intelligent Safety systems are switched off.
- The LED goes out.

### Warning with braking function

Adapting your speed and driving style
The warning does not relieve the driver
of the responsibility to adapt his or her driving
speed and style to the traffic conditions.

### **Display**

If a collision with a person detected in this way is imminent, a warning symbol appears on the instrument cluster and in the Head-up Display.



The red symbol is displayed and a signal sounds.

Intervene immediately by braking or making an evasive maneuver.

#### **Braking intervention**

The warning prompts the driver himself to intervene. During the warning, the maximum braking force is used, even with light pressure on the brake pedal. In addition, if there is a risk of collision, the system can assist with a slight braking intervention. The intervention can bring a vehicle traveling at slow speed to a complete stop.

The braking intervention is executed only if DSC Dynamic Stability Control is switched on and Dynamic Traction Control DTC is activated.

The braking intervention can be interrupted by pressing on the accelerator or by actively moving the steering wheel.

When towing or tow-starting the vehicle, switch off the pedestrian warning to prevent undesired interventions.

## **System limits**

A Be alert

Due to system limitations, warnings may be not be issued at all, or may be issued late or improperly. Therefore, always be alert and ready to intervene; otherwise, there is the danger of an accident occurring. ◄

#### **Detection range**

The detection capability of the camera is limited.

This may result in the warning not being issued or being issued late.

For example, the following situations may not be detected:

- Partially covered pedestrians.
- Pedestrians that are not detected as such because of the viewing angle or contour.
- Pedestrians outside of the detection range.
- Pedestrians below a body size of approx.
   32 in/80 cm.

#### **Functional limitations**

The system may not be fully functional or may not be available in the following situations:

- In heavy fog, rain, sprayed water or snowfall.
- In tight curves.
- If the camera view field or the front windshield are dirty or covered.
- When driving toward bright lights.
- Up to 10 seconds after the start of the engine, via the Start/Stop knob.
- During calibration of the camera immediately after vehicle shipment.

# Night Vision with Pedestrian and Animal Detection

## The concept

Night Vision with pedestrian and animal detection is a night vision system.

An infrared camera records the area in front of the vehicle and issues a warning if it detects pedestrians and animals on the street. Warm objects that are similar in shape to human beings or animals are detected by the system. If necessary, the heat image can be displayed on the Control Display.

#### **Heat image**



The image shows the heat radiated by objects in the field of view of the camera.

Warm objects have a light appearance and cold objects, a dark appearance.

The ability to detect an object depends on the temperature difference between the object and the background and on the level of heat radiation emitted by the object. Objects that are similar in temperature to the environment or that radiate very little heat are difficult to detect.

For safety reasons, when driving at speeds above approx. 3 mph/5 km/h and in low ambient light, the image is only displayed when the low beams are switched on.

A still image is displayed at regular intervals for a fraction of a second.

### **Pedestrian and animal detection**



Object detection and warning only functions in darkness.

Warm objects that are similar in shape to human beings are detected by the system.

In addition, the system also detects animals above a certain minimum size, e.g., deer.

With heat image activated on the Control Display:

People detected by the system are displayed with a slight yellow hue.

Animals detected by the system are displayed in a darker yellow.

Under good ambient conditions, the object detection operates within the following distance ranges:

- Pedestrian detection: up to approx.330 ft/100 m
- Detection of large animals: up to approx.
   490 ft/150 m
- Detection of medium animals: up to approx. 230 ft/70 m

Environmental influences can limit the availability of object detection.

If the vehicle systems detect that the vehicle is located in a residential area, the animal detection is temporarily switched off.

#### **Notes**

Personal responsibility

Night Vision cannot replace the driver's personal judgment of the visibility conditions and the traffic situation. The view ahead and the actual visibility conditions must always be the basis on which the vehicle speed is adjusted; otherwise, there is a risk to road safety.◀

### At a glance

#### **Buttons in the vehicle**






Intelligent Safety button





Switch on/switch off heat image

#### Camera



The camera is automatically heated when the external temperatures are low.

The camera is automatically cleaned together with the headlamps.

### Switching on/off

## Switching on automatically

Every time the engine is started using the Start/Stop button, the system is automatically active at dark.

## Switching on/off manually



Press button: a panel appears on the Control Display. Adjustments can be

made. The individual settings are stored for the remote control currently in use.

Press the button briefly:

- Intelligent Safety systems are individually switched off according to individual setting.
- ▶ The LED lights up orange.

Press the button again:

- All Intelligent Safety systems are switched on.
- The LED lights up green.

Hold the button down:

- All Intelligent Safety systems are switched off.
- ▶ The LED goes out.

## Switching on heat image additionally

The heat image from the Night Vision camera can also be displayed on the Control Display. This function has no effect on object detection.



Press the button.

The image from the camera is displayed on the Control Display.

## Adjustments via the iDrive

With heat image switched on:

- Press the controller.
- 2. Select brightness or contrast.
  - Select the symbol.

- Select the symbol.
- Turn the controller until the desired setting is reached, and press the controller.


#### **Display**

# Warning of people or animals in danger

If a collision with a person or an animal detected in this way is imminent, a warning symbol appears on the instrument cluster and in the Head-up Display.

Although both the shape and the heat radiation are analyzed, false warnings cannot be ruled out.

#### Warning area in front of the vehicle



The warning area for the pedestrian warning consists of two parts:

- Central area, arrow 1, directly in front of the vehicle.
- Expanded area, arrow 2, to the right and left.

In the animal warning, no distinction is made between the central or expanded area.

The entire area moves along with the vehicle in the direction of the steering angle and changes with the vehicle speed. As the vehicle speed increases, the area becomes longer and wider, for example.

#### **Prewarning**



The yellow symbol is displayed when a person is detected in the central area, arrow 1, immediately in front of the ve-

hicle.

The yellow symbol is displayed when a person in the extended area, arrow 2, is moving from the right or left towards the central area.

The displayed symbol can vary with the people detected.

Intervene actively by braking or making an evasive maneuver.



When animals are detected, an animal symbol is displayed. The symbol also shows the side of the road on which

the animal was detected. Intervene actively by braking or making an evasive maneuver.

#### **Acute warning**



The red symbol is displayed and a signal sounds.

Intervene immediately by braking or making an evasive maneuver.

With animals no acute warning occurs.

### **Display in the Head-up Display**



The warning is displayed simultaneously in the Head-up Display and on the instrument cluster. The displayed

symbol can vary with the people detected.

When animals are detected, an animal symbol is displayed.

## **System limits**

#### **Basic limits**

System operation is limited in situations such as the following:

On steep hills, in steep depressions or in tight curves.

- When the camera is dirty or the protective glass is damaged.
- ▶ In heavy fog, rain or snowfall.
- At very high external temperatures.

# Limits of pedestrian and animal detection

In some situations, it may occur that pedestrians are detected as animals or animals as pedestrians.

Small animals are not detected by the object detection function, even if they are clearly visible in the image.

Limited detection:

- People or animals who are fully or partially covered, especially when their heads are covered.
- People who are not in an upright position, e.g., lying down.
- Cyclists on unconventional bicycles (e.g., recumbent bicycles).
- After physical damage to the system, e.g., after an accident.

## No display on the rear screen

The image from Night Vision with people detection cannot be displayed on the rear screen.

# Lane departure warning

## The concept

Starting at a specific speed, this system alerts you when the vehicle on streets with lane markings is about to leave the lane. Depending on the country-specific version of the vehicle, the speed is between 35 mph/55 km/h and 45 mph/70 km/h. If the system is switched on below this speed, a message appears in the instrument cluster.

The steering wheel begins vibrating gently in the event of warnings. The time of the warning

may vary depending on the current driving situation.

The system does not provide a warning if the turn signal is set before leaving the lane.

#### **Notes**

Personal responsibility
The system cannot serve as a substitute for the driver's personal judgment of the

course of the road and the traffic situation. In the event of a warning, do not jerk the steering wheel, as you may lose control of the vehi-

## At a glance

cle.◀

#### **Button in the vehicle**





Intelligent Safety button

#### Camera



The camera is located near the base of the mirror.

Keep the windshield in the area behind the interior rear view mirror clean and clear.

#### Switching on/off

Some Intelligent Safety systems are automatically active after each engine start via the start/stop button.

Press the button:
A panel appears on the Control Dis-

play. Adjustments can be made. The individual settings are stored for the remote control currently in use.



Press the button briefly:

- Intelligent Safety systems are individually switched off according to individual setting.
- ▶ LED lights up orange or goes out depending on the individual setting.

Press the button again:

- All Intelligent Safety systems are switched on.
- The LED lights up green.



Hold the button down:

- All Intelligent Safety systems are switched off.
- ▶ The LED goes out.

## Display in the instrument cluster



- Lines: system is activated.
- Arrows: at least one lane marking was detected and warnings can be issued.

## **Issued warning**

If you leave the lane and if a lane marking has been detected, the steering wheel begins vibrating.

If the turn signal is set before changing the lane, a warning is not issued.

#### **End of warning**

The warning ends:

- Automatically after approx. 3 seconds.
- When returning to your own lane.
- When braking hard.
- When using the turn signal.


### **System limits**

The system may not be fully functional in the following situations:

- In heavy fog, rain or snowfall.
- In the event of worn, poorly visible, merging, diverging, or multiple lane markings such as in construction areas.
- When lane markings are covered in snow, ice, dirt or water.
- In tight curves or on narrow lanes.
- When the lane markings are covered by objects.
- When driving very close to the vehicle in front of you.
- When driving toward bright lights.
- When the windshield in front of the interior rearview mirror is fogged over, dirty or covered with stickers, etc.
- During calibration of the camera immediately after vehicle shipment.

# **Active Blind Spot Detection**

#### The concept



Two radar sensors below the rear bumper monitor the area behind and next to the vehicle at speeds above approx. 30 mph/50 km/h.

The system indicates whether there are vehicles in the blind spot, arrow 1, or approaching from behind on the adjacent lane, arrow 2.

The lamp in the exterior mirror housing lights up dimly.

Before you change lanes after setting the turn signal, the system issues a warning in the situations described above.

The lamp in the housing of the exterior mirror flashes and the steering wheel vibrates.

#### Notes

A Personal responsibility
The system does not serve as a substi-

tute for the driver's personal judgment of the traffic situation.

Be aware of the traffic situation and the vehicle's surroundings at all times, otherwise an accident is still possible despite all warnings.◀

### At a glance

#### **Button in the vehicle**





Intelligent Safety button

#### Radar sensors



The radar sensors are located under the rear bumper.

## Switching on/off

Some Intelligent Safety systems are automatically active after each engine start via the start/stop button.



Press the button:

A panel appears on the Control Display. Adjustments can be made. The individual settings are stored for the remote control currently in use.



Press the button briefly:

 Intelligent Safety systems are individually switched off according to individual setting. LED lights up orange or goes out depending on the individual setting.

Press the button again:

- All Intelligent Safety systems are switched on.
- The LED lights up green.



Hold the button down:

- All Intelligent Safety systems are switched off.
- ▶ The LED goes out.

## **Display**



## Information stage

The dimmed lamp in the mirror housing indicates when there are vehicles in the blind spot or approaching from behind.

## Warning

If the turn signal is set while a vehicle is in the critical zone, the steering wheel vibrates briefly and the lamp in the mirror housing flashes brightly.

The warning stops when the turn signal is switched off, or the other vehicle leaves the critical zone.

## System limits

The system may not be fully functional in the following situations:

When a vehicle is approaching at a speed much faster than your own.

- In heavy fog, rain or snowfall.
- In tight curves or on narrow lanes.
- If the bumper is dirty or iced up, or covered with stickers.

A Check Control message is displayed when the system is not fully functional.

#### For US owners only

The transmitter and receiver units comply with part 15 of the FCC/Federal Communication Commission regulations. Operation is governed by the following:

#### FCC ID:

NBG009014A.

Compliance statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modifications or changes to these devices could void the user's authority to operate this equipment.

# **Brake force display**

## The concept



 During normal brake application, the outer brake lamps light up. During heavy brake application, the inner brake lamps light up in addition.

## **Active Protection**

#### **General information**

The Active Protection safety package consists of systems that are independent of each other:

- Attentiveness assistant.
- PreCrash
- PostCrash

#### Attentiveness assistant

#### The concept

The system can detect increasing lack of alertness or fatigue of the driver during long, monotonous journeys, for example, on highways. In this situation, it is recommended that the driver take a break.

#### Note

Personal responsibility

The system cannot act as a substitute for the personal assessment of one's physical state and may not detect an increasing lack of alertness or fatigue or may not detect it correctly. Therefore, make sure that the driver is rested and alert; otherwise, risks may be detected too late and an accident be caused as a result.

#### **Function**

The system is activated each time the engine is started and cannot be switched off.

After travel has begun, the system is trained about the driver, so that increasing lack of alertness or fatigue can be detected.

This procedure takes the following criteria into account:

- Personal driving style, for example, steering behavior.
- Driving conditions, for example, length of trip.

Starting at approximately 43 mph/70 km/h, the system is active and can display a recommendation to take a break.

#### **Break recommendation**

If the driver becomes increasingly less alert or fatigued, a message is displayed in the Control Display with the recommendation to take a break.

A recommendation to take a break is displayed only once during an uninterrupted trip.

After a break, another recommendation to take a break cannot be displayed until after approximately 45 minutes.

### **System limits**

The function may be limited in the following situations, for instance, and will either output an incorrect warning or no warning at all:

- When the clock is set incorrectly.
- When the vehicle speed is mainly below about 43 mph/70 km/h.
- With a sporty driving style, such as during rapid acceleration or when cornering quickly.
- In active driving situations, such as when changing lanes frequently.
- When the road surface is poor.
- In the event of strong side winds.

#### **PreCrash**

#### The concept

With this system critical driving situations that might result in an accident can be detected above a speed of approx. 20 mph/30 km/h. In these situations, preventative protection measures are automatically undertaken to

minimize the risk in the event of an accident as much as possible.

Critical driving situations may include:

- Full brake applications.
- Severe understeering.
- Severe oversteering.

If the vehicle includes the collision warning or collision warning with braking feature, impending collisions with vehicles driving ahead or stopped in front of you can also be detected within the system's range.

#### Note

Personal responsibility

The system cannot possibly serve as a substitute for the driver's personal judgment of the traffic situation. The system may not always detect critical situations reliably and in a timely manner. Adapt speed to traffic situation and drive alertly; otherwise, a risk to safety may result.

#### **Function**

After the safety belt is buckled, the front belts are automatically pretensioned once after the vehicle is driven is away.

In critical driving situations, the following individual functions become active as needed:

- ▶ The front belts are automatically pretensioned.
- Automatic closing of the windows.
- Automatic closing of the glass sunroof.
- For vehicles equipped with Comfort Seats: automatic positioning of the backrest for the front passenger seat.

After a critical driving situation without an accident, the front belts are loosened again. All other systems can be restored to the desired setting.

If the belt tension does not loosen automatically, stop the vehicle and unbuckle the belt using the red button in the buckle. Fasten the belt before continuing on your trip.

#### **PostCrash**

In the event of an accident, the system can bring the car to a halt automatically without intervention by the driver in certain situations. This can reduce the risk of a further collision and the consequences thereof.

Depressing the brake pedal can cause the vehicle to brake harder. This interrupts automatic braking. Depressing the accelerator pedal also interrupts automatic braking.

After coming to a halt, the brake is released automatically. Secure the vehicle against rolling.

# **Driving stability control systems**

# Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

# **Antilock Brake System ABS**

ABS prevents locking of the wheels during braking.

The vehicle remains steerable even during full brake applications, thus increasing active safety.

ABS is operational every time you start the engine.

## **Brake assistant**

When you apply the brakes rapidly, this system automatically produces the maximum braking force boost. This then reduces braking distance to a minimum during full braking. This system utilizes all of the benefits provided by ABS.

Do not reduce the pressure on the brake pedal for the duration of the full braking.

When equipped with Driving Assistant Plus or with Active Cruise Control with Stop & Go function, ACC is supported by the braking intervention if there is a possible risk of collision. To do this, the braking force is automatically increased if the braking pressure is insufficient when the brakes are applied.

## **Drive-off assistant**

This system supports driving away on gradients. The parking brake is not required.

- Hold the vehicle in place with the foot brake.
- 2. Release the foot brake and drive away without delay.

After the foot brake is released, the vehicle is held in place for approx. 2 seconds.

Depending on the vehicle load or when a trailer is being used, the vehicle may roll back slightly.

Priving off without delay

After releasing the foot brake, start driving without delay, since the drive-off assistant will not hold the vehicle in place for more than approx. 2 seconds and the vehicle will begin rolling back.

## **Automatic Differential Brake**

The system controls the driving force by automatic braking intervention on individual wheels. The function corresponds to a differential lock: the system detects if a wheel begins to spin, because of loose road surface, for example, and automatically brakes it.

The driving force is diverted to the wheel with better traction.

As a result, the engine force is transferred more efficiently to the wheels during accelerations.

# Dynamic Performance Control

The Dynamic Performance Control increases both the agility of the vehicle as well as the lane stability.

The system seamlessly handles the distribution of the drive torque between the two rear wheels.

Depending on the situation, the drive torque is shifted from the wheel on the inside of the curve to the wheel on the outside of the curve or vice-versa.

To increase the maneuverability, the rear wheel on the outside of the curve is accelerated when the driving style is correspondingly sporty.

The steering responds directly; simultaneously, the understeering tendency of the fourwheel drive is canceled out.

With the oversteering tendency, the system exerts a stabilizing effect by accelerating the rear wheel on the inside of the curve.

The system noticeably improves the traction and simultaneously increases the driving safety, especially on road surfaces having fluctuating coefficients of friction.

# DSC Dynamic Stability Control

## The concept

DSC prevents traction loss in the driving wheels when driving away and accelerating.

DSC also recognizes unstable vehicle conditions, such as fishtailing or nose-diving. Subject to physical limits, DSC helps to keep the vehicle on a steady course by reducing engine speed and by applying brakes at individual wheels.

Adjust your driving style to the situation An appropriate driving style is always the responsibility of the driver.

The laws of physics cannot be repealed, even with DSC.

Therefore, do not reduce the additional safety margin by driving in a risky manner. ◀

#### **Indicator/warning lamps**



The indicator lamp flashes: DSC controls the drive forces and brake forces.

The indicator lamp lights up: DSC has

failed.

## **Deactivating DSC: DSC OFF**

When DSC is deactivated, driving stability is reduced during acceleration and when driving in bends.

To increase vehicle stability, activate DSC again as soon as possible.

### **Deactivating DSC**



Press and hold the button, but not longer than approx. 10 seconds, until the

indicator lamp for DSC OFF lights up in the instrument cluster and DSC OFF is displayed.

The DSC system is switched off.

## **Activating DSC**



Press the button.

DSC OFF and the DSC OFF indicator lamp go out.

## **Indicator/warning lamps**

When DSC is deactivated, DSC OFF is displayed in the instrument cluster.



The indicator lamp lights up: DSC is deactivated.

# **DTC Dynamic Traction Control**

#### The concept

The DTC system is a version of the DSC in which forward momentum is optimized.

The system ensures maximum forward momentum on special road conditions, e.g., unplowed snowy roads, but driving stability is limited.

It is therefore necessary to drive with appropriate caution.

You may find it useful to briefly activate DTC under the following special circumstances:

- When driving in slush or on uncleared, snow-covered roads.
- When rocking the vehicle or driving off in deep snow or on loose surfaces.
- When driving with snow chains.

# Deactivating/activating DTC Dynamic Traction Control

Activating the Dynamic Traction Control DTC provides maximum traction on loose ground. Driving stability is limited during acceleration and when driving in bends.

## **Activating DTC**

Press the button.

TRACTION is displayed in the instru-

ment cluster and the indicator lamp for DSC OFF lights up.

## **Deactivating DTC**

Press the button again.

TRACTION and the DSC OFF indicator lamp go out.

## **Indicator/warning lamps**

When DTC is activated, TRACTION is displayed in the tachometer.



The indicator lamp lights up: DTC Dynamic Traction Control is activated.

#### **xDrive**

xDrive is the all-wheel-drive system of your vehicle. Concerted action by the xDrive and DSC further optimize traction and driving dynamics. The xDrive all-wheel-drive system variably distributes the drive forces to the front and rear axles as demanded by the driving situation and road surface.

#### **Display on the Control Display**

#### Displaying xDrive view

- 1. "Vehicle Info"
- "xDrive status"
- 3. A "xDrive view"

The following information is displayed:

- With Professional navigation system: compass display for the driving direction
- Pitch attitude with degree and percentage
- ▶ Transverse gradient with degree indication
- Graphic display for the steering

# Displaying distribution of the drive torque

- 1. "Vehicle Info"
- "xDrive status"
- 3. Torque distribution"

## **HDC Hill Descent Control**

## The concept

HDC is a downhill driving assistant that automatically controls vehicle speed on steep downhill gradients. Without applying the brakes, the vehicle moves at slightly more than walking speed.


Hill Descent Control can be activated at speeds below approx. 22 mph/35 km/h. When driving downhill, the vehicle reduces its speed to approx. walking speed and then keeps its speed constant.

As long as there is active braking, the system is on standby. The system does not brake the vehicle during this time.

Use HDC in low gears or in transmission position D or R only.

### Increasing or decreasing vehicle speed

Specify desired speed in the range from approx. 4 mph/6 km/h to approx. 15 mph/25 km/h using the rocker switch of the cruise control on the steering wheel. Vehicle speed can be changed by lightly accelerating.



- Press up the rocker switch to the point of resistance: the speed increases gradually.
- Press up the rocker switch past the point of resistance: the speed increases while the rocker switch is pressed.
- Press down the rocker switch to the point of resistance: the speed decreases gradually.
- Press down the rocker switch past the point of resistance: when driving forward, the speed decreases to approx. 6 mph/10 km/h; when reversing, the speed decreases to approx. 4 mph/6 km/h.

#### **Activating HDC**





Press the button: the LED above the button lights up.

#### **Deactivating HDC**



Press the button again and the LED goes out. HDC is automatically deactivated above approx. 37 mph/60 km/h.

## Display in the instrument cluster



The selected speed is displayed in the speedometer.

- Green: the system is actively braking the vehicle.
- Orange: the system is on standby.

#### Malfunction

A message is displayed in the instrument cluster. HDC is not available, e.g., due to elevated brake temperatures.

## **Active Steering**

Active Steering varies the steering angle of the wheels in relation to the steering wheel movement as a function of the speed.

At lower speeds, for example during turning or maneuvering, the steering angle is increased, that is to say the steering becomes more direct.

At higher speeds, the steering angle is increasingly reduced.

This enables even more precise handling at high speeds and more responsive steering with reduced steering angle at low speeds.

## **Dynamic Drive**

#### The concept

Dynamic Drive reduces the lateral inclination of the vehicle that occurs during rapid driving in curves or during quick evasive maneuvers.

Driving stability and driving comfort are increased under all driving conditions. The system utilizes active stabilizer bars on the front and rear axles that react immediately to all driving situations.

#### **Programs**

The system offers two different programs.

The programs can be selected via the Driving Dynamics Control, refer to page 131.

#### **SPORT**

Sporty tuning for greater driving agility.

#### COMFORT

Comfort-oriented tuning for optimal comfort.

# **Dynamic Damping Control**

### The concept

This system reduces undesirable vehicle motion when using a dynamic driving style or traveling on uneven road surfaces.

The system enhances driving dynamics and comfort as required for the road surface and driving style.

### **Programs**

The system offers several different programs.

The programs can be selected via the Driving Dynamics Control, refer to page 131.

#### SPORT/SPORT+

Consistently sporty control of the shock absorbers for greater driving agility.

#### **COMFORT/ECO PRO**

Balanced tuning.

# **Self-leveling suspension**

#### The concept

The self-leveling suspension keeps the vehicle height and ground clearance constant. The height of the vehicle at the rear axle is maintained at a predefined level under all load conditions.

The system ensures consistent comfort by keeping spring travel constant in all driving situations.

#### Malfunction

A Check Control message is displayed. A malfunction has occurred in the self-leveling suspension. Vehicle handling may be altered and driving comfort may be noticeably reduced. Visit your nearest service center.

## **Driving Dynamics Control**

## The concept

The Driving Dynamics Control can be used to adjust the driving dynamics of the vehicle. For this purpose various programs are available for selection that are activated via the two buttons of the Driving Dynamics Control and the DSC OFF-button.

### **Operating the programs**

Press the button	Program
<b>⊜</b> off	DSC OFF
ee	TRACTION
	SPORT+
Δ	SPORT
▽	COMFORT
	ECO PRO

#### **Automatic program change**

The system may automatically switch to COM-FORT in the following situations:

The vehicle has a flat tire.

#### **DSC OFF**

Driving stability is limited during acceleration and when driving in bends.

To increase vehicle stability, activate DSC again as soon as possible.

## **Deactivating DSC: DSC OFF**



Press and hold the button, but not longer than approx. 10 seconds, until the

indicator lamp for DSC OFF lights up in the instrument cluster and DSC OFF is displayed in the tachometer.

The DSC system is switched off.

## **Activating DSC**



Press the button.

DSC OFF and the DSC OFF indicator

lamp go out.

## **Indicator/warning lamps**

When DSC OFF is activated, DSC OFF is displayed in the tachometer.



The indicator lamp lights up: DSC OFF is activated.

#### **TRACTION**

Maximum traction on loose road surfaces. DTC Dynamic Traction Control is switched on. Driving stability is limited during acceleration and when driving in bends.

#### **Activating TRACTION**



Press the button.

TRACTION is displayed in the tach-

ometer.

The DSC indicator lamp in the instrument cluster lights up.

#### **Deactivating TRACTION**



Press the button again.

TRACTION and the DSC indicator

lamp go out.

#### **Indicator/warning lamps**

When TRACTION is activated, TRACTION is displayed in the tachometer.



The indicator lamp lights up: TRAC-TION is activated.

#### SPORT+

Sporty driving with optimized chassis and adapted engine control with limited driving stabilization.

Dynamic Traction Control is switched on.

The driver handles several of the stabilization tasks.

## **Activating SPORT+**



Press the button repeatedly until SPORT+ appears in the tachometer

and the DSC OFF indicator lamp lights up in the instrument cluster.

#### Automatic program change

When switching on the adjustable speed limit or activating cruise control, the program automatically switches to SPORT mode.

### **Indicator/warning lamps**

SPORT+ is displayed in the instrument cluster.



The DSC OFF indicator lamp lights up: Dynamic Traction Control is activated.

#### **SPORT**

Consistently sporty tuning of the suspension and engine control for greater driving agility with maximum driving stabilization.

The program can be configured to individual specifications.

The configuration is stored for the remote control currently in use.

#### **Activating SPORT**



Press the button repeatedly until SPORT appears in the tachometer.

#### **COMFORT**

For a balanced tuning with maximum driving stabilization.

## **Activating COMFORT**

goes out.

Press the button repeatedly until the program display in the tachometer

In certain situations, the system automatically changes to the NORMAL program, automatic program change, refer to page 132.

#### **ECO PRO**

ECO PRO, refer to page 196, provides consistent tuning to minimize fuel consumption for maximum range with maximum driving stabilization.

Comfort functions and the engine controller are adjusted.

The program can be configured to individual specifications.

### Activating ECO PRO



Press button repeatedly until ECO PRO is displayed in the instrument cluster.

#### **Configuring ECO PRO**

- Activate FCO PRO.
- "Configure ECO PRO"

Make the desired settings.

### Displays in the instrument cluster

#### Selected program



The selected program is displayed in the tachometer.

### **Program selection**



Pressing the button displays a list of the selectable programs.

## **Display on the Control Display**

Program changes can be displayed briefly on the Control Display.

To do so, make the following settings:

- "Settings"
- "Control display"
- "Driving mode info"

# **Driving comfort**

# Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

# Active Cruise Control with Stop & Go function, ACC

### The concept

This system can be used to select a desired speed that the vehicle will maintain automatically on clear roads.

To the extent possible, the system automatically adjusts the speed to a slower vehicle ahead of you.

The distance that the vehicle maintains to the vehicle ahead of you can be varied.

For safety reasons, it depends on the speed.

To maintain a certain distance, the system automatically decelerates, applies the brakes lightly, or accelerates again if the vehicle ahead begins moving faster.

If the vehicle ahead of you brakes to a halt, the system is able to detect this within the given system limits. If the vehicle ahead of your drives away again from a halt, your vehicle is able to accelerate if operated accordingly.

Even if some time passes before the vehicle drives away again, the BMW can still be accelerated automatically and simply.

As soon as the road is clear, it accelerates to the desired speed.

The speed is also maintained on downhill gradients, but may not be maintained on uphill slopes if engine power is insufficient.

#### **General information**

When ECO PRO is activated, cruise control is also set to a driving style that saves on fuel consumption.

#### **Notes**

Personal responsibility

The system does not relieve the driver of the responsibility to adapt his or her speed, distance and driving style to the traffic conditions. Drive attentively, and react to the current traffic events. Intervene actively when necessary, e.g., by braking, steering or making an evasive maneuver, otherwise, there is danger of an accident.

#### At a glance

#### **Buttons on the steering wheel**

Press the button	Function
FR	Cruise control on/off, interrupting, refer to page 135
SET	Store/maintain speed, refer to page 136
RES	Resume speed, refer to page 137
/ <del>*</del>	Adjust distance, refer to page 137
	Rocker switch: Change/maintain speed, refer to page 136
∠⊕∠	Congestion Assistant ON/OFF, Pause, refer to page 140

The arrangement of the buttons varies according to the how the vehicle is equipped or country-specific variants.

#### Radar sensor

A radar sensor is located in the front bumper for detecting vehicles on the road ahead of the vehicle.



A dirty or covered sensor may hinder the detection of vehicles.

- ▶ If necessary, clean the radar sensor. Remove layers of snow and ice carefully.
- Do not cover the view field of the radar sensor.

#### Camera



The camera is located near the base of the mirror.

Keep the windshield in the area behind the interior rearview mirror clean and clear.

# Switching on/off and interrupting cruise control

#### Switching on



Press the button on the steering wheel

The indicator lamps in the instrument cluster light up and the marking in the speedometer is set to the current speed.

Cruise control can be used.

### **Switching off**

Deactivated or interrupted system
If the system is deactivated or interrupted, actively intervene by braking, steering and, if necessary, with evasive maneuvers; otherwise, there is the danger of an accident occurring.

If switching off the system while stationary, press on the brake pedal at the same time.



Press the button on the steering wheel.

- If active: press twice.
- If interrupted: press once.

The displays go out. The stored desired speed and distance are deleted.

### Interrupting



Press the button on the steering wheel.

If interrupting the system while stationary, press on the brake pedal at the same time.

The system is automatically interrupted in the following situations:

- When the brakes are applied.
- When transmission position D is disengaged.
- When DTC Dynamic Traction Control is activated or DSC is deactivated.


- When DSC is actively controlling stability.
- If the safety belt and the driver's door are opened when the vehicle is standing still.
- If the system has not detected objects for an extended period, e.g., on a road with very little traffic without road edge line markings.
- ▶ If the detection range of the radar is disrupted, for example, by dirt or heavy fog.

### Maintaining/storing the speed

SET

Press the button.

Or:



Press the rocker switch while the system is interrupted.

When the system is switched on, the current speed is maintained and stored as the desired speed.

It is displayed in the speedometer and briefly displayed in the instrument cluster, Displays in the instrument cluster, refer to page 137.

When cruise control is maintained or stored, DSC Dynamic Stability Control is switched on, if necessary.

# Changing, maintaining, and storing the speed

The rocker switch can be pressed while the system is interrupted to maintain and store the current speed. DSC Dynamic Stability Control is switched on, if necessary.


Adapting the desired speed

Adapt the desired speed to the road conditions and be ready to brake at all times; otherwise, there is the danger of an accident occurring.

Speed differences

Large differences in speed relative to other vehicles cannot be compensated by the system for example in the following situations:

- When catching up rapidly with a truck.
- When another vehicle suddenly swerves into the wrong lane.
- When stationary objects are approached at speed.◄



Press the rocker switch up or down repeatedly until the desired speed is set.

If active, the displayed speed is stored and the vehicle reaches the stored speed if the road is clear.

- Each time the rocker switch is pressed to the point of resistance, the desired speed increases or decreases by approx.
   1 mph/1 km/h.
- Each time the rocker switch is pressed past the point of resistance, the desired speed increases or decreases by a maximum of 5 mph/10 km/h.

Hold the rocker switch in position to repeat the action.

#### **Distance**

Selecting a distance

Adjust the distance according to the traffic and weather conditions; otherwise, there is the danger of an accident occurring. Maintain the prescribed safety distance.

#### **Adjust distance**



Press the button repeatedly until the desired distance is set.

# Calling up the desired speed and distance

#### While driving



Press the button with the system switched on.

In the following cases, the stored speed value is deleted and cannot be called up again:

- When the system is switched off.
- When the ignition is switched off.

#### While standing



Before leaving the vehicle, secure it against rolling

Before leaving the vehicle with the engine running, engage position P of the automatic transmission and apply the parking brake. Otherwise, the vehicle may begin to roll. ◀

The system brought the vehicle to a complete standstill.

- Green marking in the speedometer: Your vehicle accelerates automatically as soon as the vehicle in the range of the radar sensor moves off.
- Marking in the speedometer turns orange: no automatic driving away.
  - To accelerate to the desired speed automatically, press the accelerator briefly or press the RES or SET button.

Rolling bars in the distance display indicate that the vehicle in the radar sensor detection range has moved off.

Your vehicle was braked to a halt by pressing on the brake pedal and it is standing behind another vehicle:

- 1. Press the button to call up a stored desired speed.
- 2. Release the brake pedal.
- Press on the accelerator briefly, or press the RES button or the rocker switch when the vehicle ahead of you drives away.

#### Displays in the instrument cluster

#### **Desired speed**



- ▶ The marking lights up green: the system is active.
- The marking lights up orange: the system has been interrupted.
- The marking does not light up: the system is switched off.

## Brief status display



Selected desired speed.

If --- appears briefly on the display for Check Control messages, it is possible that the system requirements for operation are currently not met.

## Distance to vehicle ahead of you

The selected distance to the vehicle driving ahead of you is shown.

#### Distance display



Distance 1



Distance 2



Distance 3



Distance 4

This value is set after the system is switched on.



The system has been interrupted or distance control is deactivated because the accelerator is being pressed; a vehicle was not detected.



Distance control is deactivated because the accelerator is being pressed; a vehicle was detected.

Rolling bars: the detected vehicle has driven away.

## **Indicator/warning lamps**

Personal responsibility
The indicator and warning lamps do not relieve the driver of the responsibility to adapt his or her desired driving speed and style to the traffic conditions.



The vehicle symbol lights up orange: A vehicle has been detected ahead of you.



The vehicle symbol flashes orange: The conditions are not adequate for operating the system.

The system was deactivated but applies the brakes until you actively assume control by pressing on the brake pedal or accelerator.



The vehicle symbol flashes red and an acoustic signal sounds:

You are requested to intervene by braking or making an evasive maneuver.

## **Displays in the Head-up Display**

The information from Active Cruise Control can also be displayed in the Head-up Display. Adjusting the Head-up Display, refer to page 158.

### **System limits**


### **Speed range**

Best results are achieved when using the system on well-developed roads and highways. The desired speed can be selected between 20 mph/30 km/h to 110 mph/180 km/h.

The system can also be activated when stationary.

Comply with the legal speed limit in every situation when using the system.

## **Detection range**



The detection capacity of the system and the automatic braking capacity are limited.

Two-wheeled vehicles for instance might not be detected.

Limited detection capacity

Because of the limits to the detection capacity of the camera and the sensor, you should be alert at all times so that you can in-


tervene actively, if necessary; otherwise, there is the danger of an accident occurring. ◀

#### **Deceleration**

The system does not decelerate for:

- Pedestrians or similar slow-moving road users.
- Red traffic lights.
- Cross traffic.
- Oncoming traffic.

### **Swerving vehicles**




A vehicle driving in front of you is not detected until it is completely within the same lane as your vehicle.

Swerving vehicles

If a vehicle driving ahead of you suddenly swerves into your lane, the system may not be able to automatically restore the selected distance. This also applies to major speed differences to vehicles driving ahead of you, e.g., when rapidly approaching a truck. When a vehicle driving ahead of you is reliably detected, the system requests that the driver intervene by braking and carrying out evasive maneuvers, if necessary. You must react yourself; otherwise, there is the danger of an accident occurring.

#### Cornering

speed.



If the desired speed is too high for a curve, the speed is reduced slightly in the curve, although curves cannot be anticipated in advance.

Therefore, drive into a curve at an appropriate

In tight curves, situations may result due to the restricted detection range of the system in which a vehicle driving ahead of you may not be detected at all, or not until after a considerable delay.



When approaching a curve, the system may react briefly to the vehicles in the next lane due to the bend of the curve. Any deceleration of the vehicle by the system can be compensated for by briefly accelerating. After the accelerator pedal is released, the system becomes active again and independently controls the speed.

## **Driving away**

In some situations, the vehicle cannot drive away automatically, e.g., on steep inclines or behind bumps in the road.

#### Radar sensor

#### For US owners only

The transmitter and receiver units comply with part 15 of the FCC/Federal Communication Commission regulations. Operation is governed by the following:

#### FCC ID:

OAYARS3-A

Compliance statement:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- This device may not cause harmful interference, and
- this device must accept any interference received, including interference that may cause undesired operation.

Any unauthorized modifications or changes to these devices could void the user's authority to operate this equipment.

#### Malfunction

The system cannot be activated if the radar sensor is not aligned correctly. This may be caused by damage incurred during parking, for example.

A Check Control message is displayed if the system fails.

The function for detecting and responding when approaching stationary vehicles may be limited in the following situation:

- During calibration of the camera immediately after vehicle shipment.
- If the camera is malfunctioning or dirty. A Check Control message is displayed.

# **Congestion Assistant**

### The concept

In congestion situations, the system controls the speed, steers independently and keeps the vehicle in the lane.

To the extent possible, the system automatically adjusts the speed to a slower vehicle ahead of you. The distance that the vehicle maintains to the vehicle ahead of you can be varied. For safety reasons, it depends on the speed. To maintain a certain distance, the system automatically decelerates, applies the brakes lightly, or accelerates again if the vehicle ahead begins moving faster.

When lane markings are detected, the system keeps the vehicle in the lane. For this purpose, the system steers independently as needed, for example, during cornering.

#### **General information**

The congestion assistant determines speed and distance from the vehicle in front via a radar sensor and the position of the lane marking via a camera.

Sensors on the steering wheel detect whether the steering wheel is being touched.

The system is deactivated as soon as contact with the steering wheel is no longer detected.

In order to be able to use the Congestion Assistant, place your hands around the steering wheel.

When driving with gloves or with protective covers, contact with the steering wheel cannot be detected by the sensors. The system in this case cannot be used.

#### Notes

Personal responsibility

The system does not relieve the driver of the responsibility to adapt his or her speed, distance and driving style to the traffic conditions. Drive attentively, and react to the current

traffic events. Intervene actively when necessary, e.g., by braking, steering or making an evasive maneuver, otherwise, there is danger of an accident.◀

#### **Functional requirements**

- Drive on approved road type. The data on this are stored in the navigation system.
- Driving on the limited access highway or divided lane roads.
- Sufficient lane width.
- Lane marking is detected.
- Vehicle driving ahead is detected.
- Speed below 25 mph/40 km/h.
- Both hands on the steering wheel rim.


### At a glance

## **Buttons on the steering wheel**

Press the button	Function
∠⊕∠	Congestion Assistant ON/OFF, Pause, refer to page 141.
	Rocker switch: Store, change/maintain speed, refer to page 136.
SET	Maintain, store speed, refer to page 136.
RES	Resume speed, refer to page 137.
/\$\	Adjust distance, refer to page 137.

#### Radar sensor

A radar sensor is located in the front bumper for detecting vehicles on the road ahead of the vehicle.



A dirty or covered sensor may hinder the detection of vehicles.

- ▶ If necessary, clean the radar sensor. Remove layers of snow and ice carefully.
- Do not cover the view field of the radar sensor.

#### Camera



The camera is located near the base of the mirror.

Keep the windshield in the area behind the interior rearview mirror clean and clear.

## Switching on/off and pausing

## Switching on



Press the button.

- Prepare system: press once.
- Activate system:

The system is automatically activated below 25 mph/40 km/h.

If the ACC is not activated: press wiper.

With ACC activated: system is ready.



If ACC is not activated: indicator lamp in the instrument cluster comes on.



If ACC is not activated: indicator lamp in the instrument cluster comes on.

Congestion Assistant can be used.

With Congestion Assistant switched on, the Pedestrian Warning system is active.

### **Switching off**

Deactivated or interrupted system
If the system is deactivated or interrupted, actively intervene by braking, steering and, if necessary, with evasive maneuvers; otherwise, there is the danger of an accident occurring.



Press the button.

The indicator goes out. Stored desired speed and distance are still kept by the ACC.

The system no longer steers independently.

### Interrupting



When active, press the button.

The system is automatically interrupted in the following situations:

- ▶ At a speed above 25 mph/40 km/h.
- With only one detected lane marking.
- When you leave the limited access highway.
- When you leave the divided lane road.
- When the steering wheel is released.
- When steering intervention is active.
- When you leave your own lane.
- With incorrect vehicle ahead.
- When the turn signal is on.



Red flashing and signal tone:

Congestion Assistant is interrupted. The system no longer steers independently. ACC exercises control.

If the system conditions are met, the system reactivates automatically.

#### **Distance**

Selecting a distance

Adjust the distance according to the traffic and weather conditions; otherwise, there is the danger of an accident occurring. Maintain the prescribed safety distance.

#### **Adjust distance**



Press the button repeatedly until the desired distance is set.

### Distance to vehicle ahead of you

The selected distance to the vehicle driving ahead of you is shown.

#### Distance display



Distance 1



Distance 2



Distance 3



Distance 4

This value is set after the system is switched on.

Selecting a distance

Adjust the distance according to the traffic and weather conditions; otherwise, there is the danger of an accident occurring. Maintain the prescribed safety distance.

## Displays in the instrument cluster

### Symbol Description



Congestion Assistant and Distance Control on standby.



Congestion Assistant on standby. Distance control controls within the set distance.



Congestion Assistant activated. The system controls the speed and assists with maintaining the lane.



Rolling bars: at least one functional requirement is no longer satisfied. The system soon deactivates the automatic steering. ACC on standby.



Red flashing and signal tone: congestion Assistant is interrupted. The system does not steer independently. ACC exercises control.

## **System limits**

When driving within narrow driving lanes, e.g., in construction zones or rescue lanes, the system cannot be activated or meaningfully used.

Limited detection capacity

Because of the limits to the detection capacity of the camera and the sensor, you should be alert at all times so that you can intervene actively, if necessary; otherwise, there is the danger of an accident occurring.◀

Complying with country-specific laws
When the Congestion Assistant is used,
observe specific national laws.

✓

#### Cruise control

#### The concept

The system is functional at speeds beginning at approx. 20 mph/30 km/h.

It maintains the speed that was set using the control elements on the steering wheel.

The system brakes on downhill gradients if engine braking action is insufficient.

Unfavorable conditions
Do not use the system if unfavorable
conditions make it impossible to drive at a constant speed, for instance:

- On curvy roads.
- In heavy traffic.
- On slippery roads, in fog, snow or rain, or on a loose road surface.

Otherwise, you could lose control of the vehicle and cause an accident. ◀

#### **General information**

When ECO PRO is activated, cruise control is also set to a driving style that saves on fuel consumption.

#### **Controls**

## At a glance

Press the button	Function
<b>්</b> ෆ	Cruise control on/off, interrupting, refer to page 144
SET	Store/maintain speed, refer to page 144
RES	Resume speed, refer to page 145
	Rocker switch: Change/maintain speed, refer to page 144

The arrangement of the buttons varies according to the how the vehicle is equipped or country-specific variants.

#### Switching on

The marking in the speedometer is set to the current speed.

The cruise control can be used.

### Switching off

Deactivated or interrupted system
If the system is deactivated or interrupted, actively intervene by braking and, if
necessary, with evasive maneuvers; otherwise,
there is the danger of an accident occurring.

- If active: press twice.
- If interrupted: press once.


The displays go out. The stored desired speed is deleted.

#### Interrupting

The system is automatically interrupted if:

- The brakes are applied.
- ▶ The transmission position D is disengaged.
- DTC Dynamic Traction Control is activated or DSC is deactivated.
- DSC is actively controlling stability.
- HDC is activated.

## Maintaining/storing the current speed



Press the rocker switch while the system is interrupted.

When the system is switched on, the current speed is maintained and stored as the desired speed.

It is displayed in the speedometer and briefly displayed in the instrument cluster, Displays in the speedometer, refer to page 145.


When cruise control is maintained or stored, DSC Dynamic Stability Control is switched on, if necessary.

### **Changing/maintaining speed**

The rocker switch can be pressed while the system is interrupted in order to maintain and store the current speed.

Adapting the desired speed

Adapt the desired speed to the road conditions and be ready to brake at all times; otherwise, there is the danger of an accident occurring.



Press the rocker switch up or down repeatedly until the desired speed is set.

If active, the displayed speed is stored and the vehicle reaches the stored speed if the road is clear.

- Each time the rocker switch is pressed to the point of resistance, the desired speed increases or decreases by approx.
   1 mph/1 km/h.
- Each time the rocker switch is pressed past the point of resistance, the desired speed increases or decreases by a maximum of 5 mph/10 km/h.

Max. adjustable speed: 140 mph/230 km/h.

Pressing the rocker switch to the resistance point and holding it there accelerates or decelerates the vehicle without requiring pressure on the accelerator. After the rocker switch is released, the vehicle maintains its final speed. Pressing the switch beyond the resistance point causes the vehicle to accelerate more rapidly.

## Resuming the desired speed



Press the button.

The stored speed is reached and maintained.

# Displays in the instrument cluster

#### **Indicator lamp**



Depending on how the vehicle is equipped, the indicator lamp in the instrument cluster indicates whether the system is switched on.

# **Desired speed**



- The marking lights up green: the system is active.
- The marking lights up orange: the system has been interrupted.
- The marking does not light up: the system is switched off.

# **Brief status display**



Selected desired speed.

If --- appears briefly on the display for Check Control messages, it is possible that the system requirements for operation are currently not met.

# PDC Park Distance Control

### The concept

PDC supports you when parking. Objects that you are approaching slowly in front of or behind your vehicle are indicated by:

- Signal tones.
- Visual display.

#### General information

Measurements are made by ultrasound sensors in the bumpers.

The range is approx. 6 ft/2 m.

An acoustic warning is first given:

- By the front sensors and the two rear corner sensors at approx. 24 in/60 cm.
- By the rear middle sensors at approx. 5 ft/1.50 m.

#### **Notes**



PDC cannot serve as a substitute for the driver's personal judgment of the traffic situation. Check the traffic situation around the vehicle with your own eyes. Otherwise, an accident could result from road users or objects located outside of the PDC detection range.

Loud noises from outside and inside the vehicle may prevent you from hearing the PDC's signal tone. ◀



Avoid driving quickly with PDC Avoid approaching an object quickly.

Avoid driving away quickly while PDC is not yet active.

For technical reasons, the system may otherwise be too late in issuing a warning. ◀

### At a glance

#### **Button in the vehicle**





PDC Park Distance Control

# Switching on/off

# Switching on automatically

PDC switches on automatically in the following situations:

- If the engine is running, select transmission position R.
- If obstacles are detected by the PDC behind or, with the appropriate equipment, also in front of the vehicle.

Automatic activation when obstacles are detected can be switched off:

- 1. "Settings"
- "Parking"
- 3. Select the setting.

The setting is stored for the remote control currently in use.

# Automatic deactivation during forward travel

The system switches off when a certain driving distance or speed is exceeded.

Switch the system back on if necessary.

# Switching on/off manually



Press the button.

- On: the LED lights up.
- Off: the LED goes out.

In addition to the PDC Park Distance Control, the rearview camera, refer to page 148, can be switched on.

# Switching on the rearview camera via the iDrive

With PDC activated or Top View switched on:

Rar view camera"

The rearview camera image is displayed. The setting is stored for the remote control currently in use.

# **Display**

## Signal tones

When approaching an object, an intermittent tone is sounded that indicates the position of the object. For example, if an object is detected to the left rear of the vehicle, a signal tone sounds from the left rear speaker.

The shorter the distance to the object becomes, the shorter the intervals.

If the distance to a detected object is less than approx. 10 in/25 cm, a continuous tone is sounded.

If objects are located both in front of and behind the vehicle, an alternating continuous signal is sounded.

The intermittent tone is interrupted after approx. 3 seconds:

- If the vehicle stops in front of an object that is detected by only one of the corner sensors.
- If moving parallel to a wall.

The signal tone is switched off:

- ▶ When the vehicle moves away from an object by more than approx. 4 in/10 cm.
- When transmission position P is engaged.

#### Volume

The volume of the PDC signal can be adjusted, refer to user's manual for Navigation, Entertainment, Communication.

The setting is stored for the remote control currently in use.

#### **Visual warning**

The approach of the vehicle to an object can be shown on the Control Display. Objects that are farther away are displayed on the Control Display before a signal tone sounds.

A display appears as soon as Park Distance Control (PDC) is activated.

The range of the sensors is represented in the colors red, green and yellow.

If the rearview camera image was selected last, it again appears on the display. To switch to PDC:

- Rear view camera" Select the symbol on the Control Display.
- 2. Press the controller.

The setting is stored for the remote control currently in use.

#### **Active Park Distance Control**

## The concept

Active Park Distance Control assists the driver while parking by braking the vehicle automatically when it approaches an obstacle.

The system is available below walking speed in transmission position D or R. Have the vehicle roll during parking without pressing the accelerator pedal.

Pressing the gas pedal reduces or interrupts the braking assistance.

When a collision is imminent, the system automatically brakes the vehicle until it comes to a stop.

After automatic braking to a stop, further creeping toward an obstacle is possible. To

creep toward the obstacle, lightly press the gas pedal and release it again.

If the gas pedal is heavily depressed, the vehicle drives off as usual. Manual braking is possible at any time.

# **General information**

Active Park Distance Control uses the ultrasound sensors of PDC and park assistant.

Interactions with DSC:

- ▶ When DSC is switched off, the automatic brake assist is deactivated.
- If while DSC is switched off the Active Park Distance Control is switched on, DSC is also activated.

#### Note

Personal responsibility

The active Park Distance Control does not exempt the driver from personal responsibility during parking.

Watch the parking space and parking procedure closely, drive slowly and intervene if necessary; otherwise, there is the danger of an accident.◄

# **Activating system**

With PDC activated:

(1) "Active PDC"

To switch it off, select the menu item again or switch off the PDC.

The setting is stored for the remote control currently in use.

# System limits

#### Limits of ultrasonic measurement

The detection of objects can reach the physical limits of ultrasonic measurement, e.g.:

- With tow bars and trailer hitches.
- With thin or wedge-shaped objects.

- With low objects.
- With objects with corners and sharp edges.

Low objects already displayed, e.g., curbs, can move into the blind area of the sensors before or after a continuous tone sounds.

High, protruding objects such as ledges may not be detected.

### **False warnings**

PDC may issue a warning under the following conditions even though there is no obstacle within the detection range:

- In heavy rain.
- When sensors are very dirty or covered in ice.
- When sensors are covered in snow.
- On rough road surfaces.
- In large buildings with right angles and smooth walls, e.g., in underground garages.
- In heavy exhaust.
- Due to other ultrasound sources, e.g., sweeping machines, high pressure steam cleaners or neon lights.

#### Malfunction

A Check Control message is displayed.

The range of the sensors is shown as a shaded area on the Control Display.

PDC has failed. Have the system checked.

To ensure full operability:

- Keep the sensors clean and free of ice.
- When using high-pressure washers, do not spray the sensors for long periods and maintain a distance of at least 12 in/30 cm.

# **Surround View**

# The concept

Surround View comprises various camera assistance systems that help the driver when parking, maneuvering, and at complex exits and intersections.

- Rearview camera, refer to page 148
- Top View, refer to page 151.
- ▶ Panorama View, refer to page 153.

# **Backup camera**

## The concept

The backup camera provides assistance in parking and maneuvering backwards. The area behind the vehicle is shown on the Control Display.

#### **Hints**

Check the traffic situation as well
Check the traffic situation around the vehicle with your own eyes. Otherwise, an accident could result from road users or objects located outside the picture area of the backup camera.

# At a glance


#### **Button in the vehicle**





Rearview camera

#### Camera



The camera lens is located in the handle of the trunk lid. The image quality may be impaired by dirt.

Clean the lens, refer to page 238.

# Switching on/off

# Switching on automatically

Select transmission position R with the engine running.

The backup camera image is displayed if the system was switched on via the iDrive.

# Automatic deactivation during forward travel

The system switches off when a certain driving distance or speed is exceeded.

Switch the system back on if necessary.

# Switching on/off manually



Press the button.

- On: the LED lights up.
- Off: the LED goes out.

The PDC is shown on the Control Display.

# Switching on the rearview camera via the iDrive

With PDC activated or Top View switched on:

R¬ "Rear view camera"

The rearview camera image is displayed. The setting is stored for the remote control currently in use.

# **Display on the Control Display**

# **Functional requirement**

- The rearview camera is switched on.
- The tailgate is fully closed.

## **Activating the assistance functions**

More than one assistance function can be active at the same time.


- Parking aid lines
  - "Parking aid lines"

Pathway and turning circle lines are displayed.

- Obstacle marking
  - Pa "Obstacle marking"


Spatially-shaped markings are displayed.

# **Pathway lines**



- Can be shown in the rearview camera image when in transmission position R.
- Help you to estimate the space required when parking and maneuvering on level roads.
- Are dependent on the current steering angle and are continuously adjusted to the steering wheel movements.


# **Turning circle lines**



- Can be shown in the rearview camera image.
- Show the course of the smallest possible turning circle on a level road.
- Only one turning circle line is displayed when the steering wheel is turned.

## **Obstacle marking**

#### **General information**



Spatially-shaped markings can be shown in the rearview camera image.

Their colored steps match the markings of the PDC. This simplifies estimation of the distance to the object shown.

# **Obstacle marking in Surround View**

- Objects behind the vehicle are detected by the rearview camera and the PDC sensors and displayed in the Control Display.
- Obstacle marking is automatically activated when the rearview camera is active and reverse gear is engaged.


- The objects are marked by colored rectangles. The color of the mark depends on the distance of the objects from the vehicle.
- ▶ The range of object detection is no more than 16 ft/5 m.




Yellow symbol is displayed if the obstacle marking is not possible.

# Parking using pathway and turning circle lines

 Position the vehicle so that the turning circle lines lead to within the limits of the parking space.



Turn the steering wheel to the point where the pathway line covers the corresponding turning circle line.



# **Display settings**

# **Brightness**

With the rearview camera switched on:

- 1. Select the symbol.
- Turn the controller until the desired setting is reached, and press the controller.

#### **Contrast**

With the rearview camera switched on:

- 2. Turn the controller until the desired setting is reached, and press the controller.

## **System limits**

## **Detection of objects**

High, protruding objects such as ledges may not be detected by the rearview camera.

The objects displayed in the Control Display under certain circumstances are closer than they appear. Therefore, do not estimate the distance from the objects on the display.

# **Top View**

# The concept

Top View assists you in parking and maneuvering. The area around the vehicle is shown on the Control Display.

#### **General information**

The image is captured by two cameras integrated in the exterior mirrors, by the rearview camera and a camera on the front of the vehicle.

The range is no more than approx. 10 ft/3 m to the side, front and rear.

Obstacles within this range are thus displayed early on the Control Display.

#### Notes

Check the traffic situation as well
Check the traffic situation around the vehicle with your own eyes. Otherwise, an accident could result from road users or objects located outside the picture area of the cameras.

## At a glance

#### Button in the vehicle





Top View

#### **Cameras**



The lenses of the Top View cameras are located at the bottom of the exterior mirror housings. The image quality may be impaired by dirt.

Clean the lens, refer to page 238.

# **Functional requirements**

Top View can be used only to a limited extent in the following situations:

- With a door open.
- With the tailgate open.
- With an exterior mirror folded in.
- In poor light.

The unavailable camera range is depicted with cross-hatching.

# Switching on/off

# Switching on automatically

Select transmission position R with the engine running.

The Top View and PDC images are displayed if the system is switched on via iDrive.

# Automatic deactivation during forward travel

The system switches off when a certain driving distance or speed is exceeded.

Switch the system back on if necessary.

# Switching on/off manually



Press the button.

- ▷ On: the LED lights up.
- Off: the LED goes out.

Top View is displayed.

# Switching on the backup camera via the iDrive

With Top View switched on:

Ra "Rear view camera"

The backup camera image is displayed. The setting is stored for the remote control currently in use.

# **Display**

## Visual warning

The approach of the vehicle to an object can be shown on the Control Display.



The display appears as soon as Top View is activated.

If the rearview camera image was selected last, it again appears on the display when reverse gear is selected. To switch to Top View:

"Rear view camera" Select the symbol on the Control Display.

The setting is stored for the remote control currently in use.

# **Brightness**

With Top View switched on:

- Select the symbol.
- 2. Turn the controller until the desired setting is reached, and press the controller.

#### **Contrast**

With Top View switched on:

- Select the symbol.
- 2. Turn the controller until the desired setting is reached, and press the controller.

# Displaying the turning circle and pathway lines

- The static, red turning circle line shows the space needed to the side of the vehicle when the steering wheel is turned all the way.
- The variable, green pathway line assists you in assessing the amount of space actually needed to the side of the vehicle.

The pathway line is dependent on the current steering angle and is continuously adjusted with the steering wheel movement.

"Parking aid lines"


Turning circle and pathway lines are displayed.

#### **System limits**

A Check Control message is displayed when a camera is defective.

# **Panorama View**

# The concept



Panorama View provides an early look at cross traffic at blind driveways and intersections. Road users concealed by obstacles to the left and right of the vehicle can only be detected relatively late from the driver's seat. To improve the viewing, each camera, front and rear on the vehicle, detects the traffic area on the side.

Which camera is active is shown on the top edge of the screen.

#### Hints

The images of the cameras are displayed, depending on the gear selected, on the Control Display.

Check the traffic situation as well
Check the traffic situation around the vehicle on blind driveways and intersections with your own eyes. Otherwise, an accident could result from road users or objects located out-

side the picture areas of the Panorama View cameras. ◀

## At a glance

#### **Button in the vehicle**





Panorama View

#### **Cameras**



Front camera



Rear camera

Two cameras are used for the detection. The image quality may be impaired by dirt. Clean the lens, refer to page 238.

## Switching on/off

# Switching on/off manually



Press the button.

Depending on the transmission position, the picture of the front or rear camera is displayed.

# With navigation system: switching on automatically

Front Panorama View switches on automatically if the vehicle approaches a saved activation point.

Saving activation points, refer to page 154.

# Switching off automatically

By switching into a different function or when changing gears.

Front Panorama View: when a certain driving distance or speed is exceeded.

# **Display**

### **General information**

The traffic area in front of or behind the vehicle is displayed on the Control Display.

# **Brightness**

With Panorama View switched on:

- 1. Select the symbol.
- 2. Turn the controller until the desired setting is reached, and press the controller.

#### **Contrast**

With Panorama View switched on:

- 1. Select the symbol.
- Turn the controller until the desired setting. is reached, and press the controller.

# With navigation system: activation points

## The concept

Positions, at which the system is to switch on automatically, can be saved as activation points if a GPS signal is received.

Up to ten activation points can be stored.

Activation points are only possible for the front camera.

# **Storing**

- Move toward the position at which the system is to be switched on.
- 2. Press the button.
- 3. Add activation point" Select the symbol on the Control Display.
- "Save activation point"

Activation point is saved and when the appropriate equipment is available, displayed in the split screen.

Activation points are, if possible, stored with town/city and street address or with a sequential number.

# **Deletina**

- - Press the button.
- 2. 

  □ "Show activation points" Select a symbol.

A list of all activation points is displayed.

- 3. Select an activation point.
- 4. "Delete activation point" or "Delete all activation points"
- 5. "OK"

Activation points can also be deleted in the Options menu.

# System limits


The objects displayed in the Control Display under certain circumstances are closer than

they appear. Therefore, do not estimate the distance from the objects on the display.

The viewing angle is approx. 180°.

# **Parking assistant**

## The concept



This system assists the driver in parking parallel to the road.

Ultrasound sensors measure parking spaces on both sides of the vehicle.

The parking assistant calculates the best possible parking line and takes control of steering during the parking procedure.

When parking, also take note of the visual and acoustic information issued by the PDC and the parking assistant and react accordingly.

A component of the parking assistant is the PDC Park Distance Control, refer to page 145.

#### **Hints**

Personal responsibility

The parking assistant does not relieve the driver of responsibility for the vehicle during the parking procedure.

Watch the parking space and parking procedure closely and intervene if necessary; otherwise, there is the danger of an accident. ◄

Changes to the parking space
Changes to the parking space after it was measured are not taken into account by the system.

Therefore, always be alert and ready to intervene; otherwise, there is the danger of an accident occurring. ◀

Transporting loads

Loads that extend beyond the perimeter of the vehicle are not taken into account by the system during the parking procedure.

Therefore, always be alert and ready to intervene; otherwise, there is the danger of an accident occurring. ◀

Curbs

The parking assistant may steer the vehicle over or onto curbs.

Therefore, always be alert and ready to intervene; otherwise, the wheels, tires, or the vehicle may become damaged. ◀

An engine that has been switched off by the Auto Start Stop function is restarted automatically when the parking assistant is activated.

# Requirements

# For measuring parking spaces

- Maximum speed while driving forward approx. 22 mph/35 km/h.
- Maximum distance to row of parked vehicles: 5 ft/1.5 m.

# Suitable parking space

- ▶ Gap between two objects with a minimum length of approx. 5 ft/1.5 m.
- Minimum length of the gap: own vehicle's length plus approx. 4 ft/1.2 m.
- Minimum depth: approx. 5 ft/1.5 m.

# For parking procedure

- Closed doors.
- Parking brake released.

## At a glance

#### **Button in the vehicle**



Parking assistant

#### **Ultrasound sensors**



The ultrasound sensors for measuring parking spaces are located on the wheel arches.

To ensure full operability:

- Keep the sensors clean and free of ice.
- When using high-pressure washers, do not spray the sensors for long periods and maintain a distance of at least 12 in/30 cm.

# Switching on/off

# Switching on with the button



Press the button.

The LED lights up.

The current status of the parking space search is indicated on the Control Display.

Parking assistant is activated automatically.

# Switching on with reverse gear

Shift into reverse.

The current status of the parking space search is indicated on the Control Display.

Activate:  $^{P}_{\Theta}$  "Parking Assistant" Select the symbol in the Control Display.

# **Switching off**

The system can be deactivated as follows:



Press the button.

Switch off the ignition.

# **Display on the Control Display**

## **Activating/deactivating the system**

# Symbol Meaning



Gray: the system is not available. White: the system is available but

not activated.

•ିବ

The system is activated.

# Status of the system



- Colored symbols, see arrows, on the side of the vehicle representation. Parking assistant is activated and search for parking space active.
- Suitable parking spaces are displayed next to the vehicle symbol at the edge of the road as on the Control Display. When the parking assistant is active, suitable parking spaces are highlighted.



The parking procedure is active. Steering control has been seized.

Parking space search is always active whenever the vehicle is moving forwards slow and straight, even if the system is deactivated. When the system is deactivated, the displays on the Control Display are shown in gray.

## Parking using the parking assistant

Check the traffic situation as well
Loud sounds outside and within the vehicle can drown out the signal tones of the parking assistant and PDC.

Check the traffic situation around the vehicle with your own eyes; otherwise, there is the danger of an accident. ◀

- Switch on the parking assistant and activate it if necessary.
  - The status of the parking space search is indicated on the Control Display.
- Follow the instructions on the Control Display.

To achieve the best possible parking position, wait for the automatic steering wheel movement after the gear change when the vehicle is stationary.

- The end of the parking procedure is indicated on the Control Display.
- Adjust the parking position yourself if necessary.

# Interrupting manually

The parking assistant can be interrupted at any time:

- ▶ Parking Assistant" Select the symbol on the Control Display.
- Press the button.

# Interrupting automatically

The system is interrupted automatically in the following situations:

- ▶ If the driver grasps the steering wheel or if he takes over steering.
- ▶ If a gear is selected that does not match the instruction on the Control Display.
- ▶ If a turn signal is activated in the opposite direction to the desired side for parking.
- If the vehicle speed exceeds approx.6 mph/10 km/h.
- On snow-covered or slippery road surfaces if necessary.
- If doors are open.
- ▶ If the trunk lid is open.
- When there are obstacles that are hard to overcome, such as curbs.
- When there are obstacles that suddenly arise.
- ▶ If a maximum number of parking attempts or the time taken for parking is exceeded.

A Check Control message is displayed.

## Continuing

An interrupted parking procedure can be continued if necessary.

Follow the instructions on the Control Display to do this.

# System limits

# No parking assistance

The parking assistant does not offer assistance in the following situations:

- In tight curves.
- When towing a trailer.

#### **Functional limitations**

The system may not be fully functional in the following situations:

- When sensors are dirty or iced over.
- ▶ In heavy fog, rain or snowfall.
- On bumpy road surfaces such as gravel roads.

- On slippery ground.
- On steep uphill or downhill grades.
- When leaves or snow has collected in the parking space.

#### Limits of ultrasonic measurement

The detection of objects can reach the physical limits of ultrasonic measurement, e.g., in the following circumstances:

- With tow bars and trailer hitches.
- With thin or wedge-shaped objects.
- With elevated, protruding objects such as ledges or cargo.
- With objects with corners and sharp edges.
- With objects with a fine surface structure, such as fences.

Low objects already displayed, e.g., curbs, can move into the blind area of the sensors before or after a continuous tone sounds.

High, protruding objects such as ledges may not be detected.

The parking assistant may identify parking spaces that are not suitable for parking.

#### Malfunction

A Check Control message is displayed.

The parking assistant failed. Have the system checked.

# **Head-up Display**

### The concept



This system projects important information into the driver's field of vision, e.g., the speed. In this way, the driver can get information without averting his or her eyes from the road.

# **Display visibility**

The visibility of the displays in the Head-up Display is influenced by:

- Certain sitting positions.
- Objects on the cover of the Head-up Display.
- Sunglasses with certain polarization filters.
- Wet roads.
- Unfavorable light conditions.

If the image is distorted, check the basic settings.

# Switching on/off

- 1. "Settings"
- 2. "Head-Up Display"
- 3. "Head-Up Display"

# **Display**

#### Overview

- Speed.
- Navigation system.
- Check Control messages.
- Collision warning.

- Speed limit detection.
- Cruise control.
- Distance information.
- Congestion Assistant.
- Pedestrian warning.
- Selection list from the instrument cluster.

Some of this information is only displayed briefly as needed.

# Selecting displays in the Head-up Display

- 1. "Settings"
- 2. "Head-Up Display"
- 3. "Displayed information"
- 4. Select the desired displays in the Head-up Display.

The settings are stored for the remote control currently in use.

#### **Setting the brightness**

The brightness is automatically adjusted to the ambient light.

The basic setting can be adjusted manually.

- "Settings"
- 2. "Head-Up Display"
- 3. "Brightness"
- 4. Turn the controller.

When the low beams are switched on, the brightness of the Head-up Display can be additionally influenced using the instrument lighting.

The setting is stored for the remote control currently in use.

# Adjusting the height

- 1. "Settings"
- 2. "Head-Up Display"
- 3. "Height"
- 4. Turn the controller.

The setting is stored for the remote control currently in use.

# **Setting the rotation**

- 1. "Settings"
- 2. "Head-Up Display"
- 3. "Rotation"
- Turn the controller.

The setting is stored for the remote control currently in use.

# **Special windshield**

The windshield is part of the system.

The shape of the windshield makes it possible to display a precise image.

A film in the windshield prevents double images from being displayed.

Therefore, have the special windshield replaced by a service center only.

# **Distance information**

# The concept

The system displays a symbol in the Head-up Display to indicate that the distance behind the vehicle in front is not sufficient.

#### **General information**

The distance is determined by the radar sensor of the Active Cruise Control.

#### Hints


Personal responsibility

The display does not relieve the driver of the responsibility to adapt his or her distance and driving style to the traffic conditions. Maintain the prescribed safety distance.

# At a glance

#### Radar sensor

A radar sensor is located in the front bumper for detecting vehicles on the road ahead of the vehicle



A dirty or covered sensor may hinder the detection of vehicles.

- If necessary, clean the radar sensor. Remove layers of snow and ice carefully.
- Do not cover the view field of the radar sensor.

# **Switching on**

- Switching on Head-Up Display, refer to page 158.
- 2. "Distance info": Select the indication in the Head-Up Display, refer to page 158.

# Display in the Head-up Display



The symbol is displayed when the distance from the vehicle traveling ahead is too short.

# **Functional requirements**

- Active Cruise Control switched off.
- Display in the Head-up Display selected.
- Distance too short for longer than about 2 seconds.
- Speed greater than approx. 40 mph/70 km/h.

#### Malfunction

The system cannot be activated if the radar sensor is not aligned correctly. This may be caused by damage incurred during parking, for example.

A Check Control message is displayed if the system fails.


# **Climate control**

# Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equip-

ment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

# **Automatic climate control**



- 1 Air distribution, left
- 2 Temperature, left
- 3 AUTO program, left
- 4 Air flow, AUTO intensity, left, residual heat
- 5 Remove ice and condensation
- 6 Maximum cooling
- 7 Display
- 8 Air volume, AUTO intensity, right
- 9 AUTO program, right
- 10 Temperature, right

- **11** Air distribution, right
- **12** Seat heating, right 52
- 13 Active seat ventilation, right 52
- 14 Automatic recirculated-air control/recirculated-air mode
- 15 Cooling function
- 16 Rear window defroster
- 17 SYNC program
- **18** Active seat ventilation, left 52
- **19** Seat heating, left 52

#### Climate control functions in detail

#### Manual air distribution



Press the button repeatedly to select a program:

- Upper body region.
- Upper body region and footwell.
- Footwell.
- Windows and footwell.
- Windows, upper body region, and footwell.
- Windows: driver's side only.
- Windows and upper body region.

If the windows are fogged over, press the AUTO button on the driver's side to utilize the condensation sensor.

#### **Temperature**



Turn the wheel to set the desired temperature.

The automatic climate control achieves this temperature as quickly as possible, if necessary with the maximum cooling or heating capacity, and then keeps it constant.

Avoid rapidly switching between different temperature settings. Otherwise, the automatic climate control will not have sufficient time to adjust the set temperature.

# **AUTO** program

Press the button.

Air volume, air distribution, and temperature are controlled automatically.

Depending on the selected temperature, the AUTO intensity, and outside influences, the air is directed to the windshield, side windows, upper body, and into the footwell.

The cooling function, refer to page 163, is switched on automatically with the AUTO program.

At the same time, a condensation sensor controls the program so as to prevent window condensation as much as possible.

#### Intensity of the AUTO program

With the AUTO program switched on, automatic control of the air flow and air distribution can be adjusted.



Press the left or right side of the button: decrease or increase the inten-

sity.

The selected intensity is shown on the display of the automatic climate control.

## Air flow, manual

To be able to manually adjust the air flow, switch off the AUTO program first.



Press the left or right side of the button: decrease or increase air flow.

The selected air flow is shown on the display of the automatic climate control.

The air flow of the automatic climate control may be reduced automatically to save battery power.

# Defrosting windows and removing condensation

Press the button.

lce and condensation are quickly removed from the windshield and the front side windows.

The air volume can be adjusted when the program is active.

If the windows are fogged over, you can also switch on the cooling function or press the AUTO button to utilize the condensation sensor.

# **Maximum cooling**

Press the button.

The system is set to the lowest temperature, maximum air flow and air circulation mode.

Air flows out of the vents for the upper body region. The vents need to be open for this.

Air is cooled as quickly as possible:

- At an external temperature of approx. 32 °F/0 °C.
- ▶ When the engine is running.

The air volume can be adjusted when the program is active.

#### Automatic recirculated-air control/ recirculated-air mode

You can respond to unpleasant odors or pollutants in the immediate environment by temporarily suspending the supply of outside air. The system then recirculates the air currently within the vehicle.



Press the button repeatedly to select an operating mode:

- ▶ LEDs off: outside air flows in continuously.
- Left LED on, automatic recirculated-air control: a sensor detects pollutants in the outside air and controls the shutoff automatically.
- Right LED on, recirculated-air mode: the supply of outside air into the vehicle is permanently blocked.

If the windows are fogged over, switch off the recirculated-air mode and press the AUTO button on the driver's side to utilize the condensation sensor. Make sure that air can flow onto the windshield.

Continuous recirculated-air mode
The recirculated-air mode should not be used for an extended period of time, as the air quality inside the vehicle deteriorates steadily.

#### **Cooling function**

The passenger compartment can only be cooled with the engine running.

A/C Press the button.

The air is cooled and dehumidified and – depending on the temperature setting – warmed again.

Depending on the weather, the windshield may fog up briefly when the engine is started.

The cooling function is switched on automatically with the AUTO program.

When using the automatic climate control, condensation water, refer to page 190, develops that exits underneath the vehicle.

#### Rear window defroster

Press the button.

The rear window defroster switches off automatically after a certain period of time.

## **SYNC** program

SYNC

The current settings on the driver's side for temperature, air flow, air distri-

bution, and AUTO program are transferred to the front passenger side and to the left and right rear.

The program is switched off if the settings on the front passenger side or in the rear are changed.

#### **Residual heat**

The heat stored in the engine is used to heat the interior.

#### **Functional requirement**

- Up to 20 minutes after the engine has been switched off.
- Warm engine.
- ▶ The battery is sufficiently charged.
- External temperature below 77 °F/25 °C.

#### Switching on

- 1. Switch off the ignition.
- 2. Press the right side of the button on the driver's side.

The symbol appears on the automatic climate Control Display.

The interior temperature, air volume and air distribution can be adjusted with the ignition switched on.

#### **Switching off**


At the lowest fan speed, press the left side of the button on the driver's side.

The symbol on the display of the automatic climate control flashes.

# Switching the system on/off

#### **Switching off**

Complete system:



On the front passenger side:



Press and hold the left button on the front passenger side.

## **Switching on**

Press any button except:

- SYNC program.
- Rear window defroster.
- Left side of Air volume button.
- Seat heating.
- Seat ventilation.

#### Microfilter/activated-charcoal filter


The microfilter removes dust and pollen from the incoming air.

The activated-charcoal filter removes gaseous pollutants from the outside air that enters the vehicle.

This combined filter should be replaced during scheduled maintenance, refer to page 220, of your vehicle.

# **Ventilation**

#### Front ventilation



Thumbwheels to vary the temperature, arrow 1.

Toward blue: colder.

Toward red: warmer.


- Lever for changing the air flow direction, arrow 2.
- Thumbwheels for opening and closing the vents continuously, arrows 3.

# Adjusting the ventilation

Ventilation for cooling:
 Adjust the vent to direct the air in your direction, e.g., if the vehicle interior is hot from the sun.

Draft-free ventilation:
 Adjust the vent to let the air flow past you.

# Ventilation in rear, center




Thumbwheels to vary the temperature, arrow 1.

Toward blue: colder.

Toward red: warmer.

- Lever for changing the air flow direction, arrow 2.
- Thumbwheels for continuous opening and closing of the vents, arrow 3.

#### **Lateral ventilation**



- Thumbwheel for opening and closing the vents continuously, arrow 1.
- Lever for changing the air flow direction, arrow 2.

# Heating and ventilation, third row of seats

The air in the area of the third row of seats can be heated or circulated. The vents are located in the storage area between the seats and in the footwell of the third row of seats.



- Thumbwheel for the activation of the heat and distribution of the air, arrow 1.
  - Turn toward the front: activate the heater and distribute the air in the footwell.
  - Turn toward the rear: distribute the air in the storage area between the seats.
- Button for switching on the fan, arrow 2nd LED comes on.

The heater is not ready for operation without switching on the fan. After the heater is switched off, the fan can be used to circulate the interior air, e.g., at high temperatures. To do this, turn the thumbwheel, arrow 1 toward the rear and switch on the fan. arrow 2.

# Rear automatic climate control

# At a glance



- Temperature
- 2 AUTO program
- 3 Vent settings
- 4 Air volume, AUTO intensity

- 5 Display
- 6 Maximum cooling
- 7 Seat heating 54

# Switching the rear automatic climate control on/off

- 1. "Settings"
- 2. "Climate"
- "Rear climate control"

The rear automatic climate control is not operational if the automatic climate control is switched off or if the function for defrosting or defogging the windows is active.

## **AUTO** program

Press the button.

Air volume, air distribution, and temperature are controlled automatically:

Depending on the selected temperature, the AUTO intensity, and outside influences, the air is directed to the upper body and into the footwell.

The cooling function is switched on automatically with the AUTO program.

# **Intensity of the AUTO program**

With the AUTO program switched on, automatic control of the air volume and air distribution can be adjusted.



Press the left or right side of the button: decrease or increase the inten-

sity.

The selected intensity is shown on the display of the automatic climate control.

## **Temperature**



Turn the wheel to set the desired temperature.

The automatic climate control achieves this temperature as quickly as possible, if necessary with the maximum cooling or heating capacity, and then keeps it constant.

Avoid rapidly switching between different temperature settings. The automatic climate control will not have sufficient time to adjust the set temperature.

#### Manual air distribution

The air distribution can be adjusted to individual needs.



Press the button repeatedly to select a program:

- Upper body region.
- Upper body region and footwell.
- Footwell.

# Air volume, manual

To be able to manually adjust the air volume, switch off the AUTO program first.



Press the left or right side of the button: decrease or increase air volume.

The selected air volume is shown on the display of the automatic climate control.

# Switching the system on/off

# **Switching off**



Press and hold the left button.

# Switching on

Press any button except:

Left side of Air volume button.

Seat heating.

mode.

# **Maximum cooling**

The system is set to the lowest temperature, maximum air flow and air circulation

Air flows out of the vents for the upper body region. Open them for this purpose.

Air is cooled as quickly as possible:

Press the button.

- At an external temperature of approx. 32 °F/0 °C.
- ▶ When the engine is running.

# Parked-car ventilation/ heating

#### The concept

The parked-car ventilation ventilates the vehicle interior and lowers its temperature, if necessary.

The parked-car heating warms the vehicle interior, making snow and ice easier to remove. With the ignition switched off, the air is automatically routed to the windshield, to the side windows, and into the footwell.

The systems can be switched on and off directly or by using two preset departure times.

The switch-on time is automatically determined based on the temperature. The systems promptly switch on before the selected departure time.

Operation takes place on the iDrive or the remote control.

#### Note

Parked-car heating in enclosed areas
Do not operate the parked-car heating in
enclosed areas, as breathing of the harmful exhaust fumes may lead to loss of consciousness
and death. The exhaust gases contain carbon

monoxide, an odorless and colorless but highly toxic gas. Switch off the parked-car heating when refueling. ◄

At external temperatures below 32 °F/0 °C, water vapor occurs that emerges from below the vehicle.

## **Functional requirements**

#### Parked-car ventilation

- With remote control or when the departure time is preselected: depends on internal, external and set temperature.
- Direct operation via iDrive: any external temperature.
- In direct mode via remote control: external temperature above approx. 59 °F/15 °C.

Open the vents to allow air to flow out.

#### Parked-car heating


- With remote control or when the departure time is preselected: depends on internal, external and set temperature.
- Direct operation via iDrive: any external temperature.
- In direct mode via remote control: external temperature below approx. 59 °F/15 °C.
- ▶ The battery is sufficiently charged.
- ▶ The fuel tank is filled to above the reserve range.

If the parked-car heating has not been used for several months, it may be necessary to switch the system on again after several minutes.

# Switching on/off directly

- 1. "Settings"
- 2. "Climate"
- "Activate ind. heating" or

"Activate comf. ventilation"



The symbol on the automatic climate control flashes if the system is switched on.

The system continues to run for some time after being switched off.

# Preselecting the departure time

- 1. "Settings"
- 2. "Climate"
- 3. "Dep. time 1:" or "Dep. time 2:"
- Set the desired time.


# Activating the departure time

- 1. "Settings"
- 2. "Climate"
- "Activate depart. time 1" or "Activate depart. time 2"
- ★ The symbol on the automatic climate control flashes when the system has been switched on.

The system will only be switched on within the next 24 hours. After that, it needs to reactivated.

#### Remote control

#### At a glance



- **1** Display
- 2 Selection buttons
- 3 OK
- 4 MENU

#### **Buttons**

Press the button	Function
>	Decrease or increase the selection.
MENU	Press briefly: - Switch on remote control Switch menu. Press and hold down: - Switch off remote control.
ОК	Confirm the selection.

# **Symbols**

Symbols	Meaning
277	Parked-car ventilation/heating
1 <sup>⊕</sup>	Timer 1.
2 <sup>©</sup>	Timer 2.

Symbols	Meaning
(p)	Radio reception.
<b>111</b> )	Remote control battery indicator.
F	Parked-car ventilation/heating fault.
	Tank contents too low.
Ž	Vehicle battery charging state too low.
W	No radio reception.

# Switching on



Press button briefly until the display lights up.

The last menu opened is displayed.

# **Switching off**



Press for approx. 2 seconds until the display is switched off.

If no entry is made for 10 seconds, the display shuts off automatically.

#### Select menu

The following menus can be selected via the remote control.

- Parked-car ventilation/heating
- ▶ 1<sup>®</sup> Timer 1
- > 2<sup>™</sup> Timer 2



Press the button repeatedly until the desired menu is displayed.

# **Activating/deactivating the functions**

Several menu items are preceded by a checkbox. It indicates whether the function is activated or deactivated. Selecting the menu item activates or deactivates the function.

The function is activated.

The function is deactivated.

# Parked-car ventilation/heating

#### **Activating**

- Select menu.
- 2. Press button to activate parked-car ventilation/heating.

#### **Deactivating**

- Select menu.
- 2. Press button to deactivate parked-car ventilation/heating.

#### **Timer**

Two timers can be set with different times.

Only one timer can ever be activated.

#### **Activating**

- 1. Select Timer 1 or Timer 2.
- 2. Press the button to set the hour.
- 3. Press the button.
- 4. Press the button to set the minute.
- 5. Press the button twice to activate the timer.

### **Deactivating**

- Select desired timer.
- 2. Press the button to deactivate the timer.

# Remote control range

The reception-dependent average range is approx. 490 ft/150 m.

The range is greatest if the remote control is kept horizontally toward the front.

### **Frequencies**

The remote control may not function properly if it experiences interference from other systems or devices that use the same frequency.

# Replacing the batteries

Replace the batteries if a check control message is displayed or the battery indicator flashes.

No rechargeable batteries

Do not use rechargeable batteries, as
damage may result from the substances in the
batteries.

✓



- Use a suitable object to unclip the battery compartment, arrow 1.
- Remove the cover of the battery compartment; see arrow 2.
- 3. Insert batteries of the same type.
- Press the cover closed.



Take the used battery to a recycling center or to your service center.

#### Malfunction

F The symbol indicates that there is a fault in the parked-car ventilation/heating. Have the system checked by the service center.

# **Interior equipment**

# Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

# Integrated universal remote control

# The concept

The integrated universal remote control can operate up to 3 functions of remote-controlled systems such as garage door drives or lighting systems. The integrated universal remote control replaces up to 3 different hand-held transmitters. To operate the remote control, the buttons on the interior rearview mirror must be programmed with the desired functions. The hand-held transmitter for the particular system is required in order to program the remote control.

During programming

During programming and before activating a device using the integrated universal remote control, ensure that there are no people, animals, or objects in the range of movement of the remote-controlled device; otherwise, there is a risk of injury or damage.

Also follow the safety instructions of the handheld transmitter. ◄

Before selling the vehicle, delete the stored functions for the sake of security.

## Compatibility



If this symbol is printed on the packaging or in the instructions of the system to be controlled, the system is gener-


ally compatible with the integrated universal remote control.

If you have any questions, please contact:

- Your service center.
- www.homelink.com on the Internet.

HomeLink is a registered trademark of Johnson Controls, Inc.

# Controls on the interior rearview mirror



- LED, arrow 1.
- Buttons, arrow 2.
- ▶ The hand-held transmitter, arrow 3, is required for programming.

# **Programming**

#### General information

- 1. Switch on the ignition.
- Initial setup:

Press and hold the left and right button on the interior rearview mirror simultaneously for approximately 20 seconds until the LED on the interior rearview mirror flashes. This erases all programming of the buttons on the interior rearriew mirror.

- 3. Hold the hand-held transmitter for the system to be controlled approx. 1 to 3 in/2.5 to 8 cm away from the buttons on the interior rearview mirror. The required distance depends on the manual transmitter.
- 4. Simultaneously press and hold the button of the desired function on the hand-held transmitter and the button to be programmed on the interior rearview mirror. The LED on the interior rearview mirror will begin flashing slowly.
- Release both buttons as soon as the LED flashes more rapidly. When the LED is flashing faster, this indicates that the button on the interior rearview mirror has been programmed.

If the LED does not flash faster after at least 60 seconds, change the distance between the interior rearview mirror and the hand-held transmitter and repeat the step. Several more attempts at different distances may be necessary. Wait at least 15 seconds between attempts.

Canada: if programming with the handheld transmitter was interrupted, hold down the interior rearview mirror button and repeatedly press and release the hand-held transmitter button for 2 seconds.

6. To program other functions on other buttons, repeat steps 3 to 5.

The systems can be controlled using the interior rearview mirror buttons.

# Special feature of the alternatingcode wireless system

If you are unable to operate the system after repeated programming, please check if the system to be controlled features an alternating-code system.

Read the system's operating manual, or press the programmed button on the interior rear-

view mirror longer. If the LED on the interior rearview mirror starts flashing rapidly and then stays lit constantly for 2 seconds, the system features an alternating-code system. Flashing and continuous illumination of the LED will repeat for approximately 20 seconds.

For systems with an alternating-code system, the integrated universal remote control and the system also have to be synchronized.

Please read the operating manual of the system being set up for information on how to synchronize the system.

Synchronizing is easier with the aid of a second person.

#### To synchronize:

- Park the vehicle within range of the remote-controlled system.
- Program the relevant button on the interior rearview mirror as described.
- Locate and press the synchronizing button on the system being programmed. You have approx. 30 seconds for the next step.
- 4. Hold down the programmed button on the interior rearview mirror for approximately 3 seconds and then release it. If necessary, repeat this work step up to three times in order to finish synchronization. Once synchronization is complete, the programmed function will be carried out.

# Reprogramming individual buttons

- 1. Switch on the ignition.
- 2. Press and hold the interior rearview mirror button to be programmed.
- As soon as the interior rearview mirror LED starts flashing slowly, hold the hand-held transmitter for the system to be controlled approx. 1 to 3 in/2.5 to 8 cm away from the buttons on the interior rearview mirror. The required distance depends on the manual transmitter.

- Likewise, press and hold the button of the desired function on the hand-held transmitter.
- Release both buttons as soon as the interior rearview mirror LED flashes more rapidly. When the LED is flashing faster, this indicates that the button on the interior rearview mirror has been programmed.
   The system can then be controlled by the button on the interior rearview mirror.

If the LED does not flash faster after at least 60 seconds, change the distance and repeat the step. Several more attempts at different distances may be necessary. Wait at least 15 seconds between attempts.

Canada: if programming with the handheld transmitter was interrupted, hold down the interior rearview mirror button and repeatedly press and release the hand-held transmitter button for 2 seconds.

#### Controls

Before operation

Before operating a system using the integrated universal remote control, ensure that there are no people, animals, or objects within the range of movement of the remotecontrolled system; otherwise, there is a risk of injury or damage.

Also follow the safety instructions of the handheld transmitter. ◀

The system, such as the garage door, can be operated using the button on the interior rearview mirror while the engine is running or when the ignition is started. To do this, hold down the button within receiving range of the system until the function is activated. The interior rearview mirror LED stays lit while the wireless signal is being transmitted.

# **Deleting stored functions**

Press and hold the left and right button on the interior rearview mirror simultaneously for ap-

proximately 20 seconds until the LED flashes rapidly. All stored functions are deleted. The functions cannot be deleted individually.

# **Ashtray**

#### Front

# **Opening**



Slide the cover forward.

## **Emptying**

Take out the insert.

#### Rear

# **Opening**



Press on the cover.

# **Emptying**

Take out the insert.

# Lighter

#### **Hints**

Danger of burns

Only hold the hot lighter by its knob; otherwise, there is the danger of getting burned.

Switch off the ignition and take the remote

Switch off the ignition and take the remote control with you when leaving the vehicle so that children cannot use the lighter and burn themselves.◀

Replace the cover after use
Reinsert the lighter or socket cover after
use, otherwise objects may get into the lighter
socket or fixture and cause a short circuit.

#### **Front**

#### At a glance



The lighter is located next to the ashtray.

#### **Controls**



Push in the lighter.

The lighter can be removed as soon as it pops back out.

#### Rear

#### At a glance



The cigarette lighter is located in the rear center console.

#### **Controls**



Push in the lighter.

The lighter can be removed as soon as it pops back out.

# Connecting electrical devices

#### **Hints**

Do not plug chargers into the socket
Do not connect battery chargers to the
factory-installed sockets in the vehicle as this
may damage the battery.

✓

Replace the cover after use
Reinsert the lighter or socket cover after use, otherwise objects may get into the lighter socket or fixture and cause a short circuit.

#### **Sockets**

The lighter socket can be used as a socket for electrical equipment while the engine is running or when the ignition is switched on. The total load of all sockets must not exceed 140 watts at 12 volts.

Do not damage the socket by using unsuitable connectors.

#### Front center console



Slide the cover forward.

Remove the cover or cigarette lighter.

#### Center armrest



Remove the cover.

#### Rear center console



Remove the cover or cigarette lighter.

# In the cargo area



Fold open the cover.

# USB interface for data transfer

#### The concept

Connection for importing and exporting data on USB devices, e.g.:

- ▶ Personal Profile settings, refer to page 33.
- Music collection, see user's manual for Navigation, Entertainment and Communication.

# At a glance



The USB interface is located in the center armrest.

#### **Notes**

Observe the following when connecting:

▶ Do not use force when plugging the connector into the USB interface.

- Do not connect devices such as fans or lamps to the USB interface.
- Do not connect USB hard drives.
- Do not use the USB interface to recharge external devices.

# Cargo area

## Cargo cover

#### **Hints**

Hook the cargo cover on both sides
Hook the cargo cover on both sides to
prevent damaging the cover.

◄

Do not deposit heavy objects


Do not deposit heavy or hard objects on
the trunk cover. Otherwise, they could endanger occupants during braking and evasive maneuvers, for example.



Do not let the trunk cover snap back into place

Do not allow the trunk cover to snap back into place; this can damage it. ◀


# **Attaching**



- Remove cargo cover, arrow 1.
- Hook cargo cover into the brackets on both sides, arrow 2

## Removing

The cover can be removed to load bulky luggage.



- Press the button, arrow 1, to unlock the cover.
- 2. Pull the cover back, arrow 2.

## Installing

Slide the cover forward horizontally into the two side brackets until it audibly latches. The red warning fields disappear. Tug on the cover to check if it is properly locked in place.

# **Enlarging the cargo area**

#### General information

The cargo area can be enlarged by folding down the rear seat backrest.

The rear seat backrest is divided at a ratio of 40–20–40. The sides and the middle section can be folded down separately.

#### **Hints**

Danger of pinching

Before folding down the rear seat backrests, ensure that the area of movement of the backrests is clear. In particular, ensure that no one is located in the area of movement and that no one reaches into the area of movement of the rear seat backrests when the middle section is folded down. Otherwise, injury or damage may result. Lock the rear seat backrests in position
Before mounting child restraint fixing
systems, place the seat backrest as far as possible at an angle at which the child seat is resting firmly against the backrest and all backrests can be locked securely in place.
Otherwise, the child seat will not be as stable as it should be, and there is increased danger of injury due to unexpected movement of the seat backrest.

Ensure that the lock is securely engaged When folding back the backrest, be sure that it locks in place securely. When this happens the red warning field on the seat disappears. If it is not properly engaged, transported cargo could enter the passenger compartment during braking or evasive maneuvers and endanger the vehicle occupants.

Using the middle safety belt
If the middle safety belt in the rear is
used, the larger section of the backrest must
be locked. Otherwise, the safety belt will not
have a restraining effect.

# Folding down the sides



Move the front seats to an upright posi-

Before folding down the rear backrests, ensure that the front seats are moved forward slightly and are in an upright position. Otherwise, the head restraint and screen could be damaged.◀



Reach into the recess and pull forward.

# Folding down the middle section



Reach into the recess and pull forward.

#### **Partition net**

#### Note



Do not let the partition net snap back into place

Do not allow the partition net to snap back into place; otherwise, there is a danger of injury and the partition net could be damaged. ◀

## **Hooking in**

- 1. Fold open the rear covers on the headliner.
- 2. Pull the partition net out of the case by the strap.
- Insert the bars into the brackets on both sides in the headliner toward the front, arrow. This is best performed from the rear seat.



# Lowering

1. Hold the rod on both side and release it from the brackets.

2. Slowly slide the partition net into the cassette.

# Ski and snowboard bag

#### **General information**

The ski and snowboard bag is contained in a protective jacket in the cargo area.

Follow the installation and operation instructions included in the protective jacket.

# Sun visor

#### Glare shield from the side

## **Folding out**

- 1. Fold the sun visor down.
- 2. Unhook it from the holder and swing it to the side.
- 3. Move it back to the desired position.

# Folding up

Proceed in the reverse order to close the sun visor.

# **Storage compartments**

# Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

## **Notes**



No loose objects in the passenger compartment

Do not stow any objects in the passenger compartment without securing them; otherwise, they may present a danger to occupants for instance during braking and avoidance maneuvers.



Do not place anti-slip mats on the dashboard

Do not place anti-slip mats on the dashboard. The mat materials could damage the dashboard. ◀

# Storage compartments

The following storage compartments are available in the vehicle interior:

- Glove compartment on the front passenger side, refer to page 179.
- Glove compartment on the driver's side, refer to page 180.
- Compartments in the doors, refer to page 180.
- Storage compartment on the center armrest, refer to page 180.
- Storage compartment third row of seats, refer to page 180.

- Center armrest, refer to page 181.
- ▶ Glasses compartment, refer to page 182.

# **Glove compartment**

## Front passenger side


#### Note



Close the glove compartment again immediately

Close the glove compartment immediately after use while driving; otherwise, injury may occur during accidents. ◀

## **Opening**



Pull the handle.

The light in the glove compartment switches on.

The net in the glove compartment is used to store small objects.

# Closing

Fold up the cover.

# Locking

After the glove compartment is locked, the remote control can be handed over, such as at a hotel, without the integrated key.

#### Driver's side

#### Note



Close the glove compartment again immediately

Close the glove compartment immediately after use while driving; otherwise, injury may occur during accidents.◀

## **Opening**



Pull the handle.

# Closing

Fold up the cover.

# **Compartments in the doors**

Do not stow any breakable objects
Do not store any breakable objects, e. g.
glass bottles, in the compartments, or there is
an increased risk of injury in the event of an accident.

✓

# Storage compartment on the center console

## **Opening**



Slide the cover forward.

# **Closing**

Slide the cover rearward.

# **Small storage compartment**




Storage possibility for small objects, for example, coins.

# Storage compartment third row of seats

# At a glance

A storage compartment is located between the seats of third row of seats.



### **Center armrest**

#### **Front**

#### At a glance

Located in the center armrest between the front seats is a storage compartment and depending on how the vehicle is equipped also an elastic band on the left side and a cover for the mobile phone holder or the snap-in adapter.

### **Opening**



Push the cover down slightly and press the button, see arrow. The respective cover folds up.

### Closing

Fold the respective cover down until it latches.

# Connection for an external audio device



Description, see user's manual for Navigation, Entertainment and Communication.

#### Rear

#### At a glance

A storage compartment is located in the center armrest between the seats.

#### **Opening**

 Pull on the loop and fold down the center armrest.



Pull the handle.



#### Closing

Press cover down until it latches.

## **Glasses compartment**

#### At a glance

The glasses compartment is located between the interior mirror and interior lamps.

#### **Opening**



Press the button.

### **Closing**

Press the cover up until it latches.

## **Cupholders**

#### **Hints**



Shatter-proof containers and no hot drinks

Use light and shatter-proof containers and do not transport hot drinks. Otherwise, there is the increased danger of injury in an accident. ◄

Unsuitable containers

Do not forcefully push unsuitable containers into the cupholders. This may result in damage. ◀

#### **Front**

#### At a glance

In the center console.



Slide the cover forward.



Two cupholders are located in the center console.

#### Rear

#### Note

A

Pushing back the covers

Push back the covers before folding up the center armrest; otherwise, the cupholder could become damaged.

### At a glance

In the center armrest.

#### **Opening**

 Pull on the loop and fold down the center armrest.



2. Press the button.



### Closing

Press both covers inward back against each other.

#### Third row of seats

## At a glance

The drink holder is located between the seats of third row of seats.



## **Clothes hooks**

The clothes hooks are located in the grab handles in the rear.


Do not obstruct view
When suspending clothing from the hooks, ensure that it will not obstruct the driver's vision.

No heavy objects

Do not hang heavy objects from the hooks; otherwise, they may present a danger to passengers during braking and evasive maneuvers.


# Storage compartments in the cargo area

# Storage space under the cargo floor cover



Raise the cargo floor panel. The storage space under the cargo floor panel is subdivided.

#### Hooks/multi-function hook



#### **Retaining strap**

A retaining strap is available on the right side trim for fastening small objects.

#### Net

Smaller objects can be stored in the net on the left side of the cargo area.

## Storage compartment on the right side

A waterproof storage compartment is available on the right side of the cargo area floor.

#### Left side storage compartment



Pull the handle.

## Lashing eyes in the cargo area

To secure the cargo, refer to page 193, there are lashing eyes in the cargo area.

# Lashing eyes in the cargo area with rail

To secure the cargo, refer to page 193, there are lashing eyes in the cargo area.

## Cargo net, FlexNet

To secure the cargo, refer to page 193, the flexible cargo net can also be used.



# **Driving tips**

This chapter provides you with information useful in dealing with specific driving and operating modes.

## Things to remember when driving

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

## **Breaking-in period**

#### **General information**

Moving parts need to be broken in to adjust to each other.

The following instructions will help achieve a long vehicle life and good economy.

### **Engine and differential**

Always obey the official speed limit.

#### Up to 1,200 miles/2,000 km

Do not exceed the maximum engine and road speed:

For gasoline engine 4,500 rpm and 100 mph/160 km/h.

Avoid full load or kickdown under all circumstances.

### From 1,200 miles/2,000 km

The engine and vehicle speed can gradually be increased.

#### Tires

Due to technical factors associated with their manufacture, tires do not achieve their full traction potential until after an initial breakingin period.

Drive conservatively for the first 200 miles/300 km.

#### **Brake system**

Brakes require an initial break-in period of approx. 300 miles/500 km to achieve optimized contact and wear patterns between brake discs and brake pads. Drive moderately during this break-in period.

#### Following part replacement

The same breaking in procedures should be observed if any of the components mentioned above have to be renewed in the course of the vehicle's operating life.

## **General driving notes**

#### Closing the tailgate

Drive with the tailgate closed
Only drive with the tailgate closed; otherwise, in the event of an accident or braking and evasive maneuvers, passengers and other road users may be injured, and the vehicle may be damaged. In addition, exhaust fumes may enter the passenger compartment.

■

If driving with the tailgate open cannot be avoided:

- Close all windows and the glass sunroof.
- Greatly increase the blower speed.
- Drive moderately.


### Hot exhaust system

Hot exhaust system
High temperatures are generated in the exhaust system.

Do not remove the heat shields installed and never apply undercoating to them. Make sure that flammable materials, e. g. hay, leaves, grass, etc. do not come in contact with the hot exhaust system during driving, while in idle position mode, or when parked. Such contact could lead to a fire, and with it the risk of serious personal injury as well as property damage.

Do not touch hot exhaust pipes; otherwise, there is the danger of getting burned. ◀

#### Climate control windshield



The marked area is not covered with heat reflective coating.

Use this area for garage door openers, devices for electronic toll collection, etc.

# Mobile communication devices in the vehicle



Mobile communication devices in the vehicle

It is advised that you do not use mobile communication devices, e.g., mobile phones, inside the vehicle without connecting them directly to the external antenna. Otherwise, the vehicle electronics and mobile communication devices can interfere with each other. In addition, there is no assurance that the radiation generated during transmission will be discharged from the vehicle interior. ◀

## **Hydroplaning**

On wet or slushy roads, a wedge of water can form between the tires and road surface.

This phenomenon is referred to as hydroplaning. It is characterized by a partial or complete loss of contact between the tires and the road surface, ultimately undermining your ability to steer and brake the vehicle.



Hydroplaning

When driving on wet or slushy roads, reduce your speed to prevent hydroplaning. ◄

#### **Driving through water**

Drive though calm water only if it is not deeper than 19.6 inches/50 cm, and at this height no faster than walking speed.



Adhere to water depth and speed limitations

Do not exceed this water depth and walking speed; otherwise, the vehicle's engine, the electrical systems and the transmission may be damaged.◀

#### **Braking safely**

Your vehicle is equipped with ABS as a standard feature.

Applying the brakes fully is the most effective way of braking in situations when this is necessary.

The vehicle maintains steering responsiveness. You can still avoid any obstacles with a minimum of steering effort.

Pulsation of the brake pedal and sounds from the hydraulic circuits indicate that ABS is in its active mode.

### Objects in the area around the pedals

No objects in the area around the pedals Keep floor mats, carpets, and any other objects out of the area of motion of the pedals; otherwise, the function of the pedals could be impeded while driving

Do not place additional floor mats over existing mats or other objects.

Only use floor mats that have been approved for the vehicle and can be properly fixed in place.

Ensure that the floor mats are securely fastened again after they were removed for cleaning, for example. ◀

#### **Driving in wet conditions**

When roads are wet coated with road salt or there is heavy rain, briefly exert gentle pressure on the brake pedal every few miles.

Ensure that this action does not endanger other road users.

The heat generated in this process helps dry the brake discs and pads.

In this way braking efficiency will be available when you need it.

#### Hills

Drive long or steep downhill gradients in the gear in which the least braking is required. Otherwise, the brake system may overheat, resulting in a reduction in the brake system efficiency.

You can increase the engine's braking effect by shifting down, going all the way to first gear, if necessary.

Avoid load on the brakes
Avoid placing excessive load on the
brake system. Light but consistent brake pressure can lead to high temperatures, brake wear
and possibly even brake failure. ◄

Do not drive in neutral
Do not drive in neutral or with the engine
stopped, as doing so disables engine braking.
In addition, steering and brake assist is unavailable with the engine stopped.

■

#### **Brake disc corrosion**

The corrosion on the brake discs and the contamination on the brake pads are furthered by:

- Low mileage.
- Extended periods when the vehicle is not used at all.

Infrequent use of the brakes.

Corrosion occurs when the minimum pressure that must be exerted by the pads during brake applications to clean the discs is not reached.

Should corrosion form on the brake discs, the brakes will tend to respond with a pulsating effect that generally cannot be corrected.

## Condensation under the parked vehicle

When using the automatic climate control, condensation water develops that exits underneath the vehicle.

Traces of water under the vehicle like this are normal.

## **Driving on poor roads**

The vehicle connects four wheel drive to the advantages of a normal truck

Do not drive on unpaved terrain;

Do not drive on unpaved terrain; otherwise, the vehicle may be damaged.

✓

For your own safety, for the safety of passengers and of the vehicle, heed the following points:

- Become familiar with the vehicle before starting a trip; do not take risks in driving.
- Adjust the speed to the road surface conditions. The steeper and more uneven the road surface, the slower the speed should be.
- When driving on steep uphill or downhill grades: add engine oil and coolant up to near the MAX mark. Uphill and downhill grades can be traveled up to no more than 50 %.
- On steep downhill grades, use Hill Descent Control HDC, refer to page 129.
  - Starting out is possible on uphill grades up to 33 %. The permissible side tilt is 50 %.

- Avoid contact of the bottom of the body with the ground.
  - The ground clearance is no more than 7.8 inches/20 cm and can vary according to the loading condition.
- When wheels continue to turn, depress the accelerator so that driving stability control systems can distribute the driving force to the wheels. Activate DTC Dynamic Traction Control if available.

#### After a trip on poor roads

After a trip on poor roads, check wheels and tires for damage to maintain driving safety. Clear heavy soiling from the body.

## Loading

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

## **General information**

Overloading the vehicle
To avoid exceeding the approved carrying capacity of the tires, never overload the vehicle. Overloading can lead to overheating and increases the rate at which damage develops inside the tires. This could result in a sudden loss of tire inflation pressure.

No fluids in the trunk

Make sure that fluids do not leak into the trunk; otherwise, the vehicle may be damaged.

■


## **Determining the load limit**



- Locate the following statement on your vehicle's placard:
  - The combined weight of occupants and cargo should never exceed XXX kg or YYY lbs. Otherwise, damage to the

- vehicle and unstable driving situations may result.
- Determine the combined weight of the driver and passengers that will be riding in your vehicle.
- Subtract the combined weight of the driver and passengers from XXX kilograms or YYY pounds.
- The resulting figure equals the available amount of cargo and luggage load capacity.
  - For example, if the YYY amount equals 1,000 lbs and there will be four 150 lbs passengers in your vehicle, the amount of available cargo and luggage load capacity is 400 lbs: 1,000 lbs minus 600 lbs = 400 lbs.
- Determine the combined weight of luggage and cargo being loaded on the vehicle. That weight may not safely exceed the available cargo and luggage load capacity calculated in Step 4.

### Load



The maximum load is the sum of the weight of the occupants and the cargo.


The greater the weight of the occupants, the less cargo that can be transported.

## **Stowing cargo**

- Cover sharp edges and corners on the cargo.
- Heavy cargo: stow as far forward as possible, directly behind and at the bottom of the rear passenger seat backrests.
- Very heavy cargo: when the rear seat is not occupied, secure each of the outer safety belts in the opposite buckle.
- ▶ If necessary, fold down the rear backrests to stow cargo.
- Do not stack cargo above the top edge of the backrests.
- Use the cargo area partition net, refer to page 177, to protect passengers. Make sure that objects cannot penetrate the cargo area partition net.


## **Securing cargo**

#### Lashing eyes in the cargo area




To secure the cargo there are four lashing eyes in the cargo area.

# Lashing eyes in the cargo area with rails



To secure the cargo, there are four movable lashing eyes in the cargo area.




To slide the lashing eyes, press the button, arrow 1. Make sure that the lashing eyes latch at the new position.

If available, the lashing eyes are located under the cargo floor cover in the cargo area. They can be inserted into the openings in the rails.

## Cargo net, FlexNet

The flexible cargo net is hooked into eyes and secures the cargo in the cargo area. The storage net can be attached to the following eyes:



- Lashing eyes on the rail system.
- Eyes on the cargo area wall.

The eyes are located on both sides of the cargo area.

#### Securing cargo

- Smaller and lighter items: secure with retaining straps or with a cargo net or draw straps.
- Larger and heavy objects: secure with cargo straps.

Cargo straps, cargo netting, retaining straps or draw straps on the lashing eyes in the cargo area.

Securing cargo

Always position and secure the cargo as described above; otherwise, it can endanger the car's occupants if sudden braking or swerving becomes necessary.

Heavy or hard objects should not be carried loose inside the car; otherwise, they could be thrown around as a result of hard braking, sudden swerves, etc., and endanger the occupants.◀

fect on vehicle handling and steering response.

Therefore, note the following when loading and driving:

- Do not exceed the approved roof/axle loads and the approved gross vehicle weight.
- Distribute the roof load uniformly.
- The roof load should not be too large in area.
- Always place the heaviest pieces on the bottom.
- Secure the roof luggage firmly, e.g., tie with ratchet straps.
- Do not let objects project into the opening path of the tailgate.
- Drive cautiously and avoid sudden acceleration and braking maneuvers. Take corners gently.

## Roof-mounted luggage rack

#### Note

Installation only possible with roof rack.

Roof racks are available as special accessories.

### **Securing**

Follow the installation instructions of the roof rack.

## Loading

Be sure that adequate clearance is maintained for tilting and opening the glass sunroof.

Because roof racks raise the vehicle's center of gravity when loaded, they have a major ef-

## **Saving fuel**

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

### **General information**

Fuel consumption depends on a number of different factors.

The implementation of certain measures, driving style and regular maintenance can have an influence on fuel consumption and on the environmental impact.

## Remove unnecessary cargo

Additional weight increases fuel consumption.

# Remove attached parts following use

Remove auxiliary mirrors, roof or rear luggage racks which are no longer required following use.

Attached parts on the vehicle impair the aerodynamics and increase the fuel consumption.

# Close the windows and glass sunroof

Driving with the glass sunroof and windows open results in increased air resistance and raises fuel consumption.

### **Tires**

#### **General information**

Tires can affect fuel consumption values in various ways, for instance fuel consumption can be influenced by the size of the tires.

# Check the tire inflation pressure regularly

Check and, if necessary, correct the tire inflation pressure at least twice a month and before starting on a long trip.

Low tire inflation pressure increases rolling resistance and thus raises fuel consumption and tire wear.

## **Drive away without delay**

Do not wait for the engine to warm-up while the vehicle remains stationary. Start driving right away, but at moderate engine speeds.

This is the fastest way for the cold engine to reach its operating temperature.

# Look well ahead when driving

Avoid unnecessary acceleration and braking.

By maintaining a suitable distance to the vehicle driving ahead of you.

Driving smoothly and looking ahead reduces fuel consumption.

## **Use coasting conditions**

When approaching a red light, take your foot off the accelerator and let the vehicle coast to a halt.

On a downhill gradient, take your foot off the accelerator and let the vehicle roll.

The flow of fuel is interrupted while coasting.

# Switch off the engine during longer stops

Switch off the engine during longer stops, e.g., at traffic lights, railroad crossings or in traffic congestion.

### **Automatic Engine Start/Stop Function**

The Auto Start/Stop function of your vehicle automatically switches off the engine during a stop.

If the engine is switched off and then restarted rather than leaving the engine running constantly, fuel consumption and emissions are reduced. Savings can begin within a few seconds of switching off the engine.

Using this system can cause certain components of the vehicle to become worn prematurely.

In addition, fuel consumption is also determined by other factors, such as driving style, road conditions, maintenance or environmental factors.

# Switch off any functions that are not currently needed

Functions such as seat heating and the rear window defroster require a lot of energy and consume additional fuel, especially in city and stop-and-go traffic.

Therefore, switch off these functions if they are not actually needed.

# Have maintenance carried out

Have vehicles maintained regularly to achieve optimal vehicle economy and operating life. Have the maintenance carried out by your service center.

Please also note the BMW Maintenance System, refer to page 220.

#### **ECO PRO**

#### The concept

ECO PRO supports a driving style that saves on fuel consumption. For this purpose, the engine control and comfort functions, e. g. the climate control output, are adjusted.

The extension of the range that is achieved as a result can be displayed in the instrument cluster.

#### At a glance

The system includes the following EfficientDynamics functions and displays:

- ▶ ECO PRO bonus range, refer to page 197.
- ▶ ECO PRO climate control, refer to page 197.

## **Activating ECO PRO**



Press button repeatedly until ECO PRO is displayed in the instrument

cluster.

## **Configuring ECO PRO**

## **Via the Driving Dynamics Control**

- 1. Activate ECO PRO.
- 2. "Configure ECO PRO"
- 3. Configure the program.

#### Via the iDrive

- 1. "Settings"
- 2. "ECO PRO mode"

Or

- 1. "Settings"
- 2. "Driving mode"
- 3. "Configure ECO PRO"

Configure the program.

#### **ECO PRO Tip**

▶ "Tip at:":

Set ECO Pro speed at which an ECO PRO Tip is to be displayed.

"ECO PRO speed warning":

A reminder is displayed if the set ECO PRO speed is exceeded.

#### **ECO PRO climate control**

"ECO PRO climate control"

The climate control is adjusted to be fuel-efficient.

By making a slight change to the set temperature, or slowly adjusting the rate of heating or cooling of the passenger compartment, fuel consumption can be economized.

The outputs of the seat heater and the exterior mirror heating are also reduced.

The exterior mirror heating is made available when outside temperatures are very cold.

## **ECO PRO potential**

The percentage of potential savings that can be achieved with the current configuration is displayed.

#### Display in the instrument cluster

#### **ECO PRO bonus range**



An extension of the range can be achieved by an adjusted driving style.

This may be displayed as the bonus range in the instrument

cluster.

The bonus range is shown in the range display.

The bonus range is automatically reset every time the vehicle is refueled.

#### **ECO PRO Tip - driving instruction**



The arrow indicates that the driving style can be adjusted to be more fuel efficient by backing off the accelerator for instance.

#### Note

The driving style display and ECO PRO tips in the instrument cluster appear when the ECO PRO display is activated.

Activating driving style and ECO PRO tips:

- 1. "Settings"
- 2. "Info display"
- 3. "ECO PRO Info"

### **ECO PRO tip - Symbols**

An additional symbol and a text instruction are displayed.

#### Symbol Measure



For efficient driving style, back off the accelerator or delay accelerating to allow time to assess road conditions.



Reduce speed to the selected ECO PRO speed.



Automatic transmission: switch from M/S to D and avoid manual shift interventions.

### **Indications on the Control Display**

#### **EfficientDynamics**

Information on fuel consumption and technology can be displayed during driving.

- 1. "Vehicle Info"
- 2. "EfficientDynamics"

### **Displaying EfficientDynamics info**

The current efficiency can be displayed.

☐ "EfficientDynamics info"

The following systems are displayed:

- Automatic engine start-stop function.
- Energy recovery.
- Climate control output.
- Coasting.

## **Display ECO PRO tips**

i "ECO PRO Tips"

The setting is stored for the profile currently in use.

### Coasting

#### The concept

The system helps to conserve fuel.

To do this, under certain conditions the engine is automatically decoupled from the transmis-

sion when transmission position D is engaged. The vehicle continues traveling with the engine idling to reduce fuel consumption. Transmission position D remains engaged.

This driving condition is referred to as coasting.

As soon as the brake or accelerator pedal is depressed, the engine is automatically coupled to the transmission again.

#### Hints

Coasting is a component of the ECO PRO, refer to page 196, driving mode.

The function is available in a certain speed range.

A forward-looking driving style helps the driver to use the function as often as possible and supports the fuel-conserving effect of coasting.

#### Safety mode

The function is not available if one of the following conditions is satisfied.

- DSC OFF or TRACTION activated.
- Driving in the dynamic limit range and on steep uphill or downhill grades.
- Battery charge status temporarily too low or vehicle electrical system drawing excessive current.
- Cruise control activated.

### **Functional requirements**

In ECO PRO mode, this function is available in a speed range from approximately 30 mph, approx. 50 km/h to 100 mph, approx. 160 km/h, if the following conditions are satisfied:

- Accelerator pedal and brake pedal are not operated.
- The selector lever is in transmission position D.
- Engine and transmission are at operating temperature.

#### **Display**

#### Display in the instrument cluster



The mark in the bar display below the tachometer is backlit in blue and is located at the zero point. The tachometer approximately indicates idle speed.

The coasting point indicator is illuminated at the zero point during coasting.

#### **Indications on the Control Display**

The Coasting driving condition is displayed in EfficientDynamics Info while this driving mode is active.



Color code blue, arrow 1, and symbol, arrow 2: driving condition Coasting.

#### **Displaying EfficientDynamics info**

- 1. "Vehicle Info"
- 2. "EfficientDynamics"
- 3. T "EfficientDynamics info"

### **Deactivating the system manually**

The function can be deactivated in the Configure ECO PRO, refer to page 196, menu, e.g., to use the braking effect of the engine when traveling downhill.

The setting is stored for the profile currently in use.



# **Mobility**

In order to always ensure your mobility, you will find important information on operating fluids, wheels and tires, maintenance and Roadside Assistance in the following.

## Refueling

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

#### **General information**

Refuel promptly
Refuel no later than at a range of
30 miles/50 km, or operation of the engine is
not ensured and damage may occur.

## **Fuel cap**

### **Opening**

 Briefly press the rear edge of the fuel filler flap.



2. Turn the fuel cap counterclockwise.



3. Place the fuel cap in the bracket attached to the fuel filler flap.



### Closing

- Fit the cap and turn it clockwise until you clearly hear a click.
- Close the fuel filler flap.

Do not pinch the retaining strap
Do not pinch the retaining strap attached
to the cap; otherwise, the cap cannot be
closed properly and fuel vapors can escape.

A message is displayed if the cap is loose or missing.◀

## Manually unlocking fuel filler flap

In the event of an electrical malfunction, for example.

1. Open the cover on the right side trim.



2. Pull the green knob with the fuel pump symbol. This releases the fuel filler flap.



# Observe the following when refueling

The fuel tank is full when the filler nozzle clicks off the first time.

Do not overfill the fuel tank
Do not overfill the fuel tank; otherwise
fuel may escape, causing harm to the environment and damaging the vehicle. ◄

Handling fuels
Obey safety regulations posted at the gas station. ◀

## **Fuel**

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

#### **Fuel recommendation**

#### Gasoline

For the best fuel economy, the gasoline should be sulfur-free or very low in sulfur content.

Fuels that are marked on the gas pump as containing metal must not be used.



Refuel only with unleaded gasoline without metallic additives.

Do not refuel with any leaded gasoline or gasoline with metallic additives, e. g. manganese or iron, or permanent damage to the catalytic converter and other components. ◀

Fuels with a maximum ethanol content of 10 %, i. e., E10, may be used for refueling. Ethanol should satisfy the following quality standards:

US: ASTM 4806-xx CAN: CGSB-3.511-xx

xx: comply with the current standard in each case.

Do not refuel with ethanol E85 Do not refuel with E85, i.e., fuel with an ethanol content of 85 %, or with Flex Fuel, as this would damage the engine and fuel supply system.∢

#### Gasoline quality

BMW recommends AKI 91.

#### Minimum fuel grade

BMW recommends AKI 89.

Minimum fuel grade Do not use any gasoline below the minimum fuel grade as this may impair engine performance. ◀

If you use gasoline with this minimum AKI Rating, the engine may produce knocking sounds when starting at high outside temperatures. This has no effect on the engine life.

Fuel quality

The use of poor-quality fuels may result in harmful engine deposits or damage. Additionally, problems relating to drivability, starting and stalling, especially under certain environmental conditions such as high ambient temperature and high altitude, may occur.

If drivability problems are encountered, we recommend switching to a high quality gasoline brand and a higher octane grade — AKI number — for a few tank fills. To avoid harmful engine deposits, it is highly recommended to purchase gasoline from BP or Top Tier retail-

Failure to comply with these recommendations may result in the need for unscheduled maintenance. ◀

BMW recommends BP fuels \*\*



## Wheels and tires

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

## Tire inflation pressure

#### **Safety information**

The tire characteristics and tire inflation pressure influence the following:

- The service life of the tires.
- Road safety.
- Driving comfort.

### **Checking the pressure**

Only check the tire inflation pressure when the tires are cold. This means after driving no more than 1.25 miles/2 km or when the vehicle has been parked for at least 2 hours. When the tires are warm, the tire inflation pressure is higher.

Check the tire inflation pressure regularly Regularly check the tire inflation pressure, and correct it as needed: at least twice a month and before a long trip. If you fail to observe this precaution, you may be driving on tires with incorrect tire pressures, a condition that may not only compromise your vehicle's driving stability, but also lead to tire damage and the risk of an accident.

After correcting the tire inflation pressure:

- Reinitialize the Flat Tire Monitor.
- Reinitialize the Tire Pressure Monitor.

#### **Pressure specifications**

The tire inflation pressure table, refer to page 206, contains all pressure specifications for the specified tire sizes at the ambient temperature. Pressure specifications apply to approved tire sizes and recommended tire brands. This information can be obtained from your service center.

To identify the correct tire inflation pressure, please note the following:

- ▶ Tire sizes of your vehicle.
- Maximum permitted driving speed.

# Tire inflation pressures up to 100 mph/160 km/h

For speeds of up to 100 mph/160 km/h and for optimum driving comfort, note the pressure values in the tire inflation pressure table, refer to page 206, and adjust as necessary.



These pressure values can also be found on the tire inflation pressure label on the driver's door pillar.

Maximum permissible speed
Do not exceed 100 mph/160 km/h; otherwise, tire damage and accidents may result.◀

# Tire inflation pressure values up to 100 mph/160 km/h

#### X5 sDrive35i/X5 xDrive35i/ X5 xDrive50i with two rows of seats

X5 XDrive50i With t	X5 xDrive50i with two rows of seats			
Tire size	Pressure specifica- tions in bar/PSI			
Specifications in bar/PSI with cold tires	* * * * +	· † / Ø		
255/55 R 18 109 H M+S XL A/S RSC 255/55 R 18 109 H M+S XL RSC	2.3/33	2.8 / 41		
255/50 R 19 107 H M+S XL A/S RSC 255/50 R 19 107 H M+S XL RSC	2.5 / 36	3.0 / 44		
Front: 275/40 R 20 106 W XL RSC Rear: 315/35 R 20 110 W XL RSC	2.5 / 36	- 2.8 / 41		
Front: 275/40 R 20 106 V M+S XL RSC Rear: 315/35 R 20 110 V M+S XL RSC	2.5 / 36	- 2.8 / 41		
Front: 285/35 R 21 105 Y XL RSC Rear: 325/30 R 21 108 Y XL RSC	2.5 / 36	- 3.0 / 44		
Compact wheel: T 155/90 D 18 113 M T 155/80 R 19 114 M	Speed up to a max. of 50 mph / 80 km/h 4.2 / 60			

#### X5 sDrive35i/X5 xDrive35i/ X5 xDrive50i with three rows of seats

Tire size	Pressure specifica- tions in bar/PSI	
Specifications in bar/PSI with cold tires	* * * * * * * * * / 10	
255/55 R 18 109 H M +S XL A/S RSC 255/55 R 18 109 H M +S XL RSC	2.2/32 2.7/39	
255/50 R 19 107 H M +S XL A/S RSC 255/50 R 19 107 H M +S XL RSC	2.4/35 2.9/42	
Front: 275/40 R 20 106 W XL RSC Rear: 315/35 R 20 110 W XL RSC	2.4/35 - 2.7/39	
Front: 275/40 R 20 106 V M+S XL RSC Rear: 315/35 R 20 110 V M+S XL RSC	2.4/35 - - 2.7/39	
Front: 285/35 R 21 105 Y XL RSC Rear: 325/30 R 21 108 Y XL RSC	2.4/35 - 2.9/42	

# Tire inflation pressures at max. speeds above 100 mph/160 km/h

Speeds above 100 mph/160 km/h
In order to drive at maximum speeds in
excess of 100 mph/160 km/h, please observe,
and, if necessary, adjust tire pressures for
speeds exceeding 100 mph/160 km/h from the
relevant table on the following pages. Otherwise tire damage and accidents could occur.

✓

# Tire inflation pressure values over 100 mph/160 km/h

# X5 sDrive35i/X5 xDrive35i with two rows of seats

Without Sport Package

Without Sport Package			
Tire size	Pressure specifica- tions in bar/PSI		
Specifications in bar/PSI with cold tires	* * * * +	· / / D	
255/55 R 18 109 H M+S XL A/S RSC 255/55 R 18 109 H M+S XL RSC	2.6 / 38	3.1 / 45	
255/50 R 19 107 H M+S XL A/S RSC 255/50 R 19 107 H M+S XL RSC	2.8 / 41	3.3 / 48	
Front: 275/40 R 20 106 W XL RSC Rear: 315/35 R 20 110 W XL RSC	2.8 / 41 -	3.0 / 44	
Front: 275/40 R 20 106 V M+S XL RSC Rear: 315/35 R 20 110 V M+S XL RSC	2.8 / 41	3.0 / 44	
Front: 285/35 R 21 105 Y XL RSC Rear: 325/30 R 21 108 Y XL RSC	2.8 / 41	- 3.2 / 46	
Compact wheel: T 155/90 D 18 113 M T 155/80 R 19 114 M	Speed up to a max. of 50 mph / 80 km/h 4.2 / 60		

Tire size	Pressure specifications in bar/PSI	
Specifications in bar/PSI with cold tires	* * * * + * / ©	
255/55 R 18 109 H M+S XL RSC 255/50 R 19 107 H M+S XL RSC	2.9 / 42 3.4 / 49	
Front: 275/40 R 20 106 W XL RSC Rear: 315/35 R 20 110 W XL RSC	2.9 / 42 - 3.2 / 46	
Front: 275/40 R 20 106 V M+S XL RSC Rear: 315/35 R 20 110 V M+S XL RSC	2.9/42 - 3.2/46	
Front: 285/35 R 21 105 Y XL RSC Rear: 325/30 R 21 108 Y XL RSC	2.9 / 42 - 3.4/ 49	
Compact wheel: T 155/90 D 18 113 M T 155/80 R 19 114 M	Speed up to a max. of 50 mph / 80 km/h 4.2 / 60	

# X5 sDrive35i/X5 xDrive35i with three rows of seats

Without Sport Package

With Sport Package

Tire size	Pressure sp tions in bar/	
Specifications in bar/PSI with cold tires	***	*+*/10
255/55 R 18 109 H M +S XL A/S RSC 255/55 R 18 109 H M +S XL RSC	2.5 / 36	3.0 / 44
255/50 R 19 107 H M +S XL A/S RSC 255/50 R 19 107 H M +S XL RSC	2.7/39	3.2 / 46
Front: 275/40 R 20 106 W XL RSC Rear: 315/35 R 20 110 W XL RSC	2.7/39	- 3.0 / 44
Front: 275/40 R 20 106 V M+S XL RSC Rear: 315/35 R 20 110 V M+S XL RSC	2.7/39	3.0 / 44
Front: 285/35 R 21 105 Y XL RSC Rear: 325/30 R 21 108 Y XL RSC	2.7 / 39	- 3.2 / 46

With Sport Package

Tire size	Pressure specifications in bar/PSI	
Specifications in bar/PSI with cold tires	* * * * *	* * + * / 10
255/55 R 18 109 H M+S XL RSC 255/50 R 19 107 H M+S XL RSC	2.9/42	3.4 / 49
Front: 275/40 R 20 106 W XL RSC Rear: 315/35 R 20 110 W XL RSC	2.9 /42	- 3.2 / 46
Front: 275/40 R 20 106 V M+S XL RSC Rear: 315/35 R 20 110 V M+S XL RSC	2.9 / 42	- 3.2 / 46
Front: 285/35 R 21 105 Y XL RSC Rear: 325/30 R 21 108 Y XL RSC	2.9/42	- 3.4/ 49

Without Sport Package

Tire size	Pressure specifica- tions in bar/PSI
Specifications in bar/PSI with cold tires	* * * * * * * / ©
255/55 R 18 109 H M+S XL A/S RSC	2.6 / 38 3.1 / 45
255/55 R 18 109 H M+S XL RSC	

Tire size	Pressure specifica- tions in bar/PSI	
255/50 R 19 107 H M+S XL A/S RSC 255/50 R 19 107 H M+S XL RSC	2.8 / 41	3.3 / 48
Front: 275/40 R 20 106 W XL RSC Rear: 315/35 R 20 110 W XL RSC	2.8 / 41	3.0 / 44
Front: 275/40 R 20 106 V M+S XL RSC Rear: 315/35 R 20 110 V M+S XL RSC	2.8 / 41	3.0 / 44
Front: 285/35 R 21 105 Y XL RSC Rear: 325/30 R 21 108 Y XL RSC	2.8 / 41	- 3.2 / 46
Compact wheel: T 155/90 D 18 113 M T 155/80 R 19 114 M	Speed up to a max. of 50 mph / 80 km/h 4.2 / 60	

#### With Sport Package

110 W XL RSC

This opert delage		
Tire size	Pressure s tions in bar	•
Specifications in bar/PSI with cold tires	* * * *	+
255/55 R 18 109 H M+S XL RSC 255/50 R 19 107 H M+S XL RSC	2.9 / 42	3.4 / 49
Front: 275/40 R 20 106 W XL RSC Rear: 315/35 R 20	2.9 / 42	- 3.2 / 46

Pressure specifica- tions in bar/PSI	
2.9 / 42	- 3.2 / 46
2.9/42	3.2 / 46
Speed up to a max. of 50 mph / 80 km/h 4.2 / 60	
	2.9 / 42 - 2.9 / 42 - Speed up to 50 mph / 80

#### X5 xDrive50i with three rows of seats

Without Sport Package

Tire size	Pressure specifications in bar/PSI	
Specifications in bar/PSI with cold tires	* * * * * * * * * * * * * * * * * * * *	

255/55 R 18 109 H M 2.5 / 36 3.0 / 44 +S XL A/S RSC 255/55 R 18 109 H M +S XL RSC 255/50 R 19 107 H M 2.7 / 39 3.2 / 46 +S XL A/S RSC 255/50 R 19 107 H M +S XL RSC

Tire size Pressure specifications in bar/PSI  Front: 275/40 R 20 2.7 / 39 - 3.0 / 44  Rear: 315/35 R 20 110 W XL RSC  Front: 275/40 R 20 2.7 / 39 - 3.0 / 44  Rear: 315/35 R 20 3.0 / 44  Rear: 315/35 R 20 3.0 / 44  Front: 285/35 R 21 2.7 / 39 - 3.0 / 44  Front: 285/35 R 21 2.7 / 39 - 3.2 / 46  Rear: 325/30 R 21 108 Y XL RSC			
106 W XL RSC	Tire size	•	
106 V M+S XL RSC	106 W XL RSC Rear: 315/35 R 20	2.7 / 39	3.0 / 44
105 Y XL RSC - 3.2 / 46 Rear: 325/30 R 21	106 V M+S XL RSC Rear: 315/35 R 20	2.7 / 39	- 3.0 / 44
	105 Y XL RSC Rear: 325/30 R 21	2.7 / 39	- 3.2 / 46

With Sport Package		
Tire size	Pressure specifications in bar/PSI	
Specifications in bar/PSI with cold tires	* * * * *	†+†/©
255/55 R 18 109 H M+S XL RSC 255/50 R 19 107 H M+S XL RSC	2.9 / 42	3.4 / 49
Front: 275/40 R 20 106 W XL RSC Rear: 315/35 R 20 110 W XL RSC	2.9 / 42	- 3.4 / 49
Front: 275/40 R 20 106 V M+S XL RSC Rear: 315/35 R 20 110 V M+S XL RSC	2.9 / 42	- 3.4 / 49
Front: 285/35 R 21 105 Y XL RSC Rear: 325/30 R 21 108 Y XL RSC	2.9 / 42	- 3.2 / 46

## Tire identification marks

#### Tire size

245/45 R 18 96 Y

245: nominal width in mm

45: aspect ratio in %

R: radial tire code

18: rim diameter in inches

96: load rating, not for ZR tires

Y: speed rating, before the R on ZR tires

#### Speed letter

T = up to 118 mph, 190 km/h

H = up to 131 mph, 210 km/h

V = up to 150 mph, 240 km/h

W = up to 167 mph, 270 km/h

Y = up to 186 mph, 300 km/h

#### **Tire Identification Number**

DOT code: DOT xxxx xxx 1013

xxxx: manufacturer code for the tire brand

xxx: tire size and tire design

1013: tire age

Tires with DOT codes meet the guidelines of the U.S. Department of Transportation.

### Tire age

DOT ... 1013: the tire was manufactured in the 10th week 2013.

#### Recommendation

Regardless of wear, replace tires at least every 6 years.

## **Uniform Tire Quality Grading**

Quality grades can be found where applicable on the tire sidewall between tread shoulder. and maximum section width.

For example: Treadwear 200; Traction AA;

Temperature A

#### **DOT Quality Grades**

Treadwear

Traction AA A B C

Temperature A B C

All passenger car tires must conform to Federal Safety Requirements in addition to these grades.

#### **Treadwear**

The treadwear grade is a comparative rating based on the wear rate of the tire when tested under controlled conditions on a specified government test course. For example, a tire graded 150 would wear one and one-half, 1 g, times as well on the government course as a tire graded 100. The relative performance of tires depends upon the actual conditions of their use, however, and may depart significantly from the norm due to variations in driving habits, service practices and differences in road characteristics and climate.

#### **Traction**

The traction grades, from highest to lowest, are AA, A, B, and C.

Those grades represent the tire's ability to stop on wet pavement as measured under controlled conditions on specified government test surfaces of asphalt and concrete. A tire marked C may have poor traction performance.

The traction grade assigned to this tire is based on straight-ahead braking traction tests, and does not include acceleration, cornering, hydroplaning, or peak traction characteristics.

### **Temperature**

The temperature grades are A, the highest, B, and C, representing the tire's resistance to the generation of heat and its ability to dissipate heat when tested under controlled conditions on a specified indoor laboratory test wheel. Sustained high temperature can cause the material of the tire to degenerate and reduce tire life, and excessive temperature can lead to

sudden tire failure. The grade C corresponds to a level of performance which all passenger car tires must meet under the Federal Motor Vehicle Safety Standard No. 109. Grades Band A represent higher levels of performance on the laboratory test wheel than the minimum required by law.

Temperature grade for this tire
The temperature grade for this tire is established for a tire that is properly inflated and not overloaded. Excessive speed, underinflation, or excessive loading, either separately or in combination, can cause heat buildup and possible tire failure.

If necessary, have the vehicle towed. ◀

#### RSC - Run-flat tires

Run-flat tires, refer to page 214, are labeled with a circular symbol containing the letters RSC marked on the sidewall.

#### M+S

Winter and all-season tires with better cold weather performance than summer tires.

## Tire tread

#### **Summer tires**

Do not drive with a tire tread depth of less than 0.12 in/3 mm.

There is an increased danger of hydroplaning if the tread depth is less than 0.12 in/3 mm.

#### Winter tires

Do not drive with a tire tread depth of less than 0.16 in/4 mm.

Below a tread depth of 0.16 in/4 mm, tires are less suitable for winter operation.

#### Minimum tread depth



Wear indicators are distributed around the tire's circumference and have the legally required minimum height of 0.063 in/1.6 mm.

They are marked on the side of the tire with TWI, Tread Wear Indicator.

## **Tire damage**

#### **General information**

Inspect your tires often for damage, foreign objects lodged in the tread, and tread wear.

#### **Notes**

Driving over rough or damaged road surfaces, as well as debris, curbs and other obstacles can cause serious damage to wheels, tires and suspension parts. This is more likely to occur with low-profile tires, which provide less cushioning between the wheel and the road. Be careful to avoid road hazards and reduce your speed, especially if your vehicle is equipped with low-profile tires.

Indications of tire damage or other vehicle defects:

- Unusual vibrations during driving.
- Unusual handling such as a strong tendency to pull to the left or right.

Damage can, e. g., be caused by driving over curbs, road damage, or similar things.

In case of tire damage

If there are indications of tire damage, reduce your speed immediately and have the wheels and tires checked right away; otherwise, there is the increased risk of an accident.

Drive carefully to the nearest service center. If necessary, have the vehicle towed.

Otherwise, tire damage can be life-threatening for vehicle occupants and other traffic participants. ◀

Repair of tire damage

For safety reasons, the manufacturer of your vehicle recommends that you do not have damaged tires repaired; they should be replaced. Otherwise, damage can occur as a result.

## **Changing wheels and tires**

#### **Mounting**

Information on mounting tires
Have mounting and balancing performed only by a service center.

If this work is not carried out properly, there is the danger of subsequent damage and related safety hazards.◀

#### Wheel and tire combination

Information on the correct wheel-tire combination and rim versions for your vehicle can be obtained from your service center.

Incorrect wheel and tire combinations impair the function of a variety of systems such as ABS or DSC.

To maintain good handling and vehicle response, use only tires with a single tread configuration from a single manufacturer.

Following tire damage, have the original wheel and tire combination remounted on the vehicle as soon as possible.

Approved wheels and tires

The manufacturer of your vehicle recommends that you use only wheels and tires that have been approved for your particular vehicle model.

For example, despite having the same official size ratings, variations can lead to body contact and with it, the risk of severe accidents.

The manufacturer of your vehicle cannot evaluate non-approved wheels and tires to determine if they are suited for use, and therefore cannot ensure the operating safety of the vehicle if they are mounted. ◀

#### Recommended tire brands



For each tire size, the manufacturer of your vehicle recommends certain tire brands. These can be identified by a star on the tire sidewall.

With proper use, these tires meet the highest standards for safety and handling.

#### **New tires**

Due to technical factors associated with their manufacture, tires do not achieve their full traction potential until after an initial breakingin period.

Drive conservatively for the first 200 miles/300 km.

#### **Retreaded tires**

The manufacturer of your vehicle does not recommend the use of retreaded tires.

#### Retreaded tires

Possibly substantial variations in the design and age of the tire casing structures can limit service life and have a negative impact on road safety.

#### Winter tires

The manufacturer of your vehicle recommends winter tires for winter roads or at temperatures below +45 °F/+7 °C.

Although so-called all-season M+S tires do provide better winter traction than summer tires, they do not provide the same level of performance as winter tires.

#### **Maximum speed of winter tires**

If the maximum speed of the vehicle is higher than the permissible speed for the winter tires, then display a corresponding sign in the field of vision. You can obtain this sign from the tire specialist or from your service center.

Maximum speed for winter tires

Do not exceed the maximum speed for
the winter tires; otherwise, tire damage and accidents can occur.

#### Run-flat tires

If you are already using run-flat tires, for your own safety you should replace them only with the same kind. No spare tire is available in the case of a flat tire. Your service center will be glad to advise you.

### Rotating wheels between axles

The manufacturer of your vehicle advises against switching wheels between the front and rear axles.

This can impair the handling characteristics.

#### Storage

Store wheels and tires in a cool, dry place with as little exposure to light as possible.

Always protect tires against all contact with oil, grease and fuels.

Do not exceed the maximum tire inflation pressure indicated on the side wall of the tire.

#### **Run-flat tires**

#### Label



RSC label on the tire sidewall.

The wheels are composed of special rims and tires that are self-supporting, to a limited degree.

The support of the sidewall allows the tire to remain drivable to a restricted degree in the event of a pressure loss.

Continued driving with a damaged tire, refer to page 108.

Continued driving with a damaged tire, refer to page 105.

### **Changing run-flat tires**

For your own safety, only use run-flat tires. No spare tire is available in the case of a flat tire. Your service center will be glad to advise you.

## **Snow chains**

#### Fine-link snow chains

Only certain types of fine-link snow chains have been tested by the manufacturer of your vehicle, classified as road-safe and recommended.

Consult your service center for more information.

#### Use

Use only in pairs on the rear wheels, equipped with the tires of the following size:

- ▶ 255/55 R 18.
- > 255/50 R 19.

Follow the chain manufacturer's instructions.

Make sure that the snow chains are always sufficiently tight. Retighten as needed according to the chain manufacturer's instructions.

Do not initialize the Flat Tire Monitor after mounting snow chains, as doing so may result in incorrect readings.

Do not initialize the Tire Pressure Monitor after mounting snow chains, as doing so may result in incorrect readings.

When driving with snow chains, briefly activate Dynamic Traction Control if necessary.

#### Maximum speed with snow chains

Do not exceed a speed of 30 mph/50 km/h when using snow chains.


## **Engine compartment**

## Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equip-

ment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

## Important features in the engine compartment



- Washer fluid reservoir
- 2 Vehicle identification number
- 3 Jump-starting, positive terminal
- 4 Coolant reservoir

- 5 Jump-starting, negative terminal
- 6 Oil filler neck
- 7 Filler neck for reducing agent

### Hood

## **Opening the hood**

Working in the engine compartment
Never attempt to perform any service or
repair operations on your vehicle without the
necessary professional technical training.

If you are unfamiliar with the statutory guidelines, have any work on the vehicle performed only by a service center.

If this work is not carried out properly, there is the danger of subsequent damage and related safety hazards.◀




Never reach into the engine compartment

Never reach into the intermediate spaces or gaps in the engine compartment. Otherwise, there is risk of injury, e.g., from rotating or hot parts.◀

1. Pull the lever.



Press the release handle and open the hood.




Be careful of protruding parts on the hood.



Danger of injury when the hood is open There is a danger of injury from protruding parts when the hood is open. ◄

#### Closing the hood



Let the hood drop from a height of approx. 16 in/40 cm and push down on it to lock it fully.

The hood must audibly engage on both sides.

Hood open when driving
If you see any signs that the hood is not
completely closed while driving, pull over immediately and close it securely.

✓

Danger of pinching
Make sure that the closing path of the
hood is clear; otherwise, injuries may result.

✓

# **Engine oil**

# Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

### **General information**

The engine oil consumption is dependent on the driving style and driving conditions. When a sporty driving style is used, the engine oil consumption, for example, is clearly higher.

Therefore, regularly check the engine oil level after refueling.

# Checking the oil level electronically

### Status display

### The concept

The oil level is monitored electronically during driving and shown on the Control Display.

If the oil level reaches the minimum level, a check control message is displayed.

### Requirements

Depending on the previous displays, the status display is displayed when the engine is running or after the vehicle has been driven for at least 30 minutes.

### Displaying the oil level

- "Vehicle Info"
- "Vehicle status"

### 3. "Engine oil level"

### Oil level display messages

Different messages appear on the display depending on the oil level. Pay attention to these messages.

If oil level is too low, immediately add 1 US quart/liter of oil.

Take care not to add too much engine oil.

Too much engine oil
Have the vehicle checked immediately;
otherwise, surplus oil can lead to engine damage.

✓

### **Detailed measurement**

### The concept

In the detailed measurement the oil level is checked and displayed via a scale.

During the measurement, the idle speed is increased somewhat.

### General information

A detailed measurement is only possible with certain engines.

### Requirements

- Automatic transmission: selector lever in transmission position N or P and accelerator not depressed.
- Vehicle is on a level road and the engine is running at operating temperature.

### Performing a detailed measurement

In order to perform a detailed measurement of the engine oil level:

- 1. "Vehicle Info"
- "Vehicle status"

- "Measure engine oil level"
- "Start measurement"

The oil level is checked and displayed via a scale.

Duration: approx. 1 minute.

# Adding engine oil

### Filler neck



When the indicator lights up in the instrument cluster, add 1 US quart/liter of engine oil within the next 125 miles/200 km.

Protect children

Keep oil, grease, etc., out of reach of children and heed the warnings on the containers to prevent health risks.◄

# Oil types for refilling

### Hints

No oil additives

Oil additives may lead to engine dam-

age.◀

Viscosity grades for engine oils

When selecting an engine oil, ensure that the engine oil belongs to one of the viscosity grades SAE 0W-40, SAE 0W-30, SAE 5W-40, and SAE 5W-30 or malfunctions or engine damage may occur.

The engine oil quality is critical for the life of the engine.

Some types of oils in some cases are not available in all countries.

### Approved oil types

### Gasoline engine

BMW High Performance SAE 5W-30.

BMW Longlife-01.

BMW Longlife-01 FE.

Additional information about the approved types of oils can be requested from the service center.

### Alternative oil types

If the approved engine oils are not available, up to 1 US quart/liter of an oil with the following specification can be added:

### Gasoline engine

API SM or superior grade specification.

# Oil change

An oil change should be carried out by your service center only.

### BMW recommends (= Castrol /



# Coolant

# Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

### **General information**

Danger of burns from hot engine
Do not open the cooling system while
the engine is hot; otherwise, escaping coolant
may cause burns. ◄

Suitable additives
Only use suitable additives; otherwise, engine damage may occur. The additives are harmful to your health.

✓

Coolant consists of water and additives.

Not all commercially available additives are suitable for your vehicle. Ask your service center for suitable additives.

### **Coolant level**

If there is no Min. and Max. mark in the filler neck of the coolant reservoir, have the coolant level checked if necessary by your service center and add coolant as needed.

### Checking

- 1. Let the engine cool.
- 2. Turn the cap of the coolant reservoir slightly counterclockwise to allow any ex-

cess pressure to dissipate, and then open it.



The coolant level is correct if it lies between the minimum and maximum marks in the filler neck.



- 4. If the coolant is low, slowly add coolant up to the specified level; do not overfill.
- 5. Turn the cap until there is an audible click. The arrows on the coolant reservoir and the cap must point towards one another.
- 6. Have the cause of the coolant loss eliminated as soon as possible.

# **Disposal**



Comply with the relevant environmental protection regulations when disposing of coolant and coolant additives.

# **Maintenance**

### Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

# **BMW Maintenance System**

The maintenance system directs you to required maintenance measures and thereby supports you in maintaining road safety and the operational reliability of the vehicle.

# **Condition Based Service CBS**

Sensors and special algorithms take into account the driving conditions of your vehicle. Based on this, Condition Based Service determines the maintenance requirements.

The system makes it possible to adapt the amount of maintenance you need to your user profile.

Details on the service requirements, refer to page 88, can be displayed on the Control Display.

### Service data in the remote control

Information on the required maintenance is continuously stored in the remote control. Your service center will read out this data and suggest the right array of service procedures for your vehicle.

Therefore, hand your service specialist the remote control with which the vehicle was driven most recently.

### Storage periods

Storage periods during which the vehicle battery was disconnected are not taken into account.

If this occurs, have a service center update the time-dependent maintenance procedures, such as checking brake fluid and, if necessary, changing the engine oil and the microfilter/activated-charcoal filter.

### **Service history**

Perform maintenance work at the service center and have them recorded in the vehicle data. The entries are like a service booklet of the documentation of regular maintenance.

Displaying entered maintenance work on the Control Display, refer to page 89.

# Service and Warranty Information Booklet for US models and Warranty and Service Guide Booklet for Canadian models

Please consult your Service and Warranty Information Booklet for US models and Warranty and Service Guide Booklet for Canadian models for additional information on service requirements.

Maintenance and repair should be performed by your service center. Make sure to have regular maintenance procedures recorded in the vehicle's Service and Warranty Information Booklet for US models, and in the Warranty and Service Guide Booklet for Canadian models. These entries are proof of regular maintenance.

# Socket for OBD Onboard Diagnosis

### **Position**




There is an OBD socket on the driver's side for checking the primary components in the vehicle emissions.

### **Emissions**



The warning lamp lights up:



Canadian model: warning light indicates the engine symbol.

▶ The warning lamp flashes under certain circumstances:

This indicates that there is excessive misfiring in the engine.

Reduce the vehicle speed and have the system checked immediately; otherwise, serious engine misfiring within a brief period can seriously damage emission control components, in particular the catalytic converter.

### **Fuel cap**



The indicator lamp lights up.

If the fuel cap is not properly tightened, the OBD system may conclude that fuel vapor is escaping. If the cap is then tightened, the display should go out in a short time.


# **Replacing components**

## Vehicle equipment


All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

### Onboard vehicle tool kit

1. Raise the cargo floor panel.



Remove the onboard vehicle tool kit.



### Wiper blade replacement

#### Hints



Do not fold down the wipers without wiper blades

Do not fold down the wipers if wiper blades have not been installed; this may damage the windshield.◀



Folding down wipers before opening the hood


Before opening the hood, ensure that the wiper arms with the wiper blades are against the windshield to prevent damage. ◄

### Front: Replacing the wiper blades

- 1. To change the wiper blades, fold up, refer to page 75, the wiper arms.
- Lift the wiper all the way off of the windshield.



3. Fold open the holder.




4. Slide wiper blade out of the wiper arm.



- Insert the new wiper blade and press it on until it you hear it snap into the holder.
- 6. Fold down the wipers.

### Rear: replacing the wiper blades

 Lift off the wiper fully and pull off the wiper blade, arrow.



- 2. Attach a new wiper blade. It must engage audibly.
- 3. Fold down the wipers.

# Lamp and bulb replacement

#### Hints

### Lamps and bulbs

Lamps and bulbs make an essential contribution to vehicle safety.

The manufacturer of the vehicle recommends that you entrust corresponding procedures to the service center if you are unfamiliar with them or they are not described here.

You can obtain a selection of replacement bulbs at the service center.

Danger of burns

Only change bulbs when they are cool; otherwise, there is the danger of getting burned. ◀

Working on the lighting system
When working on the lighting system,
you should always switch off the lights affected to prevent short circuits.

To avoid possible injury or equipment damage when replacing bulbs, observe any instructions provided by the bulb manufacturer. ◀

A

Do not perform work/bulb replacement on xenon headlamps

Have any work on the xenon lighting system, including bulb replacement, performed only by a service center. Due to the high voltage present in the system, there is the danger of fatal injuries if work is carried out improperly. ◀

Do not touch the bulbs

Do not touch the glass of new bulbs with your bare hands, as even minute amounts of contamination will burn into the bulb's surface and reduce its service life.

Use a clean tissue, cloth or something similar, or hold the bulb by its base.◀

### **Light-emitting diodes (LEDs)**

Light-emitting diodes installed behind a cover serve as the light source for controls, display elements and other equipment.

These light-emitting diodes, which are related to conventional lasers, are officially designated as Class 1 light-emitting diodes.

Do not remove the covers

Do not remove the covers, and never stare into the unfiltered light for several hours; otherwise, irritation of the retina could result.

### **Headlamp glass**

Condensation can form on the inside of the external lamps in cool or humid weather. When driving with the light switched on, the condensation evaporates after a short time. The head-lamp glasses do not need to be changed.

If the headlamps do not dim despite driving with the light switched on, increasing humidity forms, e. g. water droplets in the light, have the service center check this.


### **Headlamp setting**

The headlamp adjustments can be affected by changing lamps and bulbs. Therefore after a change, have the headlamp setting checked and corrected by Service.

### Front lamps, bulb replacement

### At a glance

### Xenon headlamps



- Corner-illuminating lamps
- 2 Parking lamps / daytime running lights
- 3 Low beams/high beams/headlamp flasher
- 4 Turn signal/side marker light

### **Xenon headlamps**

Because of the long life of these bulbs, the likelihood of failure is very low. Switching the lamps on and off frequently shortens their life.

If a xenon bulb fails, switch on the front fog lamps and continue the trip with great care. Comply with local regulations.



Do not perform work/bulb replacement on xenon headlamps

Have any work on the xenon lighting system, including bulb replacement, performed only by a service center. Due to the high voltage present in the system, there is the danger of fatal injuries if work is carried out improperly. ◄

For checking and adjusting headlamp aim, please contact your BMW center.

### **Xenon headlamps**

Low beams and high beams are designed with xenon technology.

The parking lamps and daylight running lights are made using LED technology.

Contact your service center in the event of a malfunction.

### **LED** headlamps

### **Light-emitting diodes (LEDs)**

Follow the general instructions on Lamps and bulbs, refer to page 223.

With LED headlamps, all front lamps and side indicators are designed with LED technology. If an LED fails, switch on the front fog lamps

and continue the trip with great care. Comply with local regulations.

Contact your service center in the event of a malfunction.


### Front fog lamps

Follow the general instructions on Lamps and bulbs, refer to page 223.

Front fog lamps in vehicles equipped with Adaptive Light Control: 55-watt bulb, H11.

Front fog lamps without Adaptive Light Control: 35-watt bulb, H8.


 Insert the screwdriver from the onboard vehicle tool kit, with the flat side facing outward, past the removal hook and onto the clip, arrow 1.




- 2. Turn the screwdriver by 90°, arrow 2.
- Press the removal hook upward, arrow, and remove the front fog lamp from the front using the hook.



4. Detach the connector.



5. Turn the bulb bracket and remove it.



- 6. Remove the bulb and replace it.
- Proceed in reverse order to insert the front fog lamp. Note the guide rails in doing so.

### **LED front fog lamps**

Follow the general instructions on Lamps and bulbs, refer to page 223.

These front fog lamps are made using LED technology. Contact your service center in the event of a malfunction.

### Turn signal


Follow the general instructions on Lamps and bulbs, refer to page 223.

The turn signals are located next to each low beam in the engine compartment.

21-watt bulb, PY 21W.

- 1. Opening the hood, refer to page 215
- Unscrew the cap counterclockwise and remove it carefully.

The bulb is attached to the cap.



- 3. Turn the bulb clockwise to remove it.
- 4. Insert the new bulb and attach the cover in the reverse order.

### Lateral turn signals

Follow the general instructions on Lamps and bulbs, refer to page 223.

These lamps are made using LED technology.

Please contact your service center in the event of a malfunction.

### Tail lamps, bulb replacement

### **LED tail lamps**

These tail lamps are made using LED technology. Contact your service center in the event of a malfunction.

# **Changing wheels**


### **Hints**

With three rows of seats, the vehicle equipment does not include a spare tire.

When using run-flat tires or tire sealants, a tire does not need to be changed immediately in the event of pressure loss due to a flat tire.

The tools for changing wheels are available as accessories from your service center.

### Jacking points for the vehicle jack



The jacking points for the vehicle jack are located at the positions shown.

### Compact wheel

#### Hints



Safety measures in case of a breakdown or a wheel change

- Park the vehicle as far away as possible from passing traffic and on solid ground.
   Switch on the hazard warning system.
- ▶ Set the parking brake and engage transmission position P.
- Have all vehicle occupants get out of the vehicle and ensure that they remain outside the immediate area in a safe place, such as behind a quardrail.
- If necessary, set up a warning triangle or portable hazard warning lamp at an appropriate distance. Comply with all safety quidelines and regulations.
- Perform wheel change only on a flat, solid and slip-resistant surface. On soft or slippery ground, e.g., snow, ice, tiles, etc., the vehicle or vehicle jack can slip away to the side.
- Do not place wood blocks or similar items under the vehicle jack; otherwise, it cannot reach its carrying capacity because of the restricted height.
- ▶ If the vehicle is raised, do not lie under the vehicle and do not start the engine; otherwise, a mortal hazard exists.



Use the vehicle jack only for changing wheels

Use the vehicle jack only for changing wheels Do not attempt to use it to jack up a different type of vehicle or loads of any kind; otherwise, this could cause material damage and personal injury.◀


### At a glance

The compact wheel and the tools are located in the cargo area under the cargo floor cover.



- Compact wheel
- 2 Vehicle jack
- 3 Vehicle jack crank
- 4 Wheel lug wrench

### Remove compact wheel




- 1. Remove tool holder.
- 2. Unscrew the wing nut 1.
- 3. Remove the washer 2 to the side.
- 4. Remove compact wheel.

### Prepare wheel change

- 1. Follow the Safety instructions, refer to page 226.
- 2. Loosen the wheel lug bolts a half turn.

### Jacking up the vehicle

 Place the vehicle jack at the jacking point closest to the wheel such that the vehicle jack foot is vertically beneath the vehicle jacking point with the entire surface on the ground.



- Insert the vehicle jack head in the rectangular recess of the jacking point for cranking it up.
- Crank it up until the wheel in question lifts off of the ground.

### Wheel mounting

- Unscrew the wheel lug bolts and remove the wheel.
- 2. Put the new wheel or compact wheel on and screw in at least two bolts.
  - If original BMW light alloy wheels are not mounted, any accompanying lug bolts also have to be used.
- Screw in the remaining the lug bolts and tighten all bolts well in a crosswise pattern.
- 4. Lower the vehicle and remove the vehicle jack.

### After the wheel change

 Tighten the lug bolts crosswise. The tightening torque is 101 lb ft/140 Nm.



Check for secure seating of the lug bolts

For safety reasons, have the secure seating of the lug bolts checked with a calibrated torque wrench; otherwise, a safety hazard results from incorrectly tightened lug bolts.◀

2. Stow the defective wheel in the cargo area.

The defective wheel cannot be stored under the cargo floor cover because of its size.

- Check tire inflation pressure at the next opportunity and correct as needed.
- 4. Reinitialize the Flat Tire Monitor, refer to page 107.
  - Reinitialize the Tire Pressure Monitor, refer to page 104.
- Replace the damaged tires as soon as possible.

### **Driving with the compact wheel**



Watch the speed when driving with the compact wheel

Drive conservatively and do not exceed a speed of 50 mph/80 km/h; otherwise, changed driving characteristics such as reduced lane stability while braking, extended braking distance and changed self-steering properties in the limit area.

Mounting only one compact wheel
Only a single compact wheel may be
mounted. Reinstall wheels and tires of the
original size as quickly as possible; otherwise,
there is a safety risk.◀

### **Vehicle battery**

### **Maintenance**

The battery is maintenance-free, i.e., the electrolyte will last for the life of the battery.

Your service center will be glad to advise you on questions regarding the battery.

### **Battery replacement**

Use approved vehicle batteries only
Only use vehicle batteries that have been approved for your vehicle by the manufacturer; otherwise, the vehicle could be damaged and

systems or functions may not be fully available. ◄

After a battery replacement, have the battery registered on the vehicle by your service center to ensure that all comfort functions are fully available and that any Check Control messages of these comfort functions are no longer displayed.

### Charging the battery

### Note

Do not plug chargers into the socket
Do not connect battery chargers to the
factory-installed sockets in the vehicle as this
may damage the battery.

### **General information**

Make sure that the battery is always sufficiently charged to guarantee that the battery remains usable for its full service life.

The battery may need to be charged in the following cases:

- When making frequent short-distance drives.
- If the vehicle is not used for prolonged periods, longer than a month.

### **Starting aid terminals**

In the vehicle, only charge the battery via the starting aid terminals, refer to page 232, in the engine compartment with the engine off.

### **Power failure**

After a temporary power loss, some equipment needs to be reinitialized.

Individual settings need to be reprogrammed:

- Time: update.
- Date: update.
- Radio station: saving new, see user's manual for Navigation, Entertainment and Communication.

Navigation system: wait for the operability of the navigation.

### **Disposing of old batteries**



Have old batteries disposed of by your service center or bring them to a recycling center.

Maintain the battery in an upright position for transport and storage. Secure the battery so that it does not tip over during transport.

### **Fuses**

### **Notes**

Replacing fuses

Never attempt to repair a blown fuse and do not replace a defective fuse with a substitute of another color or amperage rating; this could lead to a circuit overload, ultimately resulting in a fire in the vehicle. ◀

Plastic tweezers and information on the fuse types and locations are stored in the fuse box in the cargo area.

### In the passenger compartment



Loosen fasteners, arrows, and open cover.

### In the cargo area



Open the cover on the right side trim.

Information on the fuse types and locations is found on a separate sheet.

# **Breakdown assistance**

# Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

# **Hazard warning flashers**



The button is located in the center console.

# Intelligent Emergency Request

### Requirements

- The radio ready state is switched on.
- ▶ The Assist system is functional.
- The SIM card integrated in the vehicle has been activated.
- A ConnectedDrive contract is available.

#### General information

Only press the SOS button in an emergency.

### Hints

Emergency Request not guaranteed For technical reasons, the Emergency Request cannot be guaranteed under unfavorable conditions.

### **Initiating an Emergency Request**



- 1. Press the cover briefly to open it.
- Press the SOS button until the LED in the button lights up.
- ▶ The LED lights up: an Emergency Request was initiated
  - If the situation allows, wait in your vehicle until the voice connection has been established.
- The LED flashes when a connection to the BMW Response Center has been established.

When the emergency request is received at the BMW Response Center, the BMW Response Center contacts you and takes further steps to help you.

Even if you are unable to respond, the BMW Response Center can take further steps to help you under certain circumstances.

For this purpose, data that are used to determine the necessary rescue measures, such as the current position of the vehicle if it can be established, are transmitted to the BMW Response Center.

If the LED is flashing, but the BMW Response Center can no longer be heard via the speaker, you can nevertheless still be heard for the BMW Response Center.

# Initiating an Emergency Request automatically


Under certain conditions, an Emergency Request is automatically initiated immediately after a severe accident. Automatic Collision Notification is not affected by pressing the SOS button.

# Warning triangle

1. Open the cover on the left side trim.



2. To remove, loosen the bracket.



### First aid kit

### Note

Some of the articles have a limited service life.

Check the expiration dates of the contents regularly and replace any expired items promptly.

### **Storage**

1. Open the cover on the left side trim.



Remove the first aid kit.



# **Roadside Assistance**

### Service availability

Roadside Assistance can be reached around the clock in many countries. You can obtain assistance there in the event of a vehicle breakdown.

### Roadside Assistance

The Roadside Assistance phone number can be viewed on the iDrive or a connection to Roadside Assistance can be established directly.

### **Jump-starting**

### **Notes**

If the battery is discharged, an engine can be started using the battery of another vehicle and two jumper cables. Only use jumper cables with fully insulated clamp handles.

To prevent personal injury or damage to both vehicles, adhere strictly to the following procedure.

Do not touch live parts
To avoid the risk of potentially fatal injury, always avoid all contact with electrical components while the engine is running.

✓

### **Preparation**

- Check whether the battery of the other vehicle has a voltage of 12 volts. This information can be found on the battery.
- Switch off the engine of the assisting vehicle.
- Switch off any electronic systems/power consumers in both vehicles.


Bodywork contact between vehicles

Make sure that there is no contact between the bodywork of the two vehicles; otherwise, there is the danger of short circuits.

✓

### Starting aid terminals

Connecting order
Connect the jumper cables in the correct
order; otherwise, there is the danger of injury
from sparking.◀



The so-called starting aid terminal in the engine compartment acts as the battery's positive terminal.



The body ground or a special nut acts as the battery negative terminal.

### **Connecting the cables**

- Pull off the cap of the BMW starting aid terminal.
- Attach one terminal clamp of the positive jumper cable to the positive terminal of the battery, or to the corresponding starting aid terminal of the vehicle providing assistance.
- Attach the terminal clamp on the other end of the cable to the positive terminal of the battery, or to the corresponding starting aid terminal of the vehicle to be started.
- Attach one terminal clamp of the negative jumper cable to the negative terminal of the battery, or to the corresponding engine or body ground of assisting vehicle.
- 5. Attach the second terminal clamp to the negative terminal of the battery, or to the

corresponding engine or body ground of the vehicle to be started.

### Starting the engine

Never use spray fluids to start the engine.

- Start the engine of the assisting vehicle and let it run for several minutes at an increased idle speed.
- 2. Start the engine of the vehicle being started in the usual way.

If the first starting attempt is not successful, wait a few minutes before making another attempt in order to allow the discharged battery to recharge.

- 3. Let both engines run for several minutes.
- Disconnect the jumper cables in the reverse order.

Check the battery and recharge if necessary.

# **Tow-starting and towing**

### **Transporting your vehicle**


#### Note

Your vehicle is not permitted to be towed. Therefore, contact a service center in the event of a breakdown.

Do not have the vehicle towed
Have your vehicle transported on a loading platform only; otherwise, damage may occur.

✓

### Tow truck



Do not lift the vehicle

Do not lift the vehicle by the tow fitting or
body and chassis parts; otherwise, damage
may result.

✓

### **Towing other vehicles**

### General information

Light towing vehicle
The towing vehicle must not be lighter
than the vehicle being towed; otherwise, it will
not be possible to control the vehicle response.

- Switch on the hazard warning system, depending on local regulations.
- If the electrical system has failed, clearly identify the vehicle being towed by placing a sign or a warning triangle in the rear window.

# Towing methods when towing other vehicles

### Tow bar

The tow fittings used should be on the same side on both vehicles.

Should it prove impossible to avoid mounting the tow bar at an offset angle, please observe the following:

- Maneuvering capability is limited during cornering.
- The tow bar will generate lateral forces if it is secured with an offset.

### Tow rope

When starting to tow the vehicle, make sure that the tow rope is taut.


To avoid jerking and the associated stresses on the vehicle components when towing, always use nylon ropes or nylon straps.

Attaching the tow rope correctly

Only secure the tow rope on the tow fitting; otherwise, damage can occur when it is secured on other parts of the vehicle.

✓

### **Tow fitting**



The screw-in tow fitting should always be carried in the vehicle. It can be screwed in at the front or rear of the BMW. It is located in the onboard vehicle tool kit under the cargo area floor.



Tow fitting, information on use

- Use only the tow fitting provided with the vehicle and screw it all the way in.
- Use the tow fitting for towing on paved roads only.
- Use the tow fitting screwed in at the front for maneuvering the vehicle only.

Avoid lateral loading of the tow fitting, e.g., do not lift the vehicle by the tow fitting.

Otherwise, damage to the tow fitting and the vehicle can occur.◀

### Screw thread



Press on the mark of the cover to push it out.

### **Tow-starting**

### **Automatic transmission**

Do not tow-start the vehicle.

Due to the automatic transmission, the engine cannot be started by tow-starting.

Have the cause of the starting difficulties remedied

# Care

# Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equipment is also described that is not available in a vehicle, e. g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.

### **Car washes**

### **Hints**

Steam jets or high-pressure washers When using steam jets or high-pressure washers, hold them a sufficient distance away and use a maximum temperature of 140 °F/60 °C.

If the vehicle has a glass sunroof, ensure that a distance of at least 31.5 inches/80 cm is maintained. Holding them too close or using excessively high pressures or temperatures can cause damage or preliminary damage that may then lead to long-term damage.

Follow the user's manual for the high-pressure washer.◀



Cleaning sensors/cameras with highpressure washers

When using high-pressure washers, do not spray the exterior sensors and cameras, e.g., Park Distance Control, for extended periods of time and only from a distance of at least 12 in/30 cm. ◀

Regularly remove foreign items such as leaves in the area below the windshield when the hood is raised.

Wash your vehicle frequently, particularly in winter.

Intense soiling and road salt can damage the vehicle.

### Automatic car washes

### **Hints**

Note the following:

- Give preference to cloth car washes or those that use soft brushes in order to avoid paint damage.
- Make sure that the wheels and tires are not damaged by the transport mechanisms.
- Fold in the exterior mirrors; otherwise, they may be damaged, depending on the width of the vehicle.
- Deactivate the rain sensor, refer to page 74, to avoid unintentional wiper activation.
- In some cases, an unintentional alarm can be triggered by the interior motion sensor of the alarm system. Follow the instructions on avoiding an unintentional alarm, refer to page 45.

Guide rails in car washes

Avoid car washes with guide rails higher
than 4 in/10 cm; otherwise, the vehicle body
could be damaged.◄

### Before driving into a car wash

In order to ensure that the vehicle can roll in a car wash, take the following steps:

- Drive into the car wash.
- 2. Engage transmission position N.
- Switch the engine off.
   In this way, the ignition remains switched on, and a Check-Control message is displayed.



Do not turn off the ignition in the car wash

Do not turn off the ignition in the car wash; otherwise, the transmission position P is engaged and damages can result.◀

To start the engine:

- 1. Depress the brake pedal.
- 2. Press the Start/Stop button.

Pressing the Start/Stop button without stepping on the brake turns the ignition off.

The vehicle cannot be locked from the outside when in transmission position N. A signal is sounded when an attempt is made to lock the vehicle.

### **Different types of tires**

Observing vehicle width
Before entering washing systems, make
sure that the vehicle width is not too great for
the car wash; otherwise, there could be damage to the vehicle and car wash.

### **Transmission position**

Transmission position P is engaged automatically:

- When the ignition is switched off.
- After approx. 15 minutes.

### **Headlamps**

- Do not rub dry and do not use abrasive or caustic cleansers.
- Soak areas that have been soiled e.g. due to insects, with shampoo and wash off with water.
- Thaw ice with deicing spray; do not use an ice scraper.

### After washing the vehicle

After washing the vehicle, apply the brakes briefly to dry them; otherwise, braking action

can be reduced and corrosion of the brake discs can occur.

Completely remove all residues on the windows, to minimize loss of visibility due to smearing and to reduce wiper noises and wiper blade wear.

### Vehicle care

### Car care products

BMW recommends using cleaning and care products from BMW, since these have been tested and approved.



Car care and cleaning products

Follow the instructions on the container.

When cleaning the interior, open the doors or windows.

Only use products intended for cleaning vehicles.

Cleansers can contain substances that are dangerous and harmful to your health. ◀

### Vehicle paint

Regular care contributes to driving safety and value retention. Environmental influences in areas with elevated air pollution or natural contaminants, such as tree resin or pollen can affect the vehicle's paintwork. Tailor the frequency and extent of your car care to these influences.

Aggressive substances, such as spilled fuel, oil, grease or bird droppings, must be removed immediately to prevent the finish from being altered or discolored.

### Leather care

Remove dust from the leather often, using a cloth or vacuum cleaner.

Otherwise, particles of dust and road grime chafe in pores and folds, and lead to increased wear and premature degradation of the leather surface.

To guard against discoloration, such as from clothing, provide leather care roughly every two months.

Clean light-colored leather more frequently because soiling on such surfaces is substantially more visible.

Use leather care products; otherwise, dirt and grease will gradually break down the protective layer of the leather surface.

Suitable care products are available from the service center.

### **Upholstery material care**

Vacuum regularly with a vacuum cleaner.

If they are very dirty, e.g., beverage stains, use a soft sponge or microfiber cloth with a suitable interior cleaner.

Clean the upholstery down to the seams using large sweeping motions. Avoid rubbing the material vigorously.

Damage from Velcro® fasteners
Open Velcro® fasteners on pants or
other articles of clothing can damage the seat
covers. Ensure that any Velcro® fasteners are
closed.

### **Caring for special components**

### **Light-alloy wheels**

When cleaning the vehicle, use only neutral wheel cleaners having a pH value from 5 to 9. Do not use abrasive cleaning agents or steam jets above 140 °F/60 °C. Follow the manufacturer's instructions.

Aggressive, acidic or alkaline cleaning agents can destroy the protective layer of adjacent components, such as the brake disk.

### **Chrome surfaces**

Carefully clean components such as the radiator grille or door handles with an ample supply of water, possibly with shampoo added, partic-

ularly when they have been exposed to road salt.

### **Rubber components**

Aside from water, treat only with rubber cleansers.

When cleaning rubber seals, do not use any silicon-containing car care products in order to avoid damage or reduced noise damping.

### Fine wood parts

Clean fine wood facing and fine wood components only with a moist rag. Then dry with a soft cloth.

### **Plastic components**

These include:

- Imitation leather surfaces.
- Headliner.
- Lamp lenses.
- Instrument cluster cover.
- Matte black spray-coated components.
- Painted parts in the interior.

Clean with a microfiber cloth.

Lightly dampen the cloth with water.

Do not soak the headliner.



Do not use cleansers that contain alcohol or solvents

Do not use cleansers that contain alcohol or solvents, such as lacquer thinners, heavy-duty grease removers, fuel, or such; this could lead to surface damage.◀

### Safety belts

Dirty belt straps impede the reeling action and thus have a negative impact on safety.

Chemical cleaning

Do not clean chemically; this can destroy the webbing. ◄

Use only a mild soapy solution, with the safety belts clipped into their buckles.

Do not allow the reels to retract the safety belts until they are dry.

### **Carpets and floor mats**

No objects in the area around the pedals Keep floor mats, carpets, and any other objects out of the area of motion of the pedals; otherwise, the function of the pedals could be impeded while driving

Do not place additional floor mats over existing mats or other objects.

Only use floor mats that have been approved for the vehicle and can be properly fixed in place.

Ensure that the floor mats are securely fastened again after they were removed for cleaning, for example. ◀

Floor mats can be removed from the passenger compartment for cleaning.

If the floor carpets are very dirty, clean with a microfiber cloth and water or a textile cleaner. To prevent matting of the carpet, rub back and forth in the direction of travel only.

#### Sensors/cameras

To clean sensors and cameras, use a cloth moistened with a small amount of glass cleaner.

### Displays/screens

Clean the displays with an antistatic microfiber cloth.

Cleaning displays

Do not use chemical or household cleansers.

Keep all fluids and moisture away from the unit.

Otherwise, they could affect or damage surfaces or electrical components.

Avoid pressing too hard when cleaning and do not use abrasive materials; otherwise, damage can result. ◀

### Long-term vehicle storage

Your service center can advise you on what to consider when storing the vehicle for longer than three months.



# Reference

This chapter contains the technical data and an index that will quickly take you to the information you need.

# **Technical data**


# Vehicle equipment

All standard, country-specific and optional equipment that is offered in the model series is described in this chapter. Therefore, equip-

ment is also described that is not available in a vehicle, e.g., because of the selected optional equipment or country variant. This also applies for safety-related functions and systems.


### **Dimensions**

### Width, height



- 1 Vehicle height: 69.4 inches/1,762 mm
- 2 Vehicle width without exterior mirrors: 76.3 inches/1,938 mm
- 3 Vehicle width with exterior mirrors: 86.0 inches/2,184 mm

### Length, wheel base



1 Wheelbase: 115.5 inches / 2,933 mm

**2** Length: 193.2 inches / 4,908 mm

### **Smallest turning circle**

Dia.: 41.8 ft / 12.7 m

# Weights

X5 sDrive35i		
Approved gross vehicle weight with the third row of seats	lbs/kg lbs/kg	6,070/2,753 6,350/2,880
Load with the third row of seats	lbs/kg lbs/kg	1,110/503 1,350/612
Approved front axle load with the third row of seats	lbs/kg lbs/kg	2,670/1,211 2,680/1,216
Approved rear axle load with the third row of seats	lbs/kg lbs/kg	3,540/1,606 3,840/1,742
Approved roof load capacity	lbs/kg	220/100
Cargo area capacity	cu ft/l	22.94-66.03/650-1,870

X5 xDrive35i		
Approved gross vehicle weight with the third row of seats	lbs/kg lbs/kg	6,250/2,835 6,460/2,930
Load with the third row of seats	lbs/kg lbs/kg	1,110/503 1,350/612
Approved front axle load with the third row of seats	lbs/kg lbs/kg	2,820/1,279 2,780/1,261
Approved rear axle load with the third row of seats	lbs/kg lbs/kg	3,580/1,624 3,840/1,742
Approved roof load capacity	lbs/kg	220/100
Cargo area capacity	cu ft/l	22.94-66.03/650-1,870

X5 xDrive50i		
Approved gross vehicle weight with the third row of seats	lbs/kg lbs/kg	6,550/2,971 6,690/3,035
Load with the third row of seats	lbs/kg lbs/kg	1,110/503 1,240/562
Approved front axle load with the third row of seats	lbs/kg lbs/kg	2,990/1,356 2,970/1,347
Approved rear axle load with the third row of seats	lbs/kg lbs/kg	3,700/1,678 3,850/1,746
Approved roof load capacity	lbs/kg	220/100
Cargo area capacity	cu ft/l	22.94-66.03/650-1,870

# **Capacities**

	US gal/liters	Notes
Fuel tank	22.4/85	Fuel quality, refer to page 204
Windshield and headlamp washer system	1.45/5.5	

# **Everything from A to Z**

### Index

### A

ABS, Antilock Brake System 127 ACC, Active Cruise Control with Stop & Go 134 Acceleration Assistant, refer to Launch Control 79 Activated-charcoal filter 164 Active Blind Spot Detection 122 Active Cruise Control with Stop & Go, ACC 134 Active Protection 124 Active roll stabilization, see Dynamic Drive 131 Active seat ventilation, front 52 Active steering 130 Adaptive brake lights, refer to Brake force display 124 Adaptive Light Control 96 Additives, oil 218 Adjustments, seats/head restraints 49 After washing vehicle 236 Airbags 100 Airbags, indicator/warning light 101 Air circulation, refer to Recirculated-air mode 163 Air distribution, manual 162 Air drying, refer to Cooling function 163 Air flow, automatic climate control 162 Air pressure, tires 205 Air vents, refer to Ventilation 164 Alarm system 44

All around the center console 14 All around the headliner 15 All around the steering wheel 12 All-season tires, refer to Winter tires 213 All-wheel-drive 129 Alternating-code hand-held transmitter 172 Alternative oil types 218 Antifreeze, washer fluid 76 Antilock Brake System, **ABS 127** Anti-slip control, refer to **DSC 128** Approved engine oils 218 Arrival time 92 Ashtray 173 Ashtray, front 173 Ashtrav, rear 173 Assistance, Roadside Assistance 231 Assistance when driving off 127 Assist system, refer to Intelligent Safety 108 Attentiveness assistant 124 AUTO H button, refer to Automatic Hold 71 **AUTO intensity 162** Automatic car wash 235 Automatic climate control 161 Automatic Cruise Control with Stop & Go 134 Automatic Curb Monitor 59 Automatic deactivation, front passenger airbags 102 Automatic headlamp control 96

Automatic Hold 71 Automatic locking 43 Automatic recirculated-air control 163 Automatic Soft Closing, doors 38 Automatic tailgate 40 Automatic transmission with Steptronic 76 AUTO program, automatic climate control 162 AUTO program, intensity 162 Auto Start/Stop function 68 Average fuel consumption 92 Average speed 92 Axle loads, weights 243

### B

Backrest curvature, refer to Lumbar support 51 Backrest, width 52 Backup camera 148 Bad road trips 190 Band-aids, refer to First aid kit 231 Bar for tow-starting/ towing 233 Battery replacement, vehicle battery 228 Battery replacement, vehicle remote control 32 Battery, vehicle 228 Belts, safety belts 54 Beverage holder, cupholder 182 Blinds, sun protection 47 BMW Assist, see user's manual for Navigation, Entertainment and Communication

Alarm, unintentional 45

BMW Homepage 6	Car care products 236	Child restraint fixing system
BMW Internet page 6	Care, displays 238	LATCH 64
BMW maintenance sys-	Care, vehicle 236	Child restraint fixing systems,
tem 220	Cargo 192	mounting 62
Bonus range, ECO PRO 197	Cargo area 176	Child safety locks 65
Bottle holder, refer to Cu-	Cargo area, enlarging 176	Child seat, mounting 62
pholder 182	Cargo area lid 38	Child seats 62
Brake assistant 127	Cargo area, storage compart-	Chrome parts, care 237
Brake discs, breaking in 188	ments 183	Cigarette lighter 174
Brake force display 124	Cargo cover 176	Cleaning, displays 238
Brake lamps, brake force dis-	Cargo, securing 193	Climate control 161
play 124	Cargo straps, securing	Climate control wind-
Brake lights, adaptive 124	cargo 193	shield 189
Brake pads, breaking in 188	Car key, refer to Remote con-	Clock 87
Braking, hints 189	trol 32	Closing/opening from in-
Breakdown assis-	Carpet, care 238	side 38
tance 230, 231	Car wash 235	Closing/opening via door
Breaking in 188	Catalytic converter, refer to	lock 37
Brightness of Control Dis-	Hot exhaust system 188	Closing/opening with remote
play 94	CBS Condition Based Serv-	control 36
Bulb replacement 223	ice 220	Clothes hooks 183
Bulb replacement, front 224	CD/Multimedia, see user's	Coasting 198
Bulb replacement, rear 226	manual for Navigation, En-	Coasting with engine decou-
Bulbs and lamps 223	tertainment and Communi-	pled, coasting 198
Button, RES 137	cation	Coasting with idling en-
Button, Start/Stop 66	Center armrest 181	gine 198
Bypassing, refer to Jump-	Center console 14	Cockpit 12
starting 232	Center-Lock, see button for central locking 35	Collision warning with braking function 112
C	Central locking system 35	Collision warning with City
	Central screen, refer to Con-	Braking function 109
California Proposition 65	trol Display 16	Combination switch, refer to
Warning 7	Changes, technical, refer to	Turn signals 73
Calling up mirror adjust-	Safety 7	Combination switch, refer to
ment 43	Changing parts 222	Wiper system 74
Calling up seat adjust-	Changing wheels 226	Comfort Access 42
ment 43	Changing wheels/tires 212	COMFORT program, Driving
Calling up steering wheel ad-	Check Control 84	Dynamics Control 133
justment 43	Checking the oil level elec-	Compact wheel 226
Camera, backup camera 149	tronically 217	Compartments in the
Camera, care 238	Children, seating position 62	doors 180
Camera, Panorama View 153	Children, transporting	Compass 92
Camera, Top View 151	safely 62	Computer 91
Can holder, refer to Cu-	Child restraint fixing sys-	Condensation on win-
pholder 182	tem 62	dows 162

Car battery 228

Condensation under the vehi- cle 190	Departure time, parked-car ventilation 168	DSC Dynamic Stability Con- trol 128
Condition Based Service	Destination distance 92	DTC driving dynamics 129
CBS 220	Digital clock 87	DTC Dynamic Traction Con-
Confirmation signal 43	Dimensions 242	trol 129
Congestion Assistant 140	Dimmable exterior mirrors 59	Dynamic Damping Con-
ConnectedDrive, see user's	Dimmable interior rearview	trol 131
manual for Navigation, En-	mirror 60	Dynamic Drive 131
tertainment and Communi-	Direction indicator, refer to	Dynamic Stability Control
cation	Turn signals 73	DSC 128
ConnectedDrive Services	Display, electronic, instru-	Dynamic Traction Control
Connecting electrical devi-	ment cluster 82	DTC 129
ces 174	Display in windshield 158	2.0.120
Connection for an external	Display lighting, refer to In-	E
audio device 181	strument lighting 98	_
Control Display 16	Displays 80	ECO PRO 196
Control Display, settings 93	Displays, cleaning 238	ECO PRO, bonus range 197
Controller 16, 17	Disposal, coolant 219	ECO PRO display 196
Control systems, driving sta-	Disposal, vehicle battery 229	ECO PRO driving mode 196
bility 127	Distance control, refer to	ECO PRO mode 196
Convenient opening 36	PDC 145	ECO PRO Tip - driving in-
Coolant 219	Distance information 159	struction 197
Coolant temperature 87	Distance to destination 92	EfficientDynamics 198
Cooling function 163	Divided screen view, split	Electronic displays, instru-
Cooling, maximum 163	screen 21	ment cluster 82
Cooling system 219	Door lock, refer to Remote	Electronic Stability Program
Corrosion on brake discs 190	control 32	ESP, refer to DSC 128
Cruise control 143	Doors, Automatic Soft Clos-	Emergency detection, remote
Cruise control, active with	ing 38	control 33
Stop & Go 134	Downhill control 129	Emergency release, door
Cruising range 87	Drink holder, third row of	lock 38
Cupholder 182	seats 183	Emergency release, fuel filler
Current fuel consumption 88	Drive-off assistant 127	flap 202
	Drive-off assistant, refer to	Emergency release, parking
D	DSC 128	brake 72
	Driving Dynamics Con-	Emergency Request 230
Damage, tires 212	trol 131	Emergency service, refer to
Damping Control, dy-	Driving instructions, breaking	Roadside Assistance 231
namic 131	in 188	Emergency start function, en-
Data, technical 242	Driving mode 131	gine start 33
Date 87	Driving notes, general 188	Energy Control 88
Daytime running lights 96	Driving on bad roads 190	Energy recovery 88
Defrosting, refer to Windows, defrosting 162	Driving stability control systems 127	Engine, automatic Start/Stop function 68
Departure time, parked-car	Driving tips 188	Engine, automatic switch-
heating 168	<b>5</b> .	off 68

Engine compartment 215 Engine compartment, working in 215 Engine coolant 219 Engine idling when driving, coasting 198 Engine oil 217 Engine oil, adding 218 Engine oil additives 218 Engine oil change 218 Engine oil filler neck 218 Engine oil temperature 86 Engine oil types, alternative 218 Engine oil types, approved 218 Engine start during malfunction 33 Engine start, jump-starting 232 Engine start, refer to Starting the engine 67 Engine stop 67 Engine temperature 86 Entering a car wash 235 Equipment, interior 171 ESP Electronic Stability Program, refer to DSC 128 Exchanging wheels/tires 212 Exhaust system 188 Exterior mirror, automatic dimming feature 59 Exterior mirrors 58 External start 232 External temperature display 87 External temperature warning 87 Eyes for securing cargo 193

### F

Failure message, refer to Check Control 84 False alarm, refer to Unintentional alarm 45 Fan. refer to Air flow 162 Fault displays, refer to Check Control 84 Filler neck for engine oil 218 Fine wood, care 237 First aid kit 231 Fitting for towing, refer to Tow fitting 234 Flat tire, changing wheels 226 Flat Tire Monitor FTM 107 Flat tire, Tire Pressure Monitor TPM 103 Flat tire, warning lamp 104, 107 Flooding 189 Floor carpet, care 238 Floor mats, care 238 Fold-out position, windshield wipers 75 Foot brake 189 Front airbags 100 Front center armrest 181 Front cupholder 182 Front fog lamps 98 Front fog lamps, bulb replacement 225 Front fog lamps, front, bulb replacement 224 Front lamps 224 Front passenger airbags, automatic deactivation 102 Front passenger airbags, indicator lamp 102 FTM Flat Tire Monitor 107 **Fuel 204** Fuel cap 202 Fuel consumption, current 88 Fuel consumption, refer to Average fuel consumption 92 Fuel filler flap 202 Fuel gauge 86 Fuel quality 204 Fuel recommendation 204 Fuel, tank capacity 244

Fuse 229

### G

Garage door opener, refer to Integrated universal remote control 171 Gasoline 204 Gasoline quality 204 Gear change, automatic transmission 77 Gear shift indicator 89 General driving notes 188 Glare shield 178 Glasses compartment 182 Glass sunroof, refer to Panoramic class sunroof 47 Glove compartment 179 Gross vehicle weight, approved 243 Gross weight, permissible for trailer towing 243

### н

Handbrake, refer to Parking brake 70 Hand-held transmitter, alternating code 172 Hazard warning flashers 230 HDC Hill Descent Control 129 Head airbags 100 Headlamp control, automatic 96 Headlamp courtesy delay feature 95 Headlamp flasher 73 Headlamp glass 224 Headlamps 224 Headlamps, care 236 Headlamp washer system 74 Headliner 15 Head restraints 49 Head restraints, front 56 Head restraints, rear 57

Head-up Display 158	inflation pressure, tires 205	Key Memory, refer to Per-
Head-up Display, care 238	Inflation pressure warning	sonal Profile 33
Heating, refer to Parked-car	FTM, tires 107	Kickdown, automatic trans-
heating 167	Info display, refer to Com-	mission 77
Heavy cargo, stowing 193	puter 91	Knee airbag 100
Height, vehicle 242	Initialize, Tire Pressure Moni-	
High-beam Assistant 97	tor TPM 104	L
High beams 73	Initializing, Flat Tire Monitor	
High beams/low beams, refer	FTM 107	Lamp replacement 223
to High-beam Assistant 97	Instrument cluster 80	Lamp replacement, front 224
Hill Descent Control	Instrument cluster, electronic	Lamp replacement, rear 226
HDC 129	displays 82	Lamps 95
Hills 190	Instrument lighting 98	Lamps and bulbs 223
Hill start assistant, refer to	Integrated key 32	Lane departure warning 120
Drive-off assistant 127	Integrated universal remote	Lane margin, warning 120
Hints 6	control 171	Language on Control Dis-
Holder for beverages 182	Intelligent Emergency Re-	play 94
Homepage 6	quest 230	Lashing eyes, securing
Hood 215	Intelligent Safety 108	cargo 193
Horn 12	Intensity, AUTO pro-	LATCH child restraint fixing
Hot exhaust system 188	gram 162	system 64
HUD Head-up Display 158	Interior equipment 171	Launch Control 79
Hydroplaning 189	Interior lamps 98	Leather, care 236
Trydropidining 100	Interior lamps via remote con-	LED front fog lamps, bulb re-
1	trol 36	placement 225
•	Interior motion sensor 45	LED headlamps, Bulb re-
Ice warning, refer to External	Interior rearview mirror, auto-	placement 224
temperature warning 87	matic dimming feature 60	LED light 224
Icy roads, refer to External	Internet page 6	LEDs, light-emitting di-
temperature warning 87	Interval display, service re-	odes 223
Identification marks, tires 210	quirements 88	Length, vehicle 243
Identification number, refer to	quirements 66	Letters and numbers, enter-
Important features in the en-	J	ing 22
	3	3
gine compartment 215	looking points for the vehicle	Light alloy wheels, care 237
iDrive 16	Jacking points for the vehicle	Light control 96
Ignition key, refer to Remote	jack 226	Light-emitting diodes,
control 32	Joystick, automatic transmis-	LEDs 223
Ignition off 66	sion 77	Lighting 95
Ignition on 66	Jump-starting 232	Lighting via remote con-
Indication of a flat	V	trol 36
tire 104, 107	K	Light switch 95
Indicator and warning	W /	Load 192
lamps 84	Key/remote control 32	Loading 192
Individual air distribution 162	Keyless Go. refer to Comfort	Lock, door 37

Lamp replacement 223
Lamp replacement, front 224
Lamp replacement, rear 226
Lamps 95
Lamps and bulbs 223
Lane departure warning 120
Lane margin, warning 120
Language on Control Dis-
play 94
Lashing eyes, securing
cargo 193
LATCH child restraint fixing
system 64
Launch Control 79
Leather, care 236
LED front fog lamps, bulb re-
placement 225
LED headlamps, Bulb re-
placement 224
LED light 224
LEDs, light-emitting di-
odes 223
Length, vehicle 243
Letters and numbers, enter-
ing 22
Light alloy wheels, care 237
Light control 96
Light-emitting diodes,
LEDs 223
Lighting 95
Lighting via remote con-
trol 36
Light switch 95
Load 192
Loading 192
Lock, door 37
Locking/unlocking from in-
side 38

Individual settings, refer to

Personal Profile 33

Access 42

Locking/unlocking via door lock 37 Locking/unlocking with remote control 36 Locking, automatic 43 Locking, central 35 Locking, settings 43 Locking via tailgate 40 Lock, power window 46 Locks, doors, and windows 65 Low beams 95 Low beams, automatic, refer to High-beam Assistant 97 Lower back support 51 Lower tailgate 42 Luggage rack, refer to Roofmounted luggage rack 194 Lumbar support 51

### M

Maintenance 220 Maintenance requirements 220 Maintenance, service requirements 88 Maintenance system, **BMW 220** Malfunction displays, refer to Check Control 84 Malfunction, self-leveling suspension 131 Manual air distribution 162 Manual air flow 162 Manual brake, refer to Parking brake 70 Manual mode, transmission 78 Manual operation, backup camera 149 Manual operation, door lock 38 Manual operation, exterior mirrors 59

Manual operation, fuel filler flap 202 Manual operation, Park Distance Control PDC 146 Manual operation, parking brake 72 Manual operation, Top View 152 Marking on approved tires 213 Marking, run-flat tires 214 Master key, refer to Remote control 32 Maximum cooling 163 Maximum speed, display 89 Maximum speed, winter tires 213 Measure, units of 94 Medical kit 231 Memory for seat, mirrors, steering wheel 58 Menu, EfficientDynamics 198 Menu in instrument cluster 91 Menus, operating, iDrive 16 Menus, refer to iDrive operating concept 18 Messages, refer to Check Control 84 Microfilter 164 Minimum tread, tires 212 Mirror 58 Mirror memory 58 Mobile communication devices in the vehicle 189 Modifications, technical, refer to Safety 7 Moisture in headlamp 224 Monitor, refer to Control Display 16 Mounting of child restraint fixing systems 62 Moving sun shade 178 Multifunction steering wheel, buttons 12

### Ν

Navigation, see user's manual for Navigation, Entertainment and Communication Neck restraints, front, refer to Head restraints 56 Neck restraints, rear, refer to Head restraints 57 Neutral cleaner, see wheel cleaner 237 New wheels and tires 212 Night Vision with pedestrian detection 117 No Passing Information 89 Nylon rope for tow-starting/ towina 234

### O

OBD Onboard Diagnosis 221 OBD, see OBD Onboard Diagnosis 221 Obstacle marking, rearview camera 150 Octane rating, refer to Gasoline quality 204 Odometer 87 Office, see user's manual for Navigation, Entertainment and Communication Offroad trips 190 Oil 217 Oil, adding 218 Oil additives 218 Oil change 218 Oil change interval, service requirements 88 Oil filler neck 218 Oil types, alternative 218 Oil types, approved 218 Old batteries, disposal 229 Onboard monitor, refer to Control Display 16 Onboard vehicle tool kit 222

Opening and closing 32

Opening and closing, from in-	Permissible axle load 243	Rear socket 175
side 38	Personal Profile 33	Rear ventilation, third row of
Opening and closing via door	Pinch protection system,	seats, ventilation, third row
lock 37	glass sunroof 48	of seats 165
Opening and closing, with re-	Pinch protection system, win-	Rearview mirror 58
mote control 36	dows 46	Rear window defroster 163
Operating concept, iDrive 16	Plastic, care 237	Recirculated-air mode 163
Optional equipment, standard	Power failure 228	Recommended tire
equipment 6	Power windows 45	brands 213
Outside air, refer to Auto-	Pressure, tire air pres-	Refueling 202
matic recirculated-air con-	sure 205	Remaining range 87
trol 163	Pressure warning FTM,	Remote control/key 32
Overheating of engine, refer	tires 107	Remote control, malfunc-
to Coolant temperature 87	Preventing Auto Start	tion 37
Overtaking prohibitions 89	Stop 69	Remote control, parked-car
	Profile, refer to Personal Pro-	heating/ventilation 168
P	file 33	Remote control, univer-
	Programmable memory but-	sal 171
Paint, vehicle 236	tons, iDrive 22	Replacement fuse 229
Panorama View 153	Protective function, glass	Replacing parts 222
Panoramic glass sunroof 47	sunroof 48	Replacing wheels/tires 212
Parallel parking assistant 155	Protective function, win-	Reporting safety defects 9
Park Distance Control	dows 46	RES button 137
PDC 145	Push-and-turn switch, refer to	Reserve warning, refer to
Parked-car heating 167	Controller 16, 17	Range 87
Parked-car ventilation 167		Reset, Tire Pressure Monitor
Parked vehicle, condensa-	Q	TPM 104
tion 190		Residual heat, automatic cli-
Parking aid, refer to PDC 145	Queuing Assistant, see Con-	mate control 163
Parking assistant 155	gestion Assistant 140	Retaining straps, securing
Parking brake 70		cargo 193
Parking lamps 95	R	Retreaded tires 213
Parking with Auto Hold 71		Roadside parking lamps 96
Partition net 177	Radiator fluid 219	Roller sunblinds 47
Passenger side mirror, tilting	Radio-operated key, refer to	Roll stabilization, see Dy-
downward 59	Remote control 32	namic Drive 131
Pathway lines, rearview cam-	Radio ready state 67	RON gasoline quality 204
era 149	Radio, see user's manual for	Roof load capacity 243
PDC Park Distance Con-	Navigation, Entertainment	Roof-mounted luggage
trol 145	and Communication	rack 194
Pedestrian detection, refer to	Rain sensor 74	Rope for tow-starting/
Night Vision 117	Rear automatic climate con-	towing 234
Pedestrian warning with city	trol 165	RSC Run Flat System Com-
braking function 115	Rear center armrest 181	ponent, refer to Run-flat
People detection, refer to	Rear drink holder 182	tires 214
Night Vision 117	Rear lamps 226	

Rubber components, care 237 Run-flat tires 214

### S

Safe braking 189 Safety 7 Safety belt reminder for driver's seat and front passenaer seat 55 Safety belts 54 Safety belts, care 237 Safety Package, refer to Active Protection 124 Safety switch, windows 46 Safety systems, airbags 100 Saving fuel 195 Screen, refer to Control Display 16 Screwdriver 222 Screw thread for tow fittina 234 Seat belts, refer to Safety belts 54 Seat heating, front 52 Seat heating, rear 54 Seating position for children 62 Seat, mirror, and steering wheel memory 58 Seats 49 Seat ventilation, front 52 Selection list in instrument cluster 91 Selector lever, automatic transmission 77 Self-leveling suspension, air suspension 131 Self-leveling suspension, malfunction 131 Sensors, care 238 Service and warranty 7 Service history 89

Service requirements, Condition Based Service **CBS 220** Service requirements, displav 88 Service, Roadside Assistance 231 Services, ConnectedDrive Settings, locking/unlocking 43 Settings on Control Display 93 Settings, storing for seat, mirrors, steering wheel 58 Shifting, automatic transmission 76 Shift paddles on steering wheel 79 Shoulder support 52 Side airbags 100 Signaling, horn 12 Signals when unlocking 43 Sitting safely 49 Size 242 Ski and snowboard bag 178 Slide/tilt glass roof 47 Smallest turning circle 243 Smoker's package 173 Snow chains 214 Socket 174 Socket, OBD Onboard Diagnostics 221 SOS button 230 Spare fuse 229 Specified engine oil types 218 Speed, average 92 Speed limit detection, onboard computer 92 Speed limiter, display 89 Speed Limit Information 89 Speed limit in the computer 92 Split screen 21 SPORT+ - program, Dynamic **Driving Control 132** 

Sport automatic transmission 79 SPORT program, driving dynamics 133 Sport program, transmission 78 Stability control systems 127 Start/stop, automatic function 68 Start/Stop button 66 Start function during malfunction 33 Starting the engine 67 Status display, tires 103 Status information, iDrive 20 Status of Owner's Manual 6 Steering, active steering 130 Steering wheel, adjusting 60 Steering wheel heating 60 Steering wheel memory 58 Steptronic, automatic transmission 76 Stopping the engine 67 Storage compartment on the center console 180 Storage compartments 179 Storage compartments, locations 179 Storage compartment third row of seats 180 Storage, tires 213 Storing the vehicle 238 Summer tires, tread 211 Sun visor 178 Supplementary text message 85 Surround View 148 Suspension settings 131 Switch for Dynamic Driving Control 131 Switch, refer to Cockpit 12 Symbols 6 SYNC program, automatic climate control 163

### Т

Tachometer 86 Tailgate 38 Tailgate, automatic 40 Tail lamps 226 Technical changes, refer to Safety 7 Technical data 242 Telephone, see user's manual for Navigation, Entertainment and Communication Temperature, automatic climate control 162 Temperature display, external temperature 87 Temperature, engine oil 86 Tempomat, refer to Active Cruise Control 134 Terminal, starting aid 232 Text message, supplementary 85 Theft alarm system, refer to Alarm system 44 Theft protection, refer to Central locking system 35 Thermal camera, refer to Night Vision 117 Thiah support 51 Third row of seats 54 Tilt alarm sensor 45 Time of arrival 92 Tire damage 212 Tire identification marks 210 Tire inflation pressure 205 Tire inflation pressure monitor, refer to FTM 107 Tire Pressure Monitor **TPM 103** Tires, changing 212 Tires, everything on wheels and tires 205 Tires, run-flat tires 214 Tire tread 211

Tone, see user's manual for Navigation, Entertainment and Communication Tools 222 Top View 151 Total vehicle weight 243 Touchpad 19 Tow fitting 234 Towing 233 Tow-starting 233 TPM Tire Pressure Monitor 103 Traction control 129 TRACTION program, Dynamic Driving Control 132 Transmission, automatic 76 Transporting children safely 62 Tread, tires 211 Trip computer 93 Triple turn signal activation 73 Trip odometer 87 Trunk lid 38 Turning circle 243 Turning circle lines, rearview camera 150 Turn signals, operation 73



Unintentional alarm 45
Units of measure 94
Universal remote control 171
Unlock button, automatic transmission 77
Unlocking/locking from inside 38
Unlocking/locking via door lock 37
Unlocking/locking with remote control 36
Unlocking, settings 43
Unpaved roads, cross-country trips 190

Updates made after the editorial deadline 7
Upholstery care 237
USB interface 175



Variable steering 130 Vehicle battery 228 Vehicle battery, replacing 228 Vehicle, breaking in 188 Vehicle care 236 Vehicle equipment 6 Vehicle identification number, refer to Identification number in the engine compartment 215 Vehicle iack 226 Vehicle paint 236 Vehicle storage 238 Vehicle wash 235 Ventilation 164 Vertical Dynamic Control, refer to Dynamic Damping Control 131 Voice activation system 24



Warning indicators 84 Warning lamps 84 Warning messages, refer to Check Control 84 Warning triangle 231 Washer fluid 76 Washer fluid reservoir, capacity 244 Washer nozzles, windshield 75 Washer system 74 Washing, vehicle 235 Water on roads 189 Weights 243 Welcome lamps 95 Wheel base, vehicle 243

Wheel cleaner 237 Wheels, changing 212 Wheels, everything on wheels and tires 205 Wheels, Flat Tire Monitor FTM 107 Wheels, Tire Pressure Monitor TPM 103 Width, vehicle 242 Window defroster, rear 163 Windows, powered 45 Windshield, climate control 189 Windshield washer fluid 76 Windshield washer nozzles 75 Windshield washer system 74 Windshield wiper 74 Windshield wipers, fold-out position 75 Winter storage, care 238 Winter tires, suitable tires 213 Winter tires, tread 211 Wiper blades, replacing 222 Wiper fluid 76 Wiper system 74 Wood, care 237 Word match concept, navigation 23 Wrench 222



xDrive 129 Xenon headlamps, bulb replacement 224

More about BMW



bmwusa.com

