

BMW F15 X5 M Sport M50d Style Trim DIY

Here is the DIY for installing the RG Sport 2014+ BMW F15 X5 M Sport M50d style front bumper grill trim.
Before and after picture.



Tools needed:

- Phillips head screwdriver

Step 1: Separate the back mounting piece from the trim as it come assembled for shipping purposes.



Step 2: Insert the supplied yellow screw fishers to each hole on the grills.



Step 3: Put the back mounting piece against the grill, line up the hole and insert the supplied screws then tighten them using the phillips screwdriver by hand. DO NOT USE POWER TOOL.



Step 4: Snap the trim piece to the back mounting piece together.



Step 5: Repeat on the other side and Enjoy!!!

That's it and good luck on the DIY project.

Feel free to contact us at sales@rgsport.com or visit our websites at <http://www.rgsportshop.com> or <http://www.rgsport.com>.

Thank you – RG Sport