

X5 Spare Wheel Carrier

Owners of the 2007 E70 BMW X5 who enjoy travelling in remote areas will now be able to enjoy the peace of mind that comes from carrying a full-size or space saver spare tyre.

The BMW Spare Wheel Carrier provides a spare wheel solution for the 7 seater, and in the 5 seater, accommodates for luggage space should storage of a punctured tyre be necessary.

Retaining use of the existing rear camera, the Spare Wheel Carrier (SWC) incorporates a Park Distance Control sensor. Also included with the SWC is a full-wheel protective cover (which can be colour-coded in dealership), plus a wiring kit, wheel brace and carrier assembly. (Not included is the tow bar, required for assembly, or the Jack Kit, required in the 7 Seater.)

To experience the confidence to go further, enquire about the X5 Spare Wheel Carrier at your BMW Dealer.

SWC operating instructions To gain access to the rear storage area:

Step 1.Depress the lever beneath the Spare Wheel Carrier (SWC).



Step 2.

Swing the SWC into the open position using the spring-loaded locking pin.



Step 3.

Lock the SWC in the open position using the locking pir



Step 4.

With the SWC in the fixed open position, you now have easy and safe access to the rear storage area. To close, reverse the above steps.



To gain access to the spare wheel:

*Please complete steps 1-4 before proceeding.

Step 5.

Unlock the full-wheel Protective Cover from the underside of the SWC.



Step 6.

Disconnect the electrical cable.



Step 7.

The full-wheel Protective Cover can now be lifted off to gain access to the spare tyre. Place the removed wheel cover in a safe place



Step 8.

Using the additional wheel brace (supplied), unbolt and carefully remove the spare wheel. To replace the spare / punctured wheel to the carrier, reverse steps 5–8. Refer to your Owner's Manual for the tyre changing procedure.



^{*}Spare Wheel Carrier will partially obscure the Rear Wheel Camera view by 5–10%.

BMW Accessories & Lifestyle

bmw.com.au

